FUJ¦FILM

DIGITAL CAMERA FINEPIX JX600 Series

Owner's Manual

Thank you for your purchase of this product. This manual describes how to use your FUJIFILM digital camera and the supplied software. Be sure that you have read and understood its contents and the warnings in "For Your Safety" (E ii) before using the camera.

For information on related products, visit our website at http://www.fujifilm.com/products/digital_cameras/index.html

First Steps	
Basic Photography and Playback	• • • • • •
More on Photography	_
More on Playback	
Movies	
Connections	9
Menus	
Technical Notes	
Troubleshooting	
Appendix	

BL02501-100 EN

Before You Begin

Finat Ct



IMPORTANT SAFETY INSTRUCTIONS

- <u>Read Instructions</u>: All the safety and operating instructions should be read before the appliance is operated.
- <u>Retain Instructions</u>: The safety and operating instructions should be retained for future reference.
- <u>Heed Warnings</u>: All warnings on the appliance and in the operating instructions should be adhered to.
- Follow Instructions: All operating and use instructions should be followed.

Installation

Power Sources: This video product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For video products intended to operate from battery power, or other sources, refer to the operating instructions.

Grounding or Polarization: This video product is equipped with a polarized alternatingcurrent line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug. Alternate Warnings: This video product is equipped with a three-wire grounding-type plug, a plug having a third (grounding) pin. This plug will only fit into a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding type plug.

Overloading: Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.

Ventilation: Slots and openings in the cabinet are provided for ventilation, to ensure reliable operation of the video product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the video product on a bed, sofa, rug, or other similar surface.

This video product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to. This video product should never be placed near or over a radiator or heat register.

Attachments: Do not use attachments not recommended by the video product manufacturer as they may cause hazards.

Water and Moisture: Do not use this video product near water—for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, and the like.

Power-Cord Protection: Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

Accessories: Do not place this video product on an unstable cart, stand, tripod, bracket, or table. The video product may fall, causing serious injury to a child or adult, and serious damage to the appliance. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the video product. Any mounting of the appliance should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.




For Your Safety

Antennas

Duttoor Antenna Grounding: If an outside antenna or cable system is connected to the video product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and builtup static charges. Section 810 of the National Electrical Code, ANSI/NFPA No. 70, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

EXAMPLE OF ANTENNA GROUNDING AS PER NATIONAL ELECTRICAL CODE



Power Lines: An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

Use

Cleaning: Unplug this video product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

Object and Liquid Entry: Never push objects of any kind into this video product through openings as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spiill liquid of any kind on the video product.

Lightning: For added protection for this video product receiver during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the video product due to lightning and powerline surges.

Service

Servicing: Do not attempt to service this video product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

Damage Requiring Service: Unplug this video product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- When the power-supply cord or plug is damaged.
- If liquid has been spilled, or objects have fallen into the video product.
- If the video product has been exposed to rain or water.
- If the video product has been dropped or the cabinet has been damaged.

If the video product does not operate nor-

mally follow the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the video product to its normal operation.

When the video product exhibits a distinct change in performance—this indicates a need for service.

Replacement Parts: When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

Safety Check: Upon completion of any service or repairs to this video product, ask the service technician to perform safety checks to determine that the video product is in proper operating condition.

Be sure to read these notes before use

Safety Notes

- Make sure that you use your camera correctly. Read these safety notes and your Owner's Manual carefully before use.
- · After reading these safety notes, store them in a safe place.

About the lcons

The icons shown below are used in this document to indicate the severity of the injury or damage that can result if the information indicated by the icon is ignored and the product is used incorrectly as a result.



This icon indicates that death or serious injury can result if the information is ignored.



This icon indicates that personal injury or material damage can result if the information is ignored.

The icons shown below are used to indicate the nature of the instructions which are to be observed.



Triangular icons tell you that this information requires attention ("Important").

Circular icons with a diagonal bar tell you that the action indicated is prohibited ("Prohibited").

Filled circles with an exclamation mark indicate an action that must be performed ("Required").





If a problem arises, turn the camera off, remove the battery, and disconnect and unplug the AC power adapter. Continued use of the camera when it is emitting smoke, is emitting any unusual odor, or is in any other abnormal state can cause a fire or electric shock. Contact your FUJIFLIM dealer.



Do not allow water or foreign objects to enter the camera. If water or foreign objects get inside the camera, turn the camera off, remove the battery, and disconnect and unplug the AC power adapter. Continued use of the camera can cause a fire or electric shock. Contact your FUJIFILM dealer.

🕂 WARNING

Do not use the camera in the bathroom or shower. This can cause

Do not use in a fire or electric shock.



Never attempt to change or take apart the camera (never open the case). Failure to observe this precaution can cause fire or electric shock.



Should the case break open as the result of a fail or other axident, do not touch the exposed parts. Failure to observe this precaution could result in electric shock or in injury from touching the damaged parts. Remove the battery immediately, taking care to avoid injury or electric shock, and take the product to the point of purchase for consultation.



Do not change, heat or unduly twist or pull the connection cord and do not place heavy objects on the connection cord. These actions could damage the cord and cause a fire or electric shock. If the cord is damaged, contact your FUJIFILM dealer.



Do not place the camera on an unstable surface. This can cause the camera to fall or tip over and cause injury.

Never attempt to take pictures while in motion. Do not use the camera while you are walking or driving a vehicle. This can result in you falling down or being involved in a traffic accident.




Do not touch any metal parts of the camera during a thunderstorm. This can cause an electric shock due to induced current from the lightning discharge.




Do not use the battery except as specified. Load the battery as shown by the indicator.

Do not heat, change or take apart the battery. Do not drop or subject the battery to impacts. Do not store the battery with metallic products. Any of these actions can cause the battery to burst or leak and cause fire or injury as a result.

Use only the battery or AC power adapters specified for use with this camera. Do not use voltages other than the power supply voltage shown. The use of other power sources can cause a fire.



For Your Safety



The Battery and Power Supply

Note: Check the type of battery used in your camera and read the appropriate sections.

The following describes the proper use of batteries and how to prolong their life. Incorrect use can shorten battery life or cause leakage, overheating, fire, or explosion.

Li-ion Batteries

Read this section if your camera uses a rechargeable Li-ion battery.

The battery is not charged at shipment. Charge the battery before use. Keep the battery in its case when not in use.

Notes on the Battery

The battery gradually loses its charge when not in use. Charge the battery one or two days before use.

Battery life can be extended by turning the camera off when not in use.

Battery capacity decreases at low temperatures; a depleted battery may not function at when cold. Keep a fully charged spare battery in a warm place and exchange as necessary, or keep the battery in your pocket or other warm place and insert it in the camera only when shooting. Do not place the battery in direct contact with hand warmers or other heating devices.

Charging the Battery

Charge the battery in the supplied battery charger. Charging times will increase at ambient temperatures below +10°C (+50°F) or above +35°C (+95°F). Do not attempt to charge the battery at temperatures above 40°C (+104°F); at temperatures below 0°C (+32°F), the battery will not charge.

Do not attempt to recharge a fully charged battery. The battery does not however need to be fully discharged before charging.

The battery may be warm to the touch immediately after charging or use. This is normal.

Battery Life

At normal temperatures, the battery can be recharged about 300 times. A noticeable decrease in the length of time the battery will hold a charge indicates that it has reached the end of its service life and should be replaced.

Storage

Performance may be impaired if the battery is left unused for extended periods when fully charged. Run the battery flat before storing it.

If the camera will not be used for an extended period, remove the battery and store it in a dy place with an ambient temperature of from $+15^{\circ}$ C to $+25^{\circ}$ C ($+59^{\circ}$ F to $+77^{\circ}$ F). Do not store in locations exposed to extremes of temperature.

Cautions: Handling the Battery

- Do not transport or store with metal objects such as necklaces or hairpins.
- · Do not expose to flame or heat.
- · Do not disassemble or modify.
- Use with designated chargers only.
- Do not drop or subject to strong physical shocks.
- · Do not expose to water.
- · Keep the terminals clean.
- The battery and camera body may become warm to the touch after extended use. This is normal.

AA Alkaline/Rechargeable Ni-MH Batteries/ AA lithium batteries

Read this section if your camera uses AA alkaline or rechargeable AA Ni-MH batteries. Information on compatible battery types may be found elsewhere in the camera manual.

Cautions: Handling the Batteries

- Do not expose to water, flame, or heat, or store in warm or humid conditions.
- Do not transport or store with metal objects such as necklaces or hairpins.
- Do not disassemble or modify the batteries or battery casing.
- · Do not subject to strong physical shocks.
- Do not use batteries that are leaking, deformed, or discolored.
- Keep out of reach of infants and small children.
- · Insert in the correct orientation.

- Do not mix old and new batteries, batteries with different charge levels, or batteries of different types.
- If the camera will not be used for an extended period, remove the batteries. Note that the camera clock will be reset.
- The batteries may be warm to the touch immediately after use. Turn the camera off and allow the batteries to cool before handling.
- Battery capacity tends to decrease at low temperatures. Keep spare batteries in a pocket or other warm place and exchange as necessary. Cold batteries may recover some of their charge when warmed.
- Fingerprints and other stains on the battery terminals can impair battery performance. Thoroughly clean the terminals with a soft, dry cloth before inserting them in the camera.



If the batteries leak, clean the battery compartment thoroughly before inserting new batteries.



If fluid from the battery comes into contact with skin or clothing, flush the affected area with water. If fluid enters your eyes, immediately flush the affected area with water and seek medical attention. Do not rub your eyes. Failure to observe this precaution could result in permanent visual impairment

Ni-MH Batteries

The capacity of NI-MH batteries may be temporarily reduced when new, after long periods of disuse, or if they are repeatedly recharged before being fully discharged. This is normal and does not indicate a malfunction. Capacity can be increased by repeatedly discharging the batteries using the discharge option in the camera setup menu and recharging them using a battery charger (sold separately).

① CAUTION: Do not use the discharge option with alkaline batteries.

The camera draws a small amount of current even when off. Ni-MH batteries that have been left in the camera for an extended period may be drawn down to the point that they no longer hold a charge. Battery performance may also drop if the batteries are run down in a device such as a flashlight. Use the discharge option in the camera setup menu to discharge Ni-MH batteries. Batteries that no longer hold a charge even after repeatedly being discharged and recharged have reached the end of their service life and must be replaced.

Ni-MH batteries can be recharged in a battery charger (sold separately). Batteries may become warm to the touch after charging. Refer to the instructions provided with the charger for more information. Use the charger with compatible batteries only.

Ni-MH batteries gradually lose their charge when not in use.

Disposal

Dispose of used batteries in accord with local regulations.

AC Power Adapters (Available Separately)

This section applies to all camera models. Use only FUJIFILM AC power adapters designated for use with this camera. Other adapters could damage the camera.

- The AC power adapter is for indoor use only.
- Be sure the DC plug is securely connected to the camera.
- Turn the camera off before disconnecting the adapter. Disconnect the adapter by the plug, not the cable.
- · Do not use with other devices.
- · Do not disassemble.
- · Do not expose to high heat and humidity.
- · Do not subject to strong physical shocks.
- The adapter may hum or become hot to the touch during use. This is normal.
- If the adapter causes radio interference, reorient or relocate the receiving antenna.

Using the Camera

Do not aim the camera at extremely bright light sources, such as the sun in a cloudless sky. Failure to observe this precaution could damage the camera image sensor.

Take Test Shots

Before taking photographs on important occasions (such as at weddings or before taking the camera on a trip), take a test shot and view the result in the LCD monitor to ensure that the camera is functioning normally. FUJIFILM Corporation can not accept liability for damages or lost profits incurred as a result of product malfunction.

Notes on Copyright

Unless intended solely for personal use, images recorded using your digital camera system cannot be used in ways that infringe copyright laws without the consent of the owner. Note that some restrictions apply to the photographing of stage performances, entertainments, and exhibits, even when intended purely for personal use. Users are also asked to note that the transfer of memory cards containing images or data protected under copyright laws is only permissible within the restrictions imposed by those copyright laws.

Handling

To ensure that images are recorded correctly, do not subject the camera to impact or physical shocks while images are being recorded.

Liquid Crystal

In the event that the LCD monitor is damaged, care should be taken to avoid contact with liquid crystal. Take the urgent action indicated should any of the following situations arise:

- If liquid crystal comes in contact with your skin, clean the area with a cloth and then wash thoroughly with soap and running water.
- If liquid crystal enters your eyes, flush the affected eye with clean water for at least 15 minutes and then seek medical assistance.
- If liquid crystal is swallowed, rinse your mouth thoroughly with water. Drink large quantities of water and induce vomiting, then seek medical assistance.

Although the display is manufactured using extremely high-precision technology, it may contain pixels that are always lit or that do not light. This is not a malfunction, and images recorded with the product are unaffected.

Trademark Information

xD-Picture Card and _____ are trademarks of FUJIFILM Corporation. The typefaces included herein are solely developed by DynaComware Taiwan Inc. Macintosh, OuickTime, and Mac OS are trademarks of Apple Inc. in the U.S.A. and other countries. Windows 8, Windows 7, Windows Vista, and the Windows logo are trademarks of the Microsoft group of companies. Adobe and Adobe Reader are either trademarks or registered trademarks of Adobe Systems Incorporated in the U.S.A. and/or other countries. The SDHC and SDXC logos are trademarks of SD-3C, LLC. The HDMI logo is a trademark. YouTube is a trademark of Google Inc. All other trade names mentioned in this manual are the trademarks or registered trademarks of their respective owners.

Electrical Interference

This camera may interfere with hospital or aviation equipment. Consult with hospital or airline staff before using the camera in a hospital or on an aircraft.

Color Television Systems

NTSC (National Television System Committee) is a color television telecasting specification adopted mainly in the U.S.A., Canada, and Japan. PAL (Phases Alternation by Line) is a color television system adopted mainly in European countries and China.

Exif Print (Exif Version 2.3)

Exif Print is a newly revised digital camera file format in which information stored with photographs is used for optimal color reproduction during printing.

IMPORTANT NOTICE: Read Before Using the Software

Direct or indirect export, in whole or in part, of licensed software without the permission of the applicable governing bodies is prohibited.


About This Manual

Before using the camera, read this manual and the warnings in "For Your Safety" (I) ii). For information on specific topics, consult the sources below.

Memory Cards

Pictures can be stored in an optional SD, SDHC, and SDXC memory cards (🕮 9), referred to in this manual as "memory cards".

Frequently-Used Buttons



For Your Safety	ii
IMPORTANT SAFETY INSTRUCTIONS	
Safety Notes	iv
About This Manual	
Frequently-Used Buttons	x

Before You Begin

Symbols and Conventions	1
Supplied Accessories	1
Parts of the Camera	
Camera Displays	4
Shooting	4
Playback	

First Steps

Inserting the Battery and a Memory Card	6
Compatible Memory Cards	9
Charging the Battery	11
Turning the Camera on and Off	
Shooting Mode	13
Playback Mode	
Basic Setup	15

Basic Photography and Playback

Taking Pictures in 品品 (Scene Recognition) Mode	16
Viewing Pictures	19

More on Photography

Shooting Mode	20
Choosing a Shooting Mode	20
Shooting Mode Options	21
A ADVANCED FILTER	23
Panorama	
읆 INDIVID. SHUTTER 3D	27
Focus Lock	29
Exposure Compensation	31
Macro Mode (Close-ups)	32
4 Using the Flash (Intelligent Flash)	33
் Using the Self-Timer	35

More on Playback

Playback Options	36
★ Favorites: Rating Pictures	
Playback Zoom	
Multi-Frame Playback	
Deleting Pictures	
Viewing Panoramas	40

Movies

Recording Movies	41
Viewing Movies	43

Connections

Viewing Pictures on TV	44
Printing Pictures via USB	45
Printing the DPOF Print Order	47
Viewing Pictures on a Computer	49
Windows: Installing MyFinePix Studio	49
Connecting the Camera	51
Importing pictures or movies to Mac (Macintosh)	53

Menus	
Using the Menus: Shooting Mode	54
Using the Shooting Menu	54
Shooting Menu Options	54
SHOOTING MODE	54
ISO ISO	54
IMAGE SIZE	55
👪 IMAGE QUALITY	56
FINEPIX COLOR	56
WB WHITE BALANCE	57
CONTINUOUS	57
😰 FACE DETECTION	58
AF MODE	58
PANORAMA MODE	59
MOVIE AF MODE	59
MOVIE MODE	59

Using the Menus: Playback Mode	
Using the Playback Menu	
Playback Menu Options	
💶 PHOTOBOOK ASSIST	61
🐼 IMAGE SEARCH	62
💼 ERASE	62
🖈 MOVIE EDIT	63
🚳 MARK FOR UPLOAD TO	64
■ SLIDE SHOW	65
•• PROTECT	65
CROP	66
🔚 RESIZE	66
IMAGE ROTATE	67
PRINT ORDER (DPOF)	67

68
68
69
69
69
69
69
70
70
70
71
71
71
72
72
72
72
72
72
73
74
74
75
75
75
75

Technical Notes

Optional Accessories	
Printing	
Computer Related	76
Audio/Visual	76
Accessories from FUJIFILM	77
Caring for the Camera	78
Storage and Use	78
Water and Sand	78
Condensation	78
Cleaning	79
Traveling	79

Troubleshooting	
Problems and Solutions	80
Warning Messages and Displays	85
······································	
Appendix	
	89

FinePix JX600 - JX645	90
Specifications	91

Before You Begin

Symbols and Conventions


The following symbols are used in this manual:

- $\ensuremath{\mathbbm O}$: This information should be read before use to ensure correct operation.
- : Additional information that may be helpful when using the camera.
- 🖽 : Other pages in this manual on which related information may be found.

Menus and other text in the LCD monitor are shown in **bold**. In the illustrations in this manual, displays may be simplified for explanatory purposes.

Supplied Accessories


The following items are included with the camera:



* Shape of adapter varies with region of sale.

Parts of the Camera

For more information, refer to the page listed to the right of each item.



* Illustrations in this manual may be simplified for explanatory purposes.

Parts of the Camera


1 Self-timer lamp	12 • (movie recording) button
2 Flash	
3 Shutter button	silent mode) button [*] x
4 Lens and lens cover	14 Battery-chamber cover 6
5 Microphone	15 USB multi-connector
6 LCD monitor	16 Speaker
7 W (zoom out) button17, 37	17 Tripod mount
8 ON/OFF button	18 Memory card slot7
9 T (zoom in) button17, 37	19 Battery chamber
10 ▶ (playback) button 19	20 Battery latch
11 Strap eyelet	
*Press and hold the DISP/BACK button until 4 is displayed.	

<u>Camera Displays</u>

The following types of indicator may be displayed during shooting and playback. Indicators vary with camera settings.

Shooting

1 ² 3456	7 Number of available frames
	8 Sensitivity54
	9 Image size/Image quality55, 56
	10 Focus warning
	11 FINEPIX color
	12 White balance
	13 Battery level
(1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	14 Exposure compensation
$15 + 250 F4.5 E = -1\frac{2}{3} - \frac{1}{14}$	15 Shutter speed/Aperture
	16 Date and time
1 Shooting mode 20	17 Blur warning
2 Intelligent Face Detection indicator	18 Focus frame
3 Continuous shooting mode57	19 Self-timer indicator
4 Silent mode indicator3, 69	20 Macro (close-up) mode 32
5 Date stamp	21 Flash mode
6 Movie mode 59	



Battery Level

Battery level is shown as follows:

Indicator	Description
(white)	Battery partially discharged.
(white)	Battery more than half discharged.
4 (red)	Low battery. Charge as soon as possible.
d (blinks red)	Battery exhausted. Turn camera off and charge battery.

Hiding and Viewing Indicators

Press DISP/BACK to cycle through shooting and playback indicators as follows:

- Shooting: Indicators displayed/indicators hidden/best framing
- Playback: Indicators displayed/indicators hidden/★ favorites

First Steps

Inserting the Battery and a Memory Card

Insert the battery and memory card as described below.

1 Open the battery-chamber cover.


- Be sure the camera is off before opening the battery-chamber cover.
- ① Do not open the battery-chamber cover when the camera is on. Failure to observe this precaution could result in damage to image files or memory cards.



① Do not use excessive force when handling the battery-chamber cover.

2 Insert the battery.

Align the orange stripe on the battery with the orange battery latch and slide the battery into the camera, keeping the battery latch pressed to one side. When inserting the battery, be sure that the battery is secured by the orange battery latch. If the battery is not securely latched, the camera may not turn on or may turn off without warning.



The camera uses an NP-45A/NP-45B rechargeable battery.


① Insert the battery in the correct orientation. Do Not use force or attempt to insert the battery upside down or backwards. The battery will slide in easily in the correct orientation.

3 Insert the memory card.


Holding the memory card in the orientation shown at right, slide it in until it clicks into place at the back of the slot.

 Be sure card is in the correct orientation; do not insert at an angle or use force.
 Be sure card is in the correct orientation; do not insert at an angle or use
 force.
 Correct orienta Sure card is in the correct orienta tion; do not insert at an angle or use
 force.
 Sure card is in the correct orienta tion; do not insert at an angle or use
 force.
 Sure card is in the correct orienta tion; do not insert at an angle or use
 force.
 Sure card is in the correct orienta tion; do not insert at an angle or use
 force.

- ① SD/SDHC/SDXC memory cards can be locked, making it impossible to format the card or to record or delete images. Before inserting an SD/SDHC/SDXC memory card, slide the write-protect switch to the unlocked position.
- **4** Close the battery-chamber cover.







Removing the Battery and Memory Card

Before removing the battery or memory card, *turn the camera off* and open the battery-chamber cover.

To remove the battery, press the battery latch to the side, and slide the battery out of the camera as shown.

Battery latch





Compatible Memory Cards

FUJIFILM and SanDisk SD, SDHC, and SDXC memory cards have been approved for use in the camera. A complete list of approved memory cards is available at *http://www.fujifilm.com/support/digital_cameras/compatibility/*. Operation is not guaranteed with other cards. The camera can not be used with *xD-Picture Cards* or MultiMediaCard (MMC) devices.

- ① Memory Cards
- Do not turn the camera off or remove the memory card while the memory card is being formatted or data are being recorded to or deleted from the card. Failure to observe this precaution could damage the card.
- Format SD/SDHC/SDXC memory cards before first use, and be sure to reformat all memory cards after using them in a computer or other device. For more information on formatting memory cards, see " FORMAT" (1).
- Memory cards are small and can be swallowed; keep out of reach of children. If a child swallows a memory card, seek medical assistance immediately.
- miniSD or microSD adapters that are larger or smaller than the standard dimensions of an SD/SDHC/SDXC memory card may not eject normally; if the card does not eject, take the camera to an authorized service representative. Do not forcibly remove the card.
- Do not affix labels to memory cards. Peeling labels can cause camera malfunction.
- Movie recording may be interrupted with some types of SD/SDHC/SDXC memory card. Use a **CLASS** card or better when shooting HD.
- Formatting a memory card in the camera creates a folder in which pictures are stored. Do not rename or delete this folder or use a computer or other device to edit, delete, or rename image files. Always use the camera to delete pictures; before editing or renaming files, copy them to a computer and edit or rename the copies, not the originals.

First Steps

① Batteries

- Remove dirt from the battery terminals with a clean, dry cloth. Failure to observe this precaution could prevent the battery from charging.
- Do not affix stickers or other objects to the battery. Failure to observe this precaution could make it impossible to remove the battery from the camera.
- Do not short the battery terminals. The battery could overheat.
- Read the cautions in "The Battery and Power Supply" (🕮 vi).
- Use only battery chargers designated for use with the battery. Failure to observe this precaution could result in product malfunction.
- Do not remove the labels from the battery or attempt to split or peel the outer casing.
- The battery gradually loses its charge when not in use. Charge the battery one or two days before use.

First Steps


Charging the Battery

The battery is not charged at shipment. Charge the battery before use. The camera charges the battery internally.

1 Charge the battery.

Turn the camera off and connect the camera to the supplied AC power adapter using the supplied USB cable. Then plug the AC power adapter into an indoor power outlet.

① Be sure the connectors are in the correct orientation and then insert them fully.




The camera operates in external power mode if the camera is turned on while plugged into AC power.

The Charging Indicator		
The charging indicator is displayed in the center of the LCD monitor.		
Charging indicator	Battery status	Action
<u>دی</u>	Battery charging.	
ĊD	Battery fault.	Unplug the AC power adapter from the power outlet and reinsert the battery in the correct orientation (🗐 80).
The charging indicator will disappear when charging completes.		

Charging via a computer

The battery can be charged by connecting the camera to a computer.

Turn the camera off and connect the supplied USB cable as shown, making sure the connectors are fully inserted. Connect the camera directly to the computer; do not use a USB hub or keyboard.




- ① If the camera is turned on, charging is not available.
- ① If the computer goes into sleep mode while charging, charging will stop. To continue charging, disable sleep mode on the computer, and disconnect and connect the USB cable.
- $\ensuremath{\mathbbm O}$ Charging may be impossible depending on computer specifications, settings or conditions.

Turning the Camera on and Off

Shooting Mode

Press the **ON/OFF** button to turn the camera on. The lens will extend and the lens cover will open.




Press **ON/OFF** again to turn the camera off.

Switching to Playback Mode

Press the D button to start playback. Press the shutter button halfway to return to shooting mode.

Playback Mode

To turn the camera on and begin playback, press the **D** button for about a second.



Press the **D** button again or press the **ON/OFF** button to turn the camera off.

Switching to Shooting Mode

To exit to shooting mode, press the shutter button halfway. Press the **D** button to return to playback.

- ${\scriptstyle \textcircled{O}}$ Forcibly obstructing the lens could cause damage or product malfunction.
- $\ensuremath{\mathbbm O}$ Fingerprints and other marks on the lens can affect pictures. Keep the lens clean.
- ${\rm \oplus}\,$ The ${\rm ON/OFF}\,$ button does not completely end the supply of power to the camera.

Auto Power Off

The camera will turn off automatically if no operations are performed for the length of time selected for **T** AUTO POWER OFF (E 72).

Basic Setup

A language-selection dialog is displayed the first time the camera is turned on. Set up the camera as described below (you can reset the clock or change languages at any time using the **③ DATE/TIME** or **③** 言語/LANG. options in the setup menu; for information on displaying the setup menu, see page 68).

- 1 Highlight a language and press MENU/OK.
 - Press DISP/BACK to skip the current step. Any steps you skip will be displayed the next time the camera is turned on.
- 2 The date and time will be displayed. Press the selector left or right to highlight the year, month, day, hour, or minute and press up or down to change. To change the order in which the year, month, and day are displayed, highlight the date format and press the selector up or down. Press **MENU/OK** when settings are complete.

The Camera Clock

If the battery is removed for an extended period, the camera clock will be reset and the language-selection dialog will be displayed when the camera is turned on.



BACKONO

OK SET

START MENU
図言語/LANG.
ENGLISH
日本語
中文简
FRANCAIS
DEUTSCH
OK SET BACK NO


Basic Photography and Playback

Taking Pictures in 🙈 (Scene Recognition) Mode

This section describes how to take pictures in 📠 (scene recognition) mode. The camera automatically analyzes the composition and adjusts settings appropriately.

1 Turn the camera on.

Press the **ON/OFF** button to turn the camera on. Shooting indicators will be displayed.



🐤 The 😫 Icon

This icon indicates that the camera continuously searches for faces to select the appropriate scene, increasing the drain on the battery.




Scene Icon

The camera selects the scene according to shooting conditions and the type of subject: O PORTRAIT (portraits), O LANDSCAPE (landscapes), O NIGHT (poorly-lit landscapes), O MACRO (close ups), O NIGHT PORTRAIT (poorly-lit portraits), O BACKLIT PORTRAIT (backlit portraits), O AUTO (all other scenes)

2 Frame the picture.

Use the zoom buttons to frame the picture in the display.



Holding the Camera

Hold the camera steady with both hands and brace your elbows against your sides. Shaking or unsteady hands can blur your shots.

To prevent pictures that are out of focus or too dark (underexposed), keep your fingers and other objects away from the lens and flash.





3 Focus.

Press the shutter button halfway to focus.

The lens may make a noise when the camera focuses; this is normal.

If the camera is able to focus, it will beep twice.

If the camera is unable to focus, the focus frame will turn red, **!AF** will be displayed. Change the composition or use focus lock (閏 29).

4 Shoot.

Smoothly press the shutter button the rest of the way down to take the picture.


If the subject is poorly lit, the flash may fire when the picture is taken. For information on using the flash when lighting is poor, see "4 Using the Flash (Intelligent Flash)" (
 (
 33).

The Shutter Button

The shutter button has two positions. Pressing the shutter button halfway sets focus and exposure; to shoot, press the shutter button the rest of the way down.







Viewing Pictures

Pictures can be viewed in the LCD monitor. When taking important photographs, take a test shot and check the results.


1 Press the 🕨 button.


The most recent picture will be displayed.

2 View additional pictures.

Press the selector right to view pictures in the order recorded, left to view pictures in reverse order.

Press the shutter button to exit to shooting mode.





More on Photography


Shooting Mode

Choose a shooting mode according to the scene or type of subject.

<u>Choosing a Shooting Mode</u>

1 Press **MENU/OK** to display the shooting menu.

- 2 Press the selector left or right to select **MODE** and press **MENU/OK** to display shooting mode options.
- 3 Highlight the desired mode and press MENU/OK.







Shooting Mode Options

Scene	Description	
品品 SCENE RECOGNITION	The camera automatically analyzes the composition and selects a scene according to shooting conditions and the type of subject.	
AUTO	Choose for crisp, clear snapshots. This mode is recommended in most situations.	
P PROGRAM AE	Options for white balance and AF mode will be fully available and expo- sure compensation can be adjusted manually.	
©\$ NATURAL & \$	The camera takes two shots: one without the flash and one with.	
NATURAL LIGHT	Capture natural lighting under low-light conditions.	
PORTRAIT	Choose for portraits.	
😂 BABY MODE	Choose for natural skin tones when taking portraits of infants.	
SMILE&SHOOT	The shutter is released automatically when Intelligent Face Detection detects a smiling face.	
LANDSCAPE	Choose for daylight shots of buildings and landscapes.	
A ADVANCED FILTER	Take photos with filter effects.	
🕅 PANORAMA	Take up to three pictures and join them together to form a panorama.	
🛠 SPORT	Choose when photographing moving subjects.	
C NIGHT	Choose this mode for poorly lit twilight or night scenes.	
& ^{(★} NIGHT (TRIPOD)	TRIPOD) Choose this mode for slow shutter speeds when shooting at night.	
• FIREWORKS	Slow shutter speeds are used to capture the expanding burst of light from a firework.	
🛎 SUNSET	Choose this mode to record the vivid colors in sunrises and sunsets.	

Shooting Mode

Scene	Description
* @ ∗ SNOW	Choose for crisp, clear shots that capture the brightness of scenes domi- nated by shining white snow.
🔊 BEACH	Choose for crisp, clear shots that capture the brightness of sunlit beaches.
₹ PARTY	Capture indoor background lighting under low-light conditions.
✤ FLOWER	Choose for vivid close-ups of flowers.
TEXT TEXT	Take clear pictures of text or drawings in print.
岛 INDIVID. SHUTTER	3D Take two shots from different angles to create a 3D image.

ADVANCED FILTER

Take photos with filter effects.

1 Select A ADVANCED FILTER for shooting mode (🕮 20).

2 Select a filter effect and press MENU/OK.

Filter	Description
n TOY CAMERA	Choose for a retro toy camera effect.
Sa MINIATURE	The tops and bottoms of pictures are blurred for a diorama effect.
🙉 POP COLOR	Create high-contrast images with saturated colors.
ଲ SOFT FOCUS	Create a look that is evenly soft throughout the whole image.
CROSS SCREEN	Create a star pattern where lines radiate out from bright objects.
🕒 PARTIAL COLOR (RED)	
🕰 PARTIAL COLOR (ORANGE)	
🗣 PARTIAL COLOR (YELLOW)	Areas of the image that are the selected color are recorded in that
🕰 PARTIAL COLOR (GREEN)	color. All others areas of the image are recorded in black-and-white.
🕰 PARTIAL COLOR (BLUE)	
PARTIAL COLOR (PURPLE)	


Depending on the subject and camera settings, images may in some cases be grainy or vary in brightness and hue.

🖬 폐 PANORAMA

In this mode, you can take up to three pictures and join them together to form a panorama. Use of a tripod is recommended to assist in composing overlapping shots. The camera zooms all the way out and zoom remains fixed at the widest angle until shooting is complete.

- Operations are described in the factory settings (Mathematication AUTO).
 - 1 Select 🖼 PANORAMA for shooting mode (🕮 20).
 - **2** Press the selector up to select a frame. Press the selector left or right to highlight a pan direction and press **MENU/OK**.
 - **3** Take a photograph. Exposure and white balance for the panorama are set with the first shot.
 - Frame the next shot to overlap with the previous picture by superimposing

 on + so that they form a solid circle (●). The camera will release the shutter automatically.



- **5** Take the last shot as described in Step 4.
 - To end shooting and create a panorama after the first or second shot, press the multi selector up after completing Step 3 or Step 4 and proceed to Step 6.
- 6 Press MENU/OK to save the picture.
 - Saving a panorama may take a while.
- ${\rm \oplus}\,$ Panoramas are created from multiple frames. The camera may in some cases be unable to stitch the frames together perfectly.
- ① The desired results may not be achieved with moving subjects, subjects close to the camera, unvarying subjects such as the sky or a field of grass, subjects that are in constant motion, such as waves and waterfalls, or subjects that undergo marked changes in brightness. Panoramas may be blurred if the subject is poorly lit.

For Best Results

For best results, be careful not to tilt the camera backward or forward or to either side and try not to move the camera while **①** and **+** are aligned to form a solid circle.


Printing Panoramas

Depending on the page size and the size of the panorama, panoramas may print with their edges cropped out or with wide margins at the top and bottom or at both sides.

Framing Panoramas Manually

Follow the steps below if the desired results are not achieved with **MAUTO** selected for **PANORAMA MODE**:

- 1 Select 🕅 MANUAL for 📄 PANORAMA MODE in the shooting menu.
- **2** Select a frame and take the first shot.
- **3** Press **MENU/OK** to display a guide showing an edge of the picture you have just taken. Take the next shot, framing it to overlap with the previous picture.



- **4** Repeat Step 3 to take the third shot and then press **MENU/OK** to display the completed panorama.
- 5 Press MENU/OK to save the picture.

🛾 追 INDIVID. SHUTTER 3D

More on Photography

Take two shots from different angles to create a 3D image.

- 1 Select 品 INDIVID. SHUTTER 3D for shooting mode (圓 20).
- **2** To choose the order in which the pictures are taken, press the selector right to display the current order and then press the selector left or right to choose from the options below.
 - $\blacksquare \longrightarrow \blacksquare$: Take the left shot first.
 - 12 + 1: Take the right shot first.
- 3 Press the shutter button to take the first shot.

To exit without recording a picture, press DISP/BACK.

- **4** The first shot will be shown superimposed on the view through the lens. Using it as a guide, frame the second shot and press the shutter release button.
 - The 3D effect may not be visible with some subjects or under some shooting conditions. For best results, the distance the camera is moved between shots should be about 1/30th to 1/50th of the distance to the subject.
 - The camera will turn off automatically if no operations performed for the time selected for AUTO POWER OFF (= 70). The first shot will not be saved if the second shot is not taken before the camera turns off.





Viewing and Printing 3D Images

- The camera displays images in 2D. Press the selector down to toggle between the first and second shots.
- Devices equipped for 3D display, such as the FINEPIX REAL 3D V3 digital photo frame or FINEPIX REAL 3D W3 digital camera, will display the images in 3D. Note that the FINEPIX REAL 3D W3 only displays images of size M or smaller.
- 3D prints can be ordered from *http://www.fujifilm.com/3d/print/*
- The supplied software displays 3D anaglyph images. 3D photos can also be viewed using other applications that support the MP format.
- **3D TVs** that support the MP format can display images in 3D. See the manual for your TV for details.
- ① Images are not output in 3D when printed directly from the camera.
- $\oplus\,$ 3D images are displayed in 2D in slide shows and when output on a conventional TV.
- ${\scriptstyle \textcircled{O}}$ 3D images can not be edited or retouched.

Note: The MP (Multi-Picture) format is a CIPA standard for files containing multiple still images. Files in MP format are referred to as "MP files" and have the extension "*.MPO". The camera uses this format for 3D images.

Focus Lock

To compose photographs with off-center subjects:

- **1** Focus: Position the subject in the focus frame (r[+]:) and press the shutter button halfway to lock focus and exposure. Focus and exposure will remain locked while the shutter button is pressed halfway (AF/AE lock).
- **2 Recompose**: Keep the button pressed halfway.

3 Shoot: Press the button all the way down.



Focus Lock

Autofocus


Although the camera boasts a high-precision autofocus system, it may be unable to focus on the subjects listed below. If the camera is unable to focus, focus on another subject at the same distance and use focus lock to recompose the photograph.

 Very shiny subjects such as mirrors or car bodies. 	• Subjects that show little contrast with the background
Fast-moving subjects.	(for example, subjects in clothing that is the same color
• Subjects photographed through a window or other re-	as the background).
flective object.	• Subjects positioned in front of or behind a high-contrast
• Dark subjects and subjects that absorb rather than reflect	object that is also in the focus frame (for example, a
light, such as hair or fur.	subject photographed against a backdrop of highly con-
 Insubstantial subjects, such as smoke or flame. 	trasting elements).

Exposure Compensation

To adjust exposure compensation when photographing very bright, very dark, or high-contrast subjects, press the selector up (12). Press the selector up or down to choose an exposure compensa-

tion value and then press MENU/OK.




- A IZ icon and exposure indicator are displayed at settings other than ±0. Exposure compensation is not reset when the camera is turned off; to restore normal exposure control, choose a value of ± 0 .
- Turn the flash off when using exposure compensation.
- Exposure compensation is available only when P (PROGRAM AE) is selected for shooting mode.

🗱 Macro Mode (Close-ups)

For close-ups, press the selector left (♥) and select ♥. When macro mode is in effect, the camera focuses on subjects near the center of the frame. Use the zoom buttons to compose pictures (♥ 17).

To exit macro mode, press the selector left (C) and select \clubsuit .

Use of a tripod is recommended to prevent blur caused by camera shake.






4 Using the Flash (Intelligent Flash)

When the flash is used, the camera's *Intelligent Flash* system instantly analyzes the scene based on such factors as the brightness of the subject, its position in the frame, and its distance from the camera. Flash output and sensitivity are adjusted to ensure that the main subject is correctly exposed while preserving the effects of ambient background lighting, even in dimly-lit indoor scenes. Use the flash when lighting is poor, for example when shooting at night or indoors under low light.

Press the selector right (\$) and choose from the following flash modes:





Option	Description
AUTO/ 🙊 (AUTO FLASH)	The flash fires when required. Recommended in most situations.
\$∕@\$ (FORCED FLASH)	The flash fires whenever a picture is taken. Use for backlit subjects or for natural coloration when shooting in bright light.
③ (SUPPRESSED FLASH)	The flash does not fire even when the subject is poorly lit. Use of a tripod is recommended.
	Capture both the main subject and the background under low light (note that brightly lit scenes may be overexposed).

- If the flash will fire, i will be displayed when the shutter button is pressed halfway. At slow shutter speeds, i will appear in the display to warn that pictures may be blurred; use of a tripod is recommended.
- The flash may fire several times with each shot. Do not move the camera until shooting is complete.
- The flash may cause vignetting.


🗫 🏩 RED EYE REDUCTION / 👁 🛊 FORCED FLASH / 🏩 RED EYE & SLOW


• icon indicates that Intelligent Face Detection is on and will be used to minimize "*red-eye*" caused by the flash reflecting from the retinas of portrait subjects.



👏 Using the Self-Timer

To use the self-timer, press the selector down (\circlearrowright) and choose from the following options:





Option	Description
SFF (OFF)	Self-timer off.
්ධ (10 SEC)	The shutter is released ten seconds after the shutter button is pressed. Use for self-portraits. The self-timer lamp on the front of the camera blinks while the timer counts down.
	The shutter is released two seconds after the shutter button is pressed. Use to reduce blur caused by the camera moving when the shutter-release button is pressed. The self-timer lamp will blink as the timer counts down.

More on Playback

Playback Options

To view the most recent picture in the LCD monitor, press the \blacktriangleright button.



Press the selector right to view pictures in the order recorded, left to view pictures in reverse order. Keep the selector pressed to scroll rapidly to the desired frame.

Pictures taken using other cameras are indicated by a # ("gift image") icon during playback.

★ Favorites: Rating Pictures

To rate the picture currently displayed in full-frame playback, press **DISP/BACK** and press the selector up and down to select from zero to five stars.

Playback Zoom

Press **T** to zoom in on pictures displayed in single-frame playback; press **W** to zoom out. When the picture is zoomed in, the selector can be used to view areas of the image not currently visible in the display.



Zoom indicator


Navigation window shows portion of image currently displayed in LCD monitor

Press **DISP/BACK** to exit zoom.

The maximum zoom ratio varies with image size. Playback zoom is not available with cropped or resized copies saved at a size of M or smaller.

Multi-Frame Playback


Pressing **W** when a picture is shown full-frame in the LCD monitor displays the current image with previous and following images in the background. Press **W** to increase the number of images displayed to two, nine, or one hundred, **T** to view fewer images.



When two or more images are displayed, use the selector to highlight images and press **MENU/OK** to view the highlighted image full frame. In the nine- and hundred-frame displays, use the selector to view more pictures.

🛅 Deleting Pictures

To delete individual pictures, multiple selected pictures, or all pictures, press the selector up ($\overline{\mathbf{m}}$), and choose from the options below. *Note that deleted pictures can not be recovered. Copy impor-*



tant pictures to a computer or other storage device before proceeding.

Option	Description	
FRAME	Press the selector left or right to scroll through pictures and press MENU/OK to delete the current picture (a confirmation dialog is not displayed).	
SELECTED FRAMES	Highlight pictures and press MENU/OK to select or deselect (pictures that are protected or in a print order are shown by ■). When the operation is complete, press DISP/BACK to display a confirmation dialog, then highlight OK and press MENU/OK to delete the selected pictures.	
ALL FRAMES	A confirmation dialog will be displayed; highlight OK and press MENU/OK to delete all unprotected pictures. Pressing DISP/BACK cancels deletion; note that any pictures deleted before the button was pressed can not be recovered.	

- Protected pictures can not be deleted. Remove protection from any pictures you wish to delete (E) 65).
- Pictures can also be deleted by m ERASE from playback menu.
- If a message appears stating that the selected images are part of a DPOF print order, press MENU/OK to delete the pictures.

Viewing Panoramas

If you press the selector down when a panorama is displayed full frame, the camera will play back the picture from left to right. To pause playback, press the selector down; press the selector down again to resume. To delete the panorama, press the selector up (\mathbf{t}) when playback is paused. To exit to full-frame playback, press the selector up while panorama playback is in progress.





Movies

Recording Movies

Press

to shoot a movie. During recording, **REC** and the time remaining will be displayed in the LCD monitor and sound will be recorded via the built-in microphone (be careful not to cover the microphone during recording).

To end recording, press the


button again. Recording ends automatically when the movie reaches maximum length or memory is full.

Automatic Scene Selection

In R mode, the camera selects the scene according to shooting conditions and the type of subject: (portraits), (poorly-lit landscapes), 🔮 (poorly-lit portraits), 🛆 (landscapes), ♥ (close-ups), ♥ (backlit portraits), or ● (other subjects).

Scene icon







Zoom adjustment

Zoom can be adjusted while recording is in progress. Select the type of zoom available for MOVIE ZOOM TYPE in the setup menu. Selecting OPTICAL blocks sound being recorded when zooming.

- Focus, exposure, and white balance are adjusted automatically throughout recording. The color and brightness of the image may vary from that displayed before recording begins.
- Sounds made by the camera may be recorded.
- ${\rm \oplus}\,$ Do not open the battery-chamber cover during shooting or saving a movie on a memory card. Failure to observe this precaution could prevent the movie from being played back.

Viewing Movies

During playback, movies are displayed in the LCD monitor as shown at right. The following operations can be performed while a movie is displayed:

Option	Description
Start/pause	Press the selector down to start playback. Press again to
playback	pause.
End playback/	Press the selector up to end playback. If playback is not in
delete	progress, pressing the selector up will delete the movie.
Advance/	Press the selector right to advance, left to rewind. If playback
rewind	is paused, the movie will advance or rewind one frame each time the selector is pressed.
Adjust volume Adjust volume Ad	

 ${\scriptstyle \textcircled{O}}$ Do not cover the speaker during playback.




Connections

Viewing Pictures on TV

Connect the camera to a TV to show pictures to a group.

1 Turn the camera off and connect an optional A/V cable as shown below.




- $\ensuremath{\mathbbm O}$ When connecting cables, be sure the connectors are fully inserted.
- Image quality may drop during movie playback.
- **2** Tune the television to the video input channel. See the documentation supplied with the television for details.
- 3 Press the button for about a second to turn the camera on. The camera monitor turns off and pictures and movies are played back on the TV. Note that the camera volume controls have no effect on sounds played on the TV; use the television volume controls to adjust the volume.

Printing Pictures via USB

If the printer supports PictBridge, the camera can be connected directly to the printer as shown below and pictures can be printed without first being copied to a computer. Note that depending on **PictBridge** the printer, not all the functions described below may be supported.

1 Connect the supplied USB cable as shown and turn the printer on.



- 2 Turn the camera on.
- **3** Press the selector left or right to display a picture you wish to print.
- 4 Press the selector up or down to choose the number of copies (up to 99).
- **5** Repeat steps 3–4 to select additional pictures. Press **MENU/OK** to display a confirmation dialog when settings are complete.

- 6 Press MENU/OK to start printing. Printing can be interrupted by pressing **DISP/BACK**, but note that some printers may not respond immediately. If the printer stops before printing is complete, turn the camera off and then on again.
- **7** After confirming that **PRINTING** has cleared from the camera display, turn the camera off and disconnect the USB cable.
- Pictures can be printed from a memory card that has been formatted in the camera.
- If no pictures are selected, the camera will print one copy of the current picture.
- Page size, print quality, and border selections are made using the printer.

Printing the Date of Recording

To print the date of recording on pictures, press **DISP/BACK** in the PictBridge display and select **PRINT WITH DATE** in the PictBridge menu (to print pictures without the date of recording, select **PRINT WITHOUT DATE**).

Printing the DPOF Print Order

The **PRINT ORDER (DPOF)** option in the playback menu can be used to create a digital "print order" for PictBridge-compatible printers (III 76) or devices that support DPOF.

DPOF

DPOF (Digital Print Order Format) is a standard that allows pictures to be printed from "print orders" stored on a memory card. The information in the order includes the pictures to be printed and the number of copies of **DPOF** each picture.

- 1 Select playback mode and press **MENU/OK** to display the playback menu.
- 2 Press the selector left or right to select 🗃 MENU and press MENU/OK.

- 3 Highlight PRINT ORDER (DPOF) and press MENU/OK.
- 4 Highlight one of the following options and press MENU/OK:
 - WITH DATE C: Print the date of recording on pictures.
 - WITHOUT DATE: Do not print the date of recording on pictures.
 - Some printers do not support date printing. See the printer manual for details.

SET MENL s PLAYBACK MENU OK SET BACK EXIT

- **5** Press the selector left or right to display a picture you wish to add to or remove from the print order.
- **6** Press the selector up or down to choose the number of copies (up to 99). To remove a picture from the print order, press the selector down until the number of copies is zero.
- **7** Repeat Steps 5–6 to complete the print order and press **MENU/OK** when settings are complete.
- **8** A confirmation dialog will be displayed. Press **MENU/OK** to save the print order.
 - Print orders can contain a maximum of 999 pictures.
 - If a memory card is inserted containing a print order created by another camera, a message will be displayed. Create a new print order as described above.

Viewing Pictures on a Computer

The supplied software can be used to copy pictures to a computer, where they can be stored, viewed, organized, and printed. Before proceeding, install the software as described below. **Do NOT** connect the camera to the computer until installation is complete.

Windows: Installing MyFinePix Studio

1 Confirm that the computer meets the following system requirements:

	Windows 8/Windows 7 (SP 1)/ Windows Vista (SP 2)1	Windows XP (SP 3) ¹
CPU	3 GHz Pentium 4 or better (2.4 GHz Core 2 Duo or better) ²	2 GHz Pentium 4 or better (2.4 GHz Core 2 Duo or better) ²
RAM	1 GB or more	512 MB or more (1 GB or more) ²
Free disk space	2 GB or more	
GPU	Supports DirectX 9 or later (recommended)	Supports DirectX 7 or later (required; performance not guaranteed with other GPUs)
Video	• 1024 × 768 pixels or more with 24-b	bit color or better
Other	 Built-in USB port recommended. Operation is not guaranteed with other USB ports. Internet connection (broadband recommended) required to install .NET Framework (if necessary), to use auto update feature, and when performing such tasks as sharing pictures on-line or via e-mail. Installation of .Net Framework 3.5 SP1 required to use upload picture feature and MapViewer. 	

1 Other versions of Windows are not supported. Only pre-installed operating systems are supported; operation is not guaranteed on home-built computers or computers that have been upgraded from earlier versions of Windows.

2 Recommended when displaying HD movies.

- **2** Start the computer. Log in to an account with administrator privileges before proceeding.
- **3** Exit any applications that may be running and insert the installer CD in a CD-ROM drive.

Windows 8/Windows 7/Windows Vista

If an AutoPlay dialog is displayed, click **SETUP.EXE**. A "User Account Control" dialog will then be displayed; click **Yes** (Windows 8/Windows 7) or **Allow** (Windows Vista).

The installer will start automatically; click **Install MyFinePix Studio** and follow the on-screen instructions to install MyFinePix Studio.

If the Installer Does Not Start Automatically


If the installer does not start automatically, select **Computer** or **My Computer** from the Start menu, then double-click the **FINEPIX** CD icon to open the FINEPIX CD window and double-click **setup** or **SETUP.EXE**.

- **4** If prompted to install Windows Media Player or DirectX, follow the onscreen instructions to complete installation.
- **5** Remove the installer CD from the CD-ROM drive when installation is complete. Store the installer CD in a dry location out of direct sunlight in case you need to re-install the software.

Installation is now complete. Proceed to "Connecting the Camera" (🕮 51).

Connecting the Camera

- 1 If the pictures you wish to copy are stored on a memory card, insert the card into the camera.
 - Windows users may require the Windows CD when starting the software for the first time.
- **2** Turn the camera off and connect the supplied USB cable as shown, making sure the connectors are fully inserted. Connect the camera directly to the computer; do not use a USB hub or keyboard.



3 Press the ▶ button for about a second to turn the camera on. After starting MyFinePix Studio, follow the on-screen instructions to copy pictures to the computer. To exit without copying pictures, click **Cancel**. For more information on using the supplied software, start the application and select the appropriate option from the **Help** menu.

- ① If a memory card containing a large number of images is inserted, there may be a delay before the software starts and you may be unable to import or save images. Use a memory card reader to transfer pictures.
- \oplus Make sure that the computer does not display a message stating that copying is in progress before turning the camera off or disconnecting the USB cable. Failure to observe this precaution could result in loss of data or damage to the memory card.
- ${\scriptstyle \oplus}\,$ Disconnect the camera before inserting or removing memory cards.
- ① In some cases, it may not be possible to access pictures saved to a network server using the supplied software in the same way as on a standalone computer.

Uninstalling the Supplied Software

Only uninstall the supplied software when it is no longer required or before beginning reinstallation. After quitting the software and disconnecting the camera, open the control panel and use "Programs and Features" (Windows 8/Windows 7/ Windows Vista) or "Add or Remove Programs" (Windows XP) to uninstall MyFinePix Studio. Under Windows, one or more confirmation dialogs may be displayed; read the contents carefully before clicking **OK**.

Importing pictures or movies to Mac (Macintosh)

Use a standard application in Mac OS such as Image Capture to import pictures or movies to Mac.

Menus

Using the Menus: Shooting Mode

<u>Using the Shooting Menu</u>

To display the shooting menu, press **MENU/OK** in shooting mode. Press the selector left or right to select **Themson MENU/OK**. Highlight items and press the selector right to view options, then highlight an option and press **MENU/OK**. Press **DISP/BACK** to exit when settings are com-

plete. The options available vary with the shooting mode selected.

Shooting Menu Options

SHOOTING MODE	(defaults to 🏭)	
Choose a shooting mo	de according to the type of subject (💷 20).	
(defaults to AUTO) Control the camera's sensitivity to light. Higher values can reduce blur; note, however, that mot- tling may appear in pictures taken at high sensitivities.		
100 Bright Less noticeable	ISO → 3200 ✓ Scene → Dark ✓ Noise (mottling) → More noticeable	
Option	Description	
AUTO	Sensitivity is adjusted automatically in response to shooting conditions.	
3200/1600/800/400/ 200/100	Sensitivity is set to the specified value, which is shown in the display.	

CINENU MENU SHOOTING MENU CIN SET ELECTENT




IMAGE QUALITY

Choose how much image files are compressed.

Option	Description	
FINE	Low compression. Select for higher image quality.	
NORMAL	High compression. Select this option to store more pictures.	

FINEPIX COLOR

Enhance contrast and color saturation or take pictures in black and white.

Option	Description
STANDARD	Standard contrast and saturation. Recommended in most situations.
Ġ₽ CHROME	Vivid contrast and color. Choose for vivid shots of flowers or enhanced greens and blues in landscapes.
B&W	Take pictures in black and white.

Settings other than for STANDARD are shown by an icon in the LCD monitor.

Depending on the subject, the effects of Br CHROME may not be visible in the LCD monitor.

(defaults to N)

(defaults to stor)

WHITE BALANCE

(defaults to AUTO)

For natural colors, choose a setting that matches the light source.

Option	Description
AUTO	White balance adjusted automatically.
*	For subjects in direct sunlight.
*	For subjects in the shade.
₩i	Use under "daylight" fluorescent lights.
₩2	Use under "warm white" fluorescent lights.
岸	Use under "cool white" fluorescent lights.
-Å-	Use under incandescent lighting.

Results vary with shooting conditions. Play pictures back after shooting to check colors in the LCD monitor.

CONTINUOUS

(defaults to OFF)

Capture motion in a series of pictures.

Option	Description
ON	The camera takes up to 3 pictures while the shutter button is pressed.
OFF	One photograph is taken each time the shutter button is pressed.

- Focus and exposure are determined by the first frame in each series.
- The flash turns off automatically. The previously selected flash mode is restored when OFF is selected for OFTINUOUS.
- Frame rate varies with shutter speed.
- The number of pictures that can be recorded depends on the memory available.

FACE DETECTION

Intelligent Face Detection sets focus and exposure for human faces anywhere in the frame, preventing the camera from focusing on the background in group portraits. Choose for shots that emphasize portrait subjects.

Option: ON/OFF

Faces can be detected with the camera in vertical or horizontal orientation; if a face is detected, it will be indicated by a green border. If there is more than one face in the frame, the camera will select the face closest to the center; other faces are indicated by white borders.



- In some modes, the camera may set exposure for the frame as a whole rather than the portrait subject.
- If the subject moves as the shutter button is pressed, their face may not be in the area indicated by the green border when the picture is taken.

AF MODE

This option controls how the camera selects the focus area. Regardless of the option selected, the camera will focus on the subject in the center of the LCD monitor when macro mode is on.

Option	Description
CENTER	The camera focuses on the subject in the center of the frame.
	Position the subject in the center focus area and press the selector left. Focus will track the subject as it moves through the frame.

Note that in I mode, the camera focuses continuously, increasing the drain on the batteries, and that the sound of the camera focusing may be audible.

Menus

Using the Menus: Shooting Mode

PANORAMA MODE

Choose how panoramas are framed (🕮 24).

Option: M AUTO/M MANUAL

This option controls how the camera selects the focus area for movies.

Option	Description	
CENTER	The camera focuses on the subject in the center of the frame.	
CONTINUOUS	The camera continuously adjusts focus to reflect changes in the distance to subjects near the center of the frame.	

Note that in I mode, the camera focuses continuously, increasing the drain on the battery, and that the sound of the camera focusing may be audible.

MOVIE MODE

Choose a frame size for movies.

Option	Description
HD 1280 (1280×720)	High Definition.
640 (640×480)	Standard definition.
320 (320×240)	Longer movie.

59

(defaults to HD)

(defaults to 🗉)

(defaults to 📖)

Using the Playback Menu

To display the playback menu, press **MENU/OK** in playback mode. Press the selector left or right to select **MENU** and press **MENU/OK**. Highlight items and press the selector right to view options, then highlight an option and press **MENU/OK**. Press **DISP/BACK** to exit when settings are complete.



Playback Menu Options

PHOTOBOOK ASSIST

Create books from your favorite photos.

Creating a PhotoBook

- 1 Select NEW BOOK and press MENU/OK.
- **2** Choose from the following options:
 - SELECT FROM ALL: Choose from all available pictures.
 - SELECT BY IMAGE SEARCH: Choose from pictures matching selected search conditions (🕮 62).
 - Neither photographs 🚳 or smaller nor movies can be selected for photobooks.
- **3** Scroll through the images and press the selector up to select or deselect. To display the current image on the cover, press the selector down. Press **MENU/OK** to exit when the book is complete.
 - The first picture selected becomes the cover image. Press the selector down to select a different image for the cover.
- 4 Select COMPLETE PHOTOBOOK (to select all photos or all photos matching the specified search conditions for the book, choose SELECT ALL). The new book will be added to the list in the photobook assist menu.
- ① Books can contain up to 300 pictures.
- ① Books that contain no photos are automatically deleted.

Viewing Photobooks

Highlight a book in the photobook assist menu and press **MENU/OK** to display the book, then press the selector left or right to scroll through the pictures.

PHOTOBOOK ASSIST (Continued)

Editing and Deleting Photobooks

Display the photobook and press **MENU/OK**. The following options will be displayed; select the desired option and follow the on-screen instructions.

- EDIT: Edit the book as described in "Creating a PhotoBook" (🕮 61).
- ERASE: Delete the book.

Photobooks

Photobooks can be copied to a computer using the supplied MyFinePix Studio software.

MAGE SEARCH

Search for pictures.

1 Choose from the following options:

- BY DATE: Search by date.
- BY FACE: Search for faces from the face recognition database.
- BY ★ FAVORITES: Search by rating.
- BY SCENE: Search by scene.
- BY TYPE OF DATA: Find all still pictures or all movies.
- BY UPLOAD MARK: Find all pictures selected for upload to a specified destination.
- 2 Select a search condition. Only pictures that match the search condition will be displayed. To delete or protect selected pictures or to view the search results in a slide show, press **MENU/OK**

and choose 📷 ERASE (🕮 39), 💁 PROTECT (🕮 65), or 📾 SLIDE SHOW (🕮 65).

ERASE

Delete all or selected pictures (EE 39). Option: FRAME/SELECTED FRAMES/ALL FRAMES

🔀 MOVIE EDIT

Edit movies.

MOVIE TRIMMING

Remove opening or ending footage to create an edited copy of the current movie.

- 1 Display the desired movie.
- 2 Select I MOVIE EDIT in the playback menu, then select MOVIE TRIMMING. To remove footage from the start of the copy, proceed to Step 3; otherwise, proceed to Step 4.
- **3** Press the selector down to begin playback and press it down again when the new opening frame is reached.
- **4** Press **MENU/OK**. To remove footage from the end of the copy, proceed to Step 5; otherwise, proceed to Step 6 (to exit without creating an edited copy, press **DISP/BACK**).
- **5** Press the selector down to begin playback and press it down again when the new closing frame is reached.
- 6 Press MENU/OK to save the copy.

MOVIE JOIN

Add existing footage to the end of the current movie to create an edited copy.

1 Display the desired movie.

- 2 Select 🔛 MOVIE EDIT in the playback menu, then select MOVIE JOIN.
- 3 Press the selector left or right to highlight a movie.
- **4** Press **MENU/OK** to add the highlighted footage to the end of the current movie and save the resulting copy, or press **DISP/BACK** to exit without creating a copy.
- Both movies must have been recorded at the same frame size and frame rate and have a combined file size of no more than 2 GB.

MARK FOR UPLOAD TO

Select pictures for upload to YouTube, Facebook or MyFinePix.com using MyFinePix Studio (Windows only).

Selecting Pictures for Upload


- 1 Select YouTube to choose movies for upload to YouTube, FACEBOOK to choose photos and movies for upload to Facebook, or MyFinePix.com to choose photos for upload to My-FinePix.com.
- 2 Press the selector left or right to display pictures and press **MENU/OK** to select or deselect. Press **DISP/BACK** to exit when all the desired pictures are selected.
- Only movies can be selected for upload to YouTube.
- Only photos can be selected for upload to MyFinePix.com.
- ♥ During playback, selected pictures are indicated by
 YouTube,
 FACEBOOK or
 My-FinePix.com icons.

RESET ALL: Deselecting All Pictures

Choose **RESET ALL** to deselect all pictures. If the number of pictures affected is very large, a message will be displayed while the operation is in progress. Press **DISP/BACK** to exit before the operation is complete.

Uploading Pictures (Windows Only)

Selected pictures can be uploaded using the YouTube/Facebook/MyFinePix.com Upload option in MyFinePix Studio.



Upload from computer

For information on installing MyFinePix Studio and connecting the camera to a computer, see "Viewing Pictures on a Computer" (💷 49).

SLIDE SHOW

(defaults to MULTIPLE)

View pictures in an automated slide show. Choose the type of show and press **MENU/OK** to start. Press **DISP/BACK** at any time during the show to view on-screen help. The show can be ended at any time by pressing **MENU/OK**.

Option	Description	
NORMAL	Press selector left or right to go back or skip ahead one frame. Select FADE-IN	
FADE-IN	for fade transitions between frames.	
NORMAL 😫	As above, except that camera automatically zooms in on faces selected with	
FADE-IN 😫	Intelligent Face detection.	
MULTIPLE	Display several pictures at once.	

The camera will not turn off automatically while a slide show is in progress.

PROTECT

Protect pictures from accidental deletion.

1 Select **PROTECT** in the playback menu.

2 Highlight one of the following options and press MENU/OK:

- FRAME: Protect selected pictures. Press the selector left or right to view pictures and press MENU/OK to select or deselect. Press DISP/BACK when the operation is complete.
- SET ALL: Protect all pictures.
- RESET ALL: Remove protection from all pictures.

 \oplus Protected pictures will be deleted when the memory card is formatted (\boxplus 70).

Using the Menus: Playback Mode

🔳 CROP

Create a cropped copy of the current picture.

- 1 Display the desired picture.
- 2 Select 🖾 CROP in the playback menu.
- **3** Use the zoom buttons to zoom in and out and use the selector to scroll the picture until the desired portion is displayed.
- 4 Press MENU/OK to display a confirmation dialog.
- 5 Press MENU/OK again to save the cropped copy to a separate file.
- Larger crops produce larger copies; all copies have an aspect ratio of 4:3. If the size of the final copy will be MO, OK will be displayed in yellow.

RESIZE

Create a small copy of the current picture.

- 1 Display the desired picture.
- 2 Select 🔚 RESIZE in the playback menu.
- 3 Highlight a size and press MENU/OK to display a confirmation dialog.
- 4 Press MENU/OK to save the resized copy to a separate file.
- The sizes available vary with the size of the original image.

IMAGE ROTATE

Rotate pictures taken in tall orientation so that they are displayed in tall orientation in the LCD monitor.

- 1 Display the desired picture.
- 2 Select 🖸 IMAGE ROTATE in the playback menu.
- **3** Press the selector down to rotate the picture 90° clockwise, up to rotate it 90° counterclockwise.
- **4** Press **MENU/OK**. The picture automatically be displayed in the selected orientation whenever it is played back on the camera.
- Protected pictures can not be rotated. Remove protection before rotating pictures (🕮 65).
- The camera may not be able to rotate pictures created with other devices.

PRINT ORDER (DPOF)

Select pictures for printing on DPOF- and PictBridge-compatible devices (🕮 47).

Using the Setup Menu

- 1 Display the setup menu.
 - **1.1** Press **MENU/OK** to display the menu for the current mode.
 - **1.2** Press the selector left or right to select **E SET** and press **MENU/OK**.



2 Adjust settings.

Highlight items and press the selector right to view options, then highlight an option and press **MENU/OK**. Press **DISP/BACK** to exit when settings are complete.

Setup Menu Options

O DATE/TIME

Set the camera clock (🕮 15).

TIME DIFFERENCE

Switch the camera clock instantly from your home time zone to the local time at your destination when traveling. To specify the difference between local time and your home time zone:

1 Highlight **+** LOCAL and press the selector right.

2 Use the selector to choose the time difference between local time and your home time zone.

3 Press MENU/OK.

To switch between local time and your home time zone, highlight **+ LOCAL** or **A HOME** and press **MENU/OK**.

Option	Description	
合 HOME	Switch to the time currently selected for 🕑 DATE/TIME (see above).	
	Switch to local time. If this option is selected, 🕂 and the time and date will be displayed in yellow for three seconds each time the camera is turned on.	

💿 言語/LANG.

Choose a language (🕮 93).

SILENT MODE

Select **ON** to disable the speaker and flash in situations in which camera sounds or lights may be unwelcome (note that the flash will still fire in **•f** mode).

(defaults to 🏠)

(defaults to ENGLISH)

(defaults to OFF)

C. RESET

Reset all settings except (DATE/TIME, (TIME DIFFERENCE,) BACKGROUND COLOR, and (VIDEO SYSTEM to default values.

- 1 Highlight G RESET and press the selector right to display a confirmation dialog.
- 2 Highlight OK and press MENU/OK.

FORMAT

This option will format the memory card.

- ① All data—including protected pictures—will be deleted from the memory card. Be sure important files have been copied to a computer or other storage device.
- ① Do not open the battery-chamber cover during formatting.

IMAGE DISP.

(defaults to 1.5 SEC)

Choose how long pictures are displayed in the LCD monitor after shooting.

Option	Description	
3 SEC	Pictures are displayed for three seconds (3 SEC) or 1.5 seconds (1.5 SEC).	
1.5 SEC	Colors may differ slightly from those in the final image.	
ZOOM (CONTINUOUS)	Pictures are displayed until the MENU/OK button is pressed.	
OFF	Pictures are not displayed after shooting.	

• OFF has no effect in continuous shooting mode.

The Setup Menu

71

New pictures are stored in image files named using a four-digit file number assigned by adding one to the last file number used. The file number is displayed during playback as shown at right. **IP FRAME NO.** controls whether file numbering is reset to 0001 when a new memory card is inserted or the current memory card is formatted.

Option	Description	
CONTINUOUS	Numbering continues from the last file number used or the first available file number, whichever is higher. Choose this option to reduce the number of pictures with duplicate file names.	
RENEW	Numbering is reset to 0001 after formatting or when a new memory card is inserted.	

- ♦ If the frame number reaches 999-9999, the shutter release will be disabled (Ⅲ 87).
- Selecting RESET (1 70) sets FRAME NO. to CONTINUOUS but does not reset the file number.
- Frame numbers for pictures taken with other cameras may differ.

OPERATION VOL.

FRAME NO.

Adjust the volume of the sounds produced when camera controls are operated. Choose **4 OFF** (mute) to disable control sounds.

SHUTTER VOLUME

Adjust the volume of the sounds produced when the shutter is released. Choose **4 OFF** (mute) to disable the shutter sound.

(defaults to 📢 💵)

(defaults to **u**(**u**))





The Setup Menu

SHUTTER SOUND

Choose the sound made by the shutter.

PLAYBACK VOLUME

Adjust the volume for movie playback.

LCD BRIGHTNESS

Control the brightness of the display.

When a shooting mode option other than P (PROGRAM AE) is selected, display brightness is automatically adjusted during shooting regardless of a option selected for M LCD BRIGHT-NESS in response to ambient lighting conditions.

LCD MODE

Choose whether the display automatically dims to save power.

AUTO POWER OFF

Choose the length of time before the camera turns off automatically when no operations are performed. Shorter times increase battery life; if **OFF** is selected, the camera must be turned off manually. Note that in some situations the camera turns off automatically even when **OFF** is selected.

ANTI-BLUR

When **AUTO** is selected, image stabilization is performed to reduce blur when the subject is poorly lit.

(defaults to 7)

(defaults to 1 1)

(defaults to 0)

(defaults to 2 MIN)

(defaults to MON)


(defaults to OFF)

BLINK DETECTION

(defaults to ON)

Choose **ON** to activate blink detection. If an option other than **OFF** is selected for **IMAGE DISP.** (\blacksquare 70), a warning will be displayed if the camera detects subjects who may have blinked when the picture was taken. If **ZOOM (CONTINUOUS)** is selected, you can press the **V** button to zoom in on these subjects.

Option: ON/OFF




Blink detection is not performed if the camera fails to detect a face or when OFF is selected for IMAGE DISP.

Q DIGITAL ZOOM

(defaults to OFF)

If **ON** is selected, pressing **T** button at the maximum optical zoom position will trigger digital zoom, further magnifying the image.



- Digital zoom produces lower quality images than optical zoom.
- Digital zoom can not be used when shooting in An mode.

MOVIE ZOOM TYPE

(defaults to Di)

Choose the zoom type when recording movies.

- Digital zoom produces lower quality images than optical zoom.
- Optical zoom blocks sound being recorded when zooming.

BACKGROUND COLOR

Choose a color scheme.

GUIDANCE DISPLAY

Choose whether to display tool tips.

WIDEO SYSTEM

Choose a video mode for connection to a TV.

Option	Description	
NTSC	Select this mode for connection to video devices in North America, the Caribbean, parts of Latin America, and some East Asian countries.	
PAL	Select this mode for connection to video devices in the United Kingdom and much of Europe, Australia, New Zealand, and parts of Asia and Africa.	

DATE STAMP

(defaults to OFF)


To add shooting date and time, choose $\overline{\mathfrak{s}} + \mathfrak{O}$. To add only shooting date, choose $\overline{\mathfrak{s}}$. When **OFF** is selected, no information will be added to the pictures.

- ① Added shooting date and time can not be deleted from the pictures. To take pictures without date and time, select **OFF** for **DATE STAMP**.
- ① When the camera clock is not set, setting dialog will be displayed. Set the date and time (🕮 15).
- ① When using M DATE STAMP, selecting WITHOUT DATE for PRINT ORDER (DPOF) is recommended (= 47).
- ${\scriptstyle \oplus}\,$ Date and time can not be added to the movies and the panoramas.

Technical Notes

Optional Accessories

The camera supports a wide range of accessories from FUJIFILM and other manufacturers.



* Available separately.

Accessories from FUJIFILM

The following optional accessories are available from FUJIFILM. For the latest information on the accessories available in your region, check with your local FUJIFILM representative or visit *http://www.fujifilm.com/products/digital_ cameras/index.html*.

-	NP-45A : Additional large-capacity NP-45A rechargeable batteries can be purchased as required.	
Battery chargers	BC-45W : Replacement battery chargers can be purchased as required. The BC-45W charges an NP-45A/NP-45B battery in about 120 minutes at +20 °C (+68 °F).	
A/V cable	AV-C1 : Use for viewing pictures on TV.	
HD players	HDP-L1 (requires HDMI cable, available from third-party suppliers): Con- nect to a High Definition (HD) TV to view photographs and movies from SD/SDHC memory cards.	

Caring for the Camera

To ensure continued enjoyment of the product, observe the following precautions.

Storage and Use

If the camera will not be used for an extended period, remove the battery and memory card. Do not store or use the camera in locations that are:

- exposed to rain, steam, or smoke
- very humid or extremely dusty
- exposed to direct sunlight or very high temperatures, such as in a closed vehicle on a sunny day
- extremely cold
- subject to strong vibration
- exposed to strong magnetic fields, such as near a broadcasting antenna, power line, radar emitter, motor, transformer, or magnet
- in contact with volatile chemicals such as pesticides
- next to rubber or vinyl products

Water and Sand

Exposure to water and sand can also damage the camera and its internal circuitry and mechanisms. When using the camera at the beach or seaside, avoid exposing the camera to water or sand. Do not place the camera on a wet surface.

Condensation

Sudden increases in temperature, such as occur when entering a heated building on a cold day, can cause condensation inside the camera. If this occurs, turn the camera off and wait an hour before turning it on again. If condensation forms on the memory card, remove the card and wait for the condensation to dissipate.

<u>Cleaning</u>

Use a blower to remove dust from the lens and LCD monitor, then gently wipe with a soft, dry cloth. Any remaining stains can be removed by wiping gently with a piece of FUJIFILM lens-cleaning paper to which a small amount of lenscleaning fluid has been applied. Care should be taken to avoid scratching the lens or LCD monitor. The camera body can be cleaned with a soft, dry cloth. Do not use alcohol, thinner, or other volatile chemicals.

<u>Traveling</u>

Keep the camera in your carry-on baggage. Checked baggage may suffer violent shocks that could damage the camera.

Troubleshooting

Problems and Solutions

Power and Battery

Problem	Solution	
The camera does not turn on.	 The battery is exhausted: Charge the battery (== 11) or insert a fully-charged spare battery (== 6). The battery is inserted incorrectly: Reinsert in the correct orientation (== 6). 	
	• The battery-chamber cover is not latched: Latch the battery-chamber cover (🗐 6).	
	• The battery is cold: Warm the battery by placing it in a pocket or other warm place and reinsert it in the camera immediately before taking a picture.	
	• There is dirt on the battery terminals: Clean the terminals with a soft, dry cloth.	
The battery runs down quickly.	• Selected for shooting mode: Select in mode to reduce the drain on the battery	
	(💷 20).	
	• 🖽 TRACKING is selected for 🗊 AF MODE: Select a different AF mode (🕮 58).	
	• The battery has been charged many times: The battery has reached the end of its charging	
	life. Purchase a new battery.	
The camera turns off suddenly.	Charge the battery (💷 11) or insert a fully-charged spare battery (🕮 6).	
Charging is slow.	Charge the battery at room temperature (💷 vi).	
	• Reinsert the battery in the correct orientation and make sure that the power connection is made	
The battery does not	(💷 6, 11).	
	• There is dirt on the battery terminals: Clean the terminals with a soft, dry cloth.	
charge. / Battery fault	• The battery has been charged many times: The battery has reached the end of its charging	
icon � ⊏! ⊐ is displayed.	life. Purchase a new battery. If the battery still fails to charge, contact your FUJIFILM dealer.	
	• The battery is too hot or too cold: Wait for the battery temperature to stabilize (💷 95).	

Menus and Displays

Problem	Solution
Menus and displays are not in English.	Select ENGLISH for 🔯 言語/LANG. (🗐 15, 69).

Shooting

Problem	Solution	
	Memory is full: Insert a new memory card or delete pictures (💷 7, 39).	
	 Memory is not formatted: Format the memory card (III) 70). 	
	• There is dirt on the memory card contacts: Clean the contacts with a soft, dry cloth.	
No picture is taken when	• The memory card is damaged: Insert a new memory card (💷 7).	
the shutter button is	• The battery is exhausted: Charge the battery (🕮 11) or insert a fully-charged spare battery	
pressed.	(🖽 6).	
	 The camera has turned off automatically: Turn the camera on (
	The shutter button is pressed right after shooting a panorama: Wait for a little while	
	then press the shutter button (🕮 24).	
The LCD monitor goes dark after shooting.	The LCD monitor may darken while the flash charges. Wait for the flash to charge (🗐 33).	
The camera does not	• The subject is close to the camera: Select macro mode (💷 32).	
	• The subject is far away from the camera. Cancel macro mode (💷 32).	
focus.	 The subject is not suited to autofocus: Use focus lock (
Macro mode is not available	Choose a different shooting mode (🕮 20).	
Intelligent Face Detection	Intelligent Face Detection is not available in the current shooting mode: Choose a differ-	
is not available.	ent shooting mode (💷 20).	

Problem	Solution				
No face is detected.	 The subject's face is obscured by sunglasses, a hat, long hair, or other objects: Remove the obstructions. The subject's face occupies only a small area of the frame: Change the composition so that the subject's face occupies a larger area of the frame (== 29). The subject's head is tilted or horizontal: Ask the subject to hold their head straight. The camera is tilted: Keep the camera level (== 17). The subject's face is poorly lit: Shoot in bright light. 				
Wrong subject is	The selected subject is closer to the center of the frame than the main subject. Recompose the				
selected.	picture or turn face detection off and frame the picture using focus lock (💷 29).				
The flash does not fire.	 The flash is not available in the current shooting mode: Choose a different shooting mode (□ 20). The battery is exhausted: Charge the battery (□ 11) or insert a fully-charged spare battery (□ 6). The camera is in continuous mode: Select OFF for CONTINUOUS (□ 57). The camera is ni silent mode: Turn silent mode off (□ 69). The flash is off (③): Choose a different flash mode (□ 33). 				
Some flash modes are	• The desired flash mode is not available in the current shooting mode: Choose a different shooting mode (20).				
not available.	• The camera is in silent mode: Turn silent mode off (💷 69).				
The flash does not fully light the subject.	 The subject is not in range of the flash: Position the subject in range of the flash (= 93). The flash window is obstructed: Hold the camera correctly (= 17). 				
Pictures are blurred.	 The lens is dirty: Clean the lens (= 79). The lens is blocked: Keep objects away from the lens (= 17). !AF is displayed during shooting and the focus frame is displayed in red: Check focus before shooting (= 85). !G[*] is displayed during shooting: Use the flash or a tripod (= 34). 				

Problem	Solution		
Pictures are mottled.	This is normal when slow shutter speeds are selected at high temperatures and does not indicate a malfunction.		
Vertical lines appear in pictures.	The camera has been used continuously at high temperatures. Turn the camera off and wait for it to cool down.		
"Smear" in the form of vertical purple or white lines appears in the display.	Vertical purple or white lines may appear after the camera has been used continuously at high temperatures or when a very bright object is in the frame; this phenomenon is common to all CCD image sensors and does not indicate a malfunction. These lines are recorded in movies but do not appear in photographs. Avoid framing bright objects when filming movies.		

Playback

Problem	Solution			
Pictures are grainy.	ne pictures were taken with a different make or model of camera.			
Playback zoom is unavail- able.	The pictures were created using 🎦 RESIZE or with a different make or model of camera.			
	• Playback volume is too low: Adjust playback volume (💷 72).			
No sound in movie	• The microphone was obstructed: Hold the camera correctly during recording (💷 17, 41).			
playback.	• The speaker is obstructed: Hold the camera correctly during playback (💷 43).			
piayback.	• When OPTICAL is selected for Kan MOVIE ZOOM TYPE, zooming blocks			
	sound being recorded: Select D DIGITAL for 👪 MOVIE ZOOM TYPE (🗐 42).			
Selected pictures are not	Some of the pictures selected for deletion are protected. Remove protection using the device with			
deleted.	which it was originally applied (🕮 65).			
File numbering is	The battery-chamber cover was opened while the camera was on. Turn the camera off before			
unexpectedly reset.	opening the battery-chamber cover (🗐 13).			

Problem	Solution			
No picture or sound.	 The camera is not properly connected: Connect the camera properly (== 44). An A/V cable was connected during movie playback: Connect the camera once movie playback has ended. Input on the television is set to "TV": Set input to "VIDEO". The camera is not set to the correct video standard: Match the camera III VIDEO SYS-TEM setting to the TV (== 75). The volume on the TV is too low: Adjust the volume. 			
No color	Match the camera 🚟 VIDEO SYSTEM setting to the TV (💷 75).			
The computer does not recognize the camera.	Be sure the camera and computer are correctly connected (💷 51).			
Pictures can not be printed.	 The camera is not properly connected: Connect the camera correctly (= 45). The printer is off: Turn the printer on. 			
Only one copy is printed/ the date is not printed.	The printer is not PictBridge compatible.			
The camera is unre- sponsive.	Temporary camera malfunction: Remove and reinsert the battery (== 6). The battery is exhausted: Charge the battery (== 11) or insert a fully-charged spare battery (== 6).			
The camera does not function as expected.	Remove and reinsert the battery (💷 6). If the problem persists, contact your FUJIFILM dealer.			
No sound.	Turn silent mode off (💷 69).			
Date and time added by DATE DATE STAMP	/ The camera clock is not correctly set: Reset the date and time (== 15).			
are not correct.				
Date and time are added to the pictures. Image: The pictures of				

Warning Messages and Displays

The following warnings are displayed in the LCD monitor:

Warning	Description		
□ (red)	Low battery. Charge the battery (🕮 11) or insert a fully-charged spare battery (🕮 6).		
d (blinks red)	Battery exhausted. Charge the battery (💷 11) or insert a fully-charged spare battery (💷 6).		
ļo	Slow shutter speed. Pictures may be blurred; use the flash or a tripod.		
?AF (displayed in red with red focus frame)	 The camera can not focus. Try one of the following solutions: Use focus lock to focus on another subject at the same distance, then recompose the picture (= 29). Use macro mode to focus when taking close-ups (= 32). 		
Aperture or shutter speed displayed in red	The subject is too bright or too dark and the picture will be over- or under-exposed. If the subject is dark, use the flash (📖 33).		
FOCUS ERROR TURN OFF THE CAMERA AND TURN ON AGAIN	Camera malfunction or moving parts of lens obstructed. Turn the camera off and then on again, taking care not to touch the lens. If the message persists, contact a FUJIFILM dealer.		
CARD NOT INITIALIZED	 The memory card is not formatted or was formatted in a computer or other device: Format the memory card using the PORMAT option in the camera setup menu (== 70). The memory card contacts require cleaning: Clean the contacts with a soft, dry cloth. If the message is repeated, format the card (== 70). If the message persists, replace the card. Camera malfunction: Contact a FUJIFILM dealer. 		
PROTECTED CARD	The memory card is locked. Unlock the card (🕮 7).		
BUSY	The memory card is incorrectly formatted. Use the camera to format the card (🗐 70).		

Warning	Description				
	The memory card is not formatted for use in the camera. Format the card (🗐 70).				
	The memory card contacts require cleaning or the memory card is damaged. Clean the contacts				
CARD FRROR	with a soft, dry cloth. If the message is repeated, format the card (💷 70). If the message persists,				
CANDENNON	replace the card.				
	Incompatible memory card. Use a compatible card (💷 9).				
	Camera malfunction. Contact a FUJIFILM dealer.				
MEMORY FULL	The memory card is full and pictures can not be recorded or copied. Delete pictures or insert a				
	memory card with more free space.				
	• Memory card error or connection error: Reinsert the card or turn the camera off and then				
	on again. If the message persists, contact a FUJIFILM dealer.				
WRITE ERROR	Not enough memory remaining to record additional pictures: Delete pictures or insert				
	a memory card with more free space.				
	The memory card is not formatted: Format the memory card (70).				
	The file is corrupt or was not created with the camera: The file can not be viewed.				
RFAD FRROR	• The memory card contacts require cleaning: Clean the contacts with a soft, dry cloth. If				
	the message is repeated, format the card (🕮 70). If the message persists, replace the card.				
	Camera malfunction: Contact a FUJIFILM dealer.				

Warning	Description				
FRAME NO. FULL	The camera has run out of frame numbers (current frame number is 999-9999). Format the memory card and select RENEW for FRAME NO. Take a picture to reset frame numbering to 100-0001, then select CONTINUOUS for FRAME NO. (\equiv 71).				
PRESS AND HOLD THE DISP BUTTON TO DEACTIVATE SILENT MODE	An attempt was made to choose a flash mode or adjust the volume with the camera in silent mode. Exit silent mode before choosing a flash mode or adjusting the volume (🗐 69).				
TOO MANY FRAMES	A search has returned more 5,000 results, or more than 999 frames were selected for deletion. Perform a different search or select fewer pictures.				
PROTECTED FRAME	An attempt was made to delete or rotate to a protected picture. Remove protection and try again (\blacksquare 65).				
640 CAN NOT CROP	640 pictures can not be cropped.				
CAN NOT CROP	The picture is damaged or was not created with the camera.				
640 CANNOT EXECUTE	An attempt was made to create a resized copy at a size equal to or larger than the original. Choose a smaller size.				
CAN NOT ROTATE	An attempt was made to rotate a picture that can not be rotated.				
😫 CAN NOT ROTATE	Movies can not be rotated.				

Warning	Description			
NO CARD				
INSERT A NEW CARD	No memory card inserted; insert a memory card.			
NO CARD				
DPOF FILE ERROR	The DPOF print order on the current memory card contains more than 999 images.			
CAN NOT SET DPOF	The picture can not be printed using DPOF.			
😫 CAN NOT SET DPOF	Movies can not be printed using DPOF.			
COMMUNICATION ERROR	A connection error occurred while pictures were being printed or copied to a computer or other			
	device. Confirm that the device is turned on and that the USB cable is connected.			
PRINTER ERROR	Printer out of paper or ink, or other printer error. Check printer (see printer manual for details).			
	To resume printing, turn the printer off and then turn it back on.			
PRINTER ERROR	Printer out of paper or ink, or other printer error. Check printer (see printer manual for details). If			
RESUME?	printing does not resume automatically, press MENU/OK to resume.			
	An attempt was made to print a movie, a picture not created with the camera, or a picture in a			
	format not supported by the printer. Movies and some pictures created with other devices can			
CANNOT BE PRINTED	not be printed; if the picture is a still picture created with the camera, check the printer manual			
	to confirm that the printer supports the JFIF-JPEG or Exif-JPEG format. If it does not, the pictures			
	can not be printed.			

Appendix

Memory Card Capacity

The following table shows the recording time or number of pictures available at different image sizes. All figures are approximate; file size varies with the scene recorded, producing wide variations in the number of files that can be stored. The number of exposures or length remaining may not diminish at an even rate.

Medium		2 GB		4 GB		8 GB	
		FINE	NORMAL	FINE	NORMAL	FINE	NORMAL
	4:3	240	470	480	950	970	1910
_	3:2	270	530	540	1060	1080	2130
Phot	16:9	310	620	640	1250	1280	2510
Photographs	M 4:3	470	920	940	1840	1890	3680
aph	16:9	700	1340	1400	2690	2810	5380
Ű.	S 4:3	920	1740	1840	3490	3690	6980
	S 16:9	1680	3040	3360	6080	6720	12160
z	ID 1280 [†]	9 min.		18 min.		37 min.	
Movies*	640	27 min.		55 min.		111 min.	
°,	320 58 min.		116 min.		233 min.		

FinePix JX650 - JX695

* Individual movies can not exceed 2 GB in size or 29 minutes in length. If more than 2 GB are available, the camera will show the time remaining for a movie 2 GB in size.

† Use a **CLASS** card or better when shooting HD movies.

Medium		2 GB		4 GB		8 GB	
		FINE	NORMAL	FINE	NORMAL	FINE	NORMAL
	4:3	270	540	550	1090	1110	2180
_	3:2	310	610	620	1220	1240	2440
Phot	16:9	360	710	730	1430	1470	2870
Photographs	M 4:3	530	1030	1060	2060	2130	4120
aph	16:9	700	1340	1400	2690	2810	5380
~	S 4:3	1150	2140	2300	4290	4600	8580
	S 16:9	1680	3040	3360	6080	6720	12160
Movies*	1280 †	9 min.		18 min.		37 min.	
	640	27 min.		55 min.		111 min.	
v,	320	58 min.		116 min.		233 min.	

* Individual movies can not exceed 2 GB in size or 29 minutes in length. If more than 2 GB are available, the camera will show the time remaining for a movie 2 GB in size.

†Use a **CLASS** card or better when shooting HD movies.

Specifications

Custom					
System					
Model	Digital Camera FinePix JX600 Series FinePix JX650 - JX695				
Effective pixels					
	16 million				
	FinePix JX600 - JX645				
	14 million				
CCD	¹ /2.3 - in., square-pixel CCD with primary color filter				
Storage media	SD/SDHC/SDXC memory cards				
File system	e system Compliant with Design Rule for Camera File System (DCF), Exif 2.3, and Digital F				
	Format (DPOF)				
File format	Still pictures: Exif 2.3 JPEG (compressed) Still pictures (3D): MPO				
	Movies: AVI-format Motion JPEG				
Image size (pixels)	FinePix JX650 - JX695				
	• 4:3 : 4,608 × 3,440 • 3:2 : 4,608 × 3,072	• 🔳 16:9: 4,608×2,592			
	• M 4:3: 3,264×2,448	• M 16:9: 3,072×1,728			
	• S 4:3 :2,304×1,728	• S 16:9 : 1,920 × 1,080			
	FinePix JX600 - JX645				
	• 4:3 : 4,288 × 3,216 • 3:2 : 4,288 × 2,864	• 🔳 16:9: 4,288×2,416			
	• M 4:3: 3,072×2,304	• M 16:9: 3,072×1,728			
	• S 4:3:2,048×1,536	• S 16:9 : 1,920 × 1,080			
Lens	Fujinon 5 × optical zoom lens, F3.5 (wide angle) – F6.3 (teleph	noto)			
Focal length	f=4.6 mm-23.0 mm (35-mm format equivalent: 26 mm-130 mm)				
Digital zoom	FinePix JX650 - JX695				
-	Approx. 7.2 \times (up to 36.0 \times when combined with optical zoom)				
	FinePix JX600 - JX645				
	Approx. 6.7 \times (up to 33.5 \times when combined with optical zoom)				

Specifications

System				
Aperture	F3.5/F8.0 (wide angle), F6.3/F15.0 (telephoto); uses Neutral Density (ND) filter			
Focus range	Approx. 50 cm (1.6 ft.)-infinity (wide angle); 90 cm (2.9 ft.)-infinity (telephoto)			
(distance from front of lens)	• Macro: approx. 10 cm-80 cm/0.3 ft2.6 ft. (wide angle); 80 cm-1.3 m/2.6 ft4.2 ft. (telephoto)			
Sensitivity	Standard output sensitivity equivalent to ISO 100, 200, 400, 800, 1600, 3200 (image size S); AUTO			
Metering	256-segment through-the-lens (TTL) metering			
Exposure control	Programmed AE			
Exposure compensation	$-2 \text{ EV} - +2 \text{ EV}$ in increments of $\frac{1}{3} \text{ EV}$			
Shutter speed	• AUTO mode: 1/4 s-1/1,400 s			
(combined mechanical and	• Other modes: 8 s-1/1,400 s			
electronic shutter)				
Continuous	Up to 1.1 fps; max. 3 frames			
Focus	Mode: Single AF, continuous AF			
	Autofocus system: Contrast-detect TTL AF			
	Focus-area selection: CENTER, TRACKING			
White balance	Automatic scene detection; six manual preset modes for direct sunlight, shade, daylight fluores-			
	cent, warm white fluorescent, cool white fluorescent, and incandescent			
Self-timer	Off, 10 sec., 2 sec.			

System	
Flash	CCD-metered auto flash control; effective range when sensitivity is set to AUTO is approx. 50 cm–6.3 m/1.6 ft.–20.6 ft. (wide angle), 90 cm–3.5 m/2.9 ft.–11.4 ft. (telephoto); effective range in macro mode is approx. 30 cm–80 cm/0.9 ft.–2.6 ft. (wide angle), 80 cm–1.2 m/2.6 ft.–3.9 ft. (telephoto)
Flash mode	AUTO, 4, ③, S4 (face detection off); 爲, @4, ③, 爲, (face detection on)
LCD monitor	FinePix JX680 - JX695 / JX620 - JX645 3.0-in. (7.6 cm), 230k-dot color LCD monitor; frame coverage approx. 96%
	FinePix JX650 - JX675 / JX600 - JX615 2.7-in. (6.9 cm), 230k-dot color LCD monitor; frame coverage approx. 96%
Movies	Frame size 1,280 × 720, 640 × 480, 320 × 240; 30 fps; Linear PCM/monaural sound
Languages	Arabic, Bulgarian, Simplified Chinese, Traditional Chinese, Czech, Danish, Dutch, English, Farsi, Finnish, French, German, Greek, Hebrew, Hungarian, Indonesian, Italian, Japanese, Kazakh, Korean, Latvian, Lithuanian, Norwegian, Polish, Portuguese, Romanian, Russian, Serbian, Slovak, Spanish, Swedish, Thai, Turkish, Ukrainian, Vietnamese
Input/output terminals	
A/V OUT (audio/video output)	NTSC or PAL output with monaural sound
Digital input/output	USB 1.1 Full-Speed; shares A/V OUT connector; MTP/PTP

Specifications

Power supply/other				
Power supply	NP-45A/NP-45B rechargeable battery			
Battery life (approximate number of frames that can be taken with a fully-charged battery)	Battery type	Approximate number of frames		
	ND 454 (ND 450 (turns sumplied with some so)	FinePix JX650 - JX695: 230		
	NP-45A/NP-45B (type supplied with camera)	FinePix JX600 - JX645: 210		
	CIPA standard, measured in 🗖 (auto) mode using battery supplied with camera and SD memory card.			
	Note : Number of shots that can be taken with a decline at low temperatures.	battery varies with battery charge level and will		
Charging time	Approx. 120 minutes (+20 °C/+68 °F)			
Dimensions ($W \times H \times D$)	FinePix JX680 - JX695 / JX620 - JX645			
	95.1 mm × 57.1 mm × 21.4 mm/3.7 in. × 2.2 in. × 0.8 in.,			
	excluding projections (minimum depth 19.4 mm/0.7 in.)			
	FinePix JX650 - JX675 / JX600 - JX615			
	95.1 mm \times 57.1 mm \times 21.3 mm/3.7 in. \times 2.2 in. \times 0.8 in.,			
	excluding projections (minimum depth 19.3 mm/0.7 in.)			
Shooting weight	FinePix JX680 - JX695 / JX620 - JX645			
	Approx. 120 g/4.2 oz., including battery and memory card			
	FinePix JX650 - JX675 / JX600 - JX615			
	Approx. 113 g/3.9 oz., including battery and memory card			
Weight	FinePix JX680 - JX695 / JX620 - JX645			
	Approx. 104 g/3.6 oz., excluding battery, accessories, and memory card			
	FinePix JX650 - JX675 / JX600 - JX615			
	Approx. 97 g/3.4 oz., excluding battery, accessories, and memory card			
Operating conditions	 Temperature: 0 °C - +40 °C/+32 °F - +104 °F 			
	 Humidity: 10 % – 80 % (no condensation) 			

NP-45A/NP-45B rechargeable battery			
Nominal voltage	DC 3.7 V		
Nominal capacity	720 mAh		
Operating temperature	0 °C - +40 °C/+32 °F - +104 °F		
Dimensions ($W \times H \times D$)	31.0 mm × 39.6 mm × 6.0 mm/1.2 in. × 1.5 in. × 0.2 in.		
Weight	Approx. 15.5 g/0.5 oz.		
AC power adapter			
Rated input	100 V-240 V AC, 50/60 Hz		
Input capacity	• 100 V: 10 VA • 240 V: 20 VA		
Rated output	5.0 V DC, 1000 mA		
Operating temperature	0 °C - +40 °C/+32 °F - +104 °F		
Weight	Approx. 42 g/1.5 oz., excluding battery		

Weight and dimensions may vary with the country or region of sale.

Notices

- Specifications subject to change without notice. FUJIFILM shall not be held liable for damages resulting from errors in this manual.
- Although the LCD monitor is manufactured using advanced high-precision technology, small bright points and anomalous colors may appear, particularly in the vicinity of text. This is normal for this type of LCD monitor and does not indicate a malfunction; images recorded with the camera are unaffected.
- Digital cameras may malfunction when exposed to strong radio interference (e.g., electric fields, static electricity, or line noise).
- Due to the type of lens used, some distortion may occur at the periphery of images. This is normal.

FUJIFILM

FUJIFILM Corporation

7-3, AKASAKA 9-CHOME, MINATO-KU, TOKYO 107-0052, JAPAN http://www.fujifilm.com/products/digital_cameras/index.html

Please contact your local distributor for repairs and technical support. (see Worldwide Network list)