# **FUJ!FILM**















- **Getting Ready**
- Using the Camera
- Advanced **Features**
- **Settings**
- 5 Software Installation
- Viewing Images

DIGITAL CAMERA IS-1

# **OWNER'S MANUAL**

This manual will show you how to use your FUJIFILM DIGITAL CAMERA IS-1 correctly. Please follow the instructions carefully.

# Warning

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

### For customers in the U.S.A.

Tested To Comply With FCC Standards FOR HOME OR OFFICE USE

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try

to correct the interference by one or more of the following

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for

You are cautioned that any changes or modifications not expressly approved in this manual could void the user's authority to operate the equipment.

### Notes on the Grant

To comply with Part 15 of the FCC Rules, this product must be used with a Fuiifilm-specified ferrite-core A/V cable. USB cable and DC supply cord.

### For customers in Canada

This Class B digital apparatus complies with Canadian ICES-003.

Please read the Safety Notes (⇒P.160) and make sure you understand them before using the camera.

# **IMPORTANT**

Be sure to read this page before using the Software.

### NOTICE

BEFORE OPENING THE CD-ROM PROVIDED BY FUJIFILM Corporation, PLEASE READ THIS END USER LICENSE AGREEMENT CAREFULLY, ONLY IF YOU AGREE WITH THIS AGREEMENT. SHOULD YOU USE THE SOFTWARE RECORDED ON THE CD-ROM, BY OPENING THE PACKAGE, YOU ACCEPT AND AGREE TO BE BOUND BY THIS AGREEMENT

### **End User License Agreement**

This End User License Agreement ("Agreement") is an agreement between FUJIFILM Corporation ("FUJIFILM") and you, which sets forth the terms and conditions of the license granted for you to use the software provided by

The CD-ROM contains third party software. In case a separate agreement is provided by a third party supplier for its software, the provisions of such separate agreement shall apply to the use of such third party software, prevailing over those of this Agreement.

### 1 Definitions

- (a) Here, "CD-ROMs" refers to the CD-ROMs entitled "Software for FinePix" and "Hyper-Utility2" that are provided to you by FUJIFILM.
- (b) "Software" means the software which is recorded on Media.
  (c) "Documentation" means the operation manuals of Software and other
- related written materials which are provided to you together with
- (d) "Product" means Media (including Software) and Documentation

### 2. Use of Software.

- FUJIFILM grants to you a nontransferable, nonexclusive license: (a) to install one copy of Software onto one computer in binary machine executable form:
- (b) to use Software on the computer onto which Software is installed;
- (c) to make one backup copy of Software

### 3. Restrictions.

- 3.1 You shall not distribute rent lease or otherwise transfer all or any part of Software, Media or Documentation to any third party without FUJIFILM's prior written consent. You also shall not sublicense, assign or otherwise transfer all or any part of the rights granted to you by FUJIFILM under this Agreement without FUJIFILM's prior
- 3.2 Except as expressly granted by FUJIFILM hereunder, you shall not copy or reproduce all or any part of Software or Documentation.
- 3.3 You shall not modify, adapt or translate Software or Documentation. You also shall not alter or remove copyright and other proprietary notices that appear on or in Software or Documentation.
- 3.4 You shall not, or shall not have any third party, reverse-engineer decompile or disassemble Software

### 4. Ownership.

All copyrights and other proprietary rights to Software and Documentation are owned and retained by FUJIFILM or the third party suppliers as indicated on or in Software or Documentation. Nothing contained herein shall be construed, expressly or implicitly, as transferring or granting any right, license, or title to you other than those explicitly granted under this Agreement.

 Limited Warranty.
 FUJIFILM warrants to you that Media is free from any defect in material and workmanship under normal use for ninety (90) days from the date of your receipt of Media. Should Media not meet the foregoing warranty, FUJIFILM shall replace such defective Media with other Media bearing no defect. FUJIFILM's entire liability and your sole and exclusive remedy with regard to any defect in Media shall be expressly limited to such FUJIFILM's replacement of Media as provided herein

### 6. DISCLAIMER OF WARRANTY.

EXCEPT AS PROVIDED IN SECTION 5 HEREIN, FUJIFILM PROVIDES PRODUCT "AS IS" AND WITHOUT WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED. FUJIFILM SHALL MAKE NO WARRANTY, EXPRESS, IMPLIED OR STATUTORY, AS TO ANY OTHER MATTERS, INCLUDING, BUT NOT LIMITED TO NON-INFRINGEMENT OF ANY COPYRIGHT, PATENT, TRADE SECRET, OR ANY OTHER PROPRIETARY RIGHTS OF ANY THIRD PARTY, MERCHANTABILITY, OR FITNESS FOR ANY PARTICULAR

7. LIMITATION OF LIABILITY.
IN NO EVENT SHALL FUJIFILM HAVE ANY LIABILITY FOR ANY GENERAL, SPECIAL, DIRECT, INDIRECT, CONSEQUENTIAL INCIDENTAL, OR OTHER DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS OR LOST SAVINGS) INCURRED FROM THE USE OF OR INABILITY TO USE PRODUCT EVEN IF FUJIFILM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

### 8. No export.

You acknowledge that neither Software nor any part thereof, will be transferred, or exported to any country or used in any manner in violation of any export control laws and regulations to which Software is

In case you breach any of the terms and conditions hereof, FUJIFILM may immediately terminate this Agreement without any notice.

This Agreement is effective until the date when you cease to use Software, unless earlier terminated in accordance with Section 9

### 11. Obligation upon termination.

Upon termination or expiration of this Agreement, you shall, at your own responsibility and expense, delete or destroy immediately all Software (including its copies), Media and Documentation.

### 12. Governing Law.

This Agreement shall be governed by and construed in accordance with laws of Japan

# **EC Declaration of Conformity**

We Name: FUJIFILM Europe GmbH

Address: Heesenstrasse 31

40549 Dusseldorf, Germany

### declare that the product

FUJIFILM DIGITAL CAMERA IS-1 Product Name:

Manufacture's Name: FUJIFILM Corporation

Manufacture's Address: MIDTOWN WEST, 7-3, AKASAKA 9-CHOME, MINATO-KU,

TOKYO 107-0052, JAPAN

conforms to the following Standards Safety: EN60065

EMC: EN55022: 1998 Classe B

EN55024: 1998

EN61000-3-2: 1995 + A1: 1998 + A2: 1998

following the provision of the EMC Directive (89/336/EEC, 92/31/EEC and 93/68/EEC) and Low Voltage Directive (73/23/EEC).



Dusseldorf, Germany Place

February 1, 2007

Date

Signature/Managing Director



Bij dit produkt zijn batterijen geleverd. Wanneer deze leeg zijn, moet u ze niet weggooien maar inleveren als KCA

# Disposal of Electric and Electronic Equipment in Private Households

Disposal of used Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)



This symbol on the product, or in the manual and in the warranty, and/or on its packaging indicates that this product shall not be treated as household waste.

Instead it should be taken to an applicable collection point for the recycling of electrical and electronic equipment.

By ensuring this product is disposed of correctly, you will help prevent potential negative consequences to the environment and human health, which could otherwise be caused by inappropriate waste handling of this product.

If your equipment contains easy removable batteries or accumulators please dispose these separately according to your local requirements.

The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you have purchased the product.

### In Countries outside the EU:

If you wish to discard this product, please contact your local authorities and ask for the correct way of

# **Contents**

Warning         2           IMPORTANT         2           EC Declaration of Conformity         3           Disposal of Electric and Electronic Equipment in Private Households         3           Preface         7	Accessories included 8 Camera parts and features 9 Example of screen text display 10 Photography mode 10 Playback mode 10
1 Getting Ready	
ATTACHING THE STRAP, LENS CAP AND LEN	S HOOD11
Attaching the lens cap	
Attaching the lens hood	
INSERTING THE MEDIA	······································
Checking the battery charge	
TURNING ON AND OFF / SETTING THE DATE A	AND TIME 16
CORRECTING THE DATE AND TIME / CHANGI	NG THE DATE FORMAT ······· 17
SELECTING THE LANGUAGE	
2 Using the Camera	
BASIC OPERATION GUIDE	20
PHOTOGRAPHY MODE	
TAKING PICTURES (AUTO MODE)	23
INDICATOR LAMP DISPLAY	
NUMBER OF AVAILABLE FRAMES	
LISING AE/AE LOCK	
USING ZOOM FUNCTION	
PLAYBACK MODE	
VIEWING THE IMAGES (▶ PLAYBACK) ·········	31
Single-frame playback / Selecting images / Mu	ulti-frame playback ······ 31
Sorting by date	
FRASING IMAGE (FRASE FRAME)	
ETHORIVA INFACE (ETHOLTTIME)	
3 Advanced Features	
<b>● STILL PHOTOGRAPHY</b>	
PHOTOGRAPHY FUNCTIONS	
FOCUSING (DISTANCE)	
EXPOSURE (SHUTTER SPEED AND APERTUR	RE)
SELECTING PHOTOGRAPHY MODE	40
AUTO AUTO	40
SCENE POSITION	40
P PROGRAMMED AUTO	41
S SHUTTER-PRIORITY AUTO	42
A APERTURE-PRIORITY AUTO	43
AF- USING AF LOCK	
ADJUSTING LIGHT METERING (PHOTOMETRY	/)····································
CONTINUOUS AF	
MANUAL FOCUS	49

MACRO (CLOSE-UP)	50
FLASH PHOTOGRAPHY	
A\$ Auto flash	52
Red-eye reduction	
Forced flash	
\$\$ Slow synchro	
Red-eye reduction + Slow synchro	
CONTINUOUS SHOOTING.	54
Top 4-frame continuous shooting	55
♣ Auto bracketing	55 FF
☐ Final 4-frame continuous shooting	55 56
■ Long-period continuous shooting  INCREASING MONITOR BRIGHTNESS	
PHOTOGRAPHY INFORMATION	
F PHOTO MODE PHOTOGRAPHY	
	50
QUALITY MODE (NUMBER OF RECORDED PIXELS)	
Quality settings in Photography mode SENSITIVITY	61
☐ FinePix COLOR	
PHOTOGRAPHY MENU	_
SETTING PHOTOGRAPHY MENU ······	62
PHOTOGRAPHY MENU	
SELF-TIMER PHOTOGRAPHY	
IB WHITE BALANCE (SELECTING THE LIGHT SOURCE)	
I HIGH-SPEED SHOOTING	
■ AF MODE	
FLASH BRIGHTNESS ADJUSTMENT	69
S SHARPNESS	69
SATURATION	70
■ CONTRAST	
☐ BRACKETING	
MULTIPLE EXPOSURE	
■ USING AN EXTERNAL FLASH ····································	72
PLAYBACK	
PHOTOGRAPHY FUNCTIONS	
PLAYBACK INFORMATION	74
PLAYBACK MENU	
ERASING SINGLE / ALL FRAMES	75
2 IMAGE ROTATE	
F PHOTO MODE PLAYBACK	U
■ HOW TO SPECIFY PRINT OPTIONS (DPOF)	78
SPECIFYING DPOF SETTINGS EASILY	
PLAYBACK MENU	
□ DPOF SET FRAME ·······	81 <b>C</b>
DPOF ALL RESET	
☐ PROTECTING IMAGES: FRAME / SET ALL / RESET ALL ··································	-
AUTOMATIC PLAYBACK	
☑ RECORDING VOICE MEMOS	
☑ PLAYING BACK VOICE MEMOS ······	
■ Playing back voice memos ······	
Adjusting volume of voice memos	90
■ TRIMMING ·····	
MOVIE	
MOVIE MODE	
RECORDING MOVIES	93
■ Recording times per media ·······	
F PHOTO MODE MOVIE	
	05 <b>-</b>
■ QUALITY SETTINGS IN MOVIE MODE	<sup>95</sup> 5

# **Contents**

PLAYBACK MODE	
PLAYING BACK MOVIES	96
■ Playing back movies ·····	
Adjusting volume of movies ·····	97
4 Settings	
SET-UP	98
3 USING THE SET-UP SCREEN	
■ SET-UP menu options ······	
☑ IMAGE DISPLAY ····································	
PLAYBACK VOLUME	
■ FRAME NO. ·····	
ADJUSTING SCREEN BRIGHTNESS	
■ CCD-RAW	
₫ AUTO POWER OFF ·····	
■ FORMAT	
TIME DIFFERENCE	105
5 Software Installation	
5.1 SOFTWARE CONFIGURATION	
5.2 INSTALLATION ON A Windows PC (FinePixViewer)	108
5.3 INSTALLATION ON A Mac OS X (FinePixViewer)	110
5.4 INSTALLATION ON A Windows PC (Hyper-Utility2)	113
5.5 INSTALLATION ON A Mac OS X (Hyper-Utility2)	118
6 Viewing Images	
6.1 CAMERA CONNECTION	121
6.1.1 Using the AC Power adapter	121
6.1.2 Connecting to a TV	121
6.2 CONNECTING THE CAMERA DIRECTLY TO THE PRINTER — PictBridge FUNCTION	122
6.2.1 Specifying images for printing on the camera	122
6.2.2 Specifying images for printing without using DPOF (single-frame printing) ·······	
6.3 CONNECTING TO A PC	
6.3.1 Connecting to a PC ·····	
6.3.2 Disconnecting the camera ·····	
6.4 USING FinePixViewer	
6.4.1 Mastering FinePixViewer ·····	
6.4.2 Uninstalling the software ·····	
6.5 USING Hyper-Utility2 ·····	132

Notes on the Media 141 Warning Displays 142 Troubleshooting 145
Specifications
Explanation of Terms 151
FUJIFILM Digital Camera
Worldwide Network 154
Safety Notes ······ 160

# **Preface**

### ■ Test Shots Prior to Photography

For important photographs (such as weddings and overseas trips), always take a test shot and view the image to make sure that the camera is working normally.

 FUJIFILM Corporation cannot accept liability for any incidental losses (such as the costs of photography or the loss of income from photography) incurred as a result of faults with this product.

### ■ Notes on Copyright

Images recorded using your digital camera system cannot be used in ways that infringe copyright laws without the consent of the owner, unless intended only for personal use. Note that some restrictions apply to the photographing of stage performances, entertainments and exhibits, even when intended purely for personal use. Users are also asked to note that the transfer of memory cards (xD-Picture Card or CF/Microdrive) containing images or data protected under copyright laws is only permissible within the restrictions imposed by those copyright laws.

### ■ Liquid Crystal

If the LCD monitor is damaged, take particular care with the liquid crystal in the monitor. If any of the following situations arise, take the urgent action indicated.

- If liquid crystal comes in contact with your skin Wipe the area with a cloth and then wash thoroughly with soap and running water.
- If liquid crystal gets into your eye
   Flush the affected eye with clean water for at least
   15 minutes and then seek medical assistance.
- If liquid crystal is swallowed Flush your mouth thoroughly with water. Drink large quantities of water and induce vomiting. Then seek medical assistance.

### ■ Notes on Electrical Interference

If the camera is to be used in hospitals or aircrafts, please note that this camera may cause interference to other equipment in the hospital or aircraft. For details, please check with the applicable regulations.

### ■ Handling Your Digital Camera

This camera contains precision electronic components. To ensure that images are recorded correctly, do not subject the camera to impact or shock while an image is being recorded.

### ■ Trademark Information

- and xD-Picture Card™ are trademarks of FUJIFILM Corporation.
- IBM PC/AT is a registered trademark of International Business Machines Corp. of the U.S.A.
- Macintosh, Power Macintosh, iMac, PowerBook, iBook and Mac OS are trademarks of Apple Computer, Inc., registered in the U.S. and other countries.
- Microsoft, Windows, and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries. Windows is an abbreviated term referring to the Microsoft<sup>®</sup> Windows<sup>®</sup> Operating System.
- \* The "Designed for Microsoft" Windows XP" logo refers to the camera and the driver only.
- Other company or product names are trademarks or registered trademarks of the respective companies.

### **■** Explanation of Color Television System

NTSC: National Television System Committee, color television telecasting specifications adopted mainly in the U.S.A., Canada and Japan.

PAL: Phase Alternation by Line, a color television system adopted mainly by European countries and China.

### ■ Exif Print (Exif ver. 2.2)

Exif Print Format is a newly revised digital camera file format that contains a variety of shooting information for optimal printing.

Do not store or use the camera in direct sunlight or in places subject to extreme temperature rises, such as in a closed car in summer.

# **Accessories included**

• AA-size Alkaline Batteries (LR6) (4)



• Strap (1)



Lens cap (1)Lens cap holder (1)




an and

Lens hood (1)



A/V cable (1)

Approx. 1.2 m (3.9 ft.), plug (2.5 mm dia.) to pin-plug  $\times$ 2



• USB cable (mini-B) (1)



• CD-ROM (3)

Software for FinePix CX




· Hyper-Utility Software




Owner's Manual


# **Camera parts and features**

\* Refer to the pages in parentheses for information on using the camera parts or features.






# **Camera parts and features**




# **Example of screen text display**

# ■ Photography mode




# ■ Playback mode



1 Getting Ready

# ATTACHING THE STRAP, LENS CAP AND LENS HOOD




Attach the strap to the strap mounts on the camera. Once you have attached both ends of the strap, check carefully to make sure that the strap is firmly secured.

Attach the strap correctly to prevent dropping the camera.


Pull the lens cap cord through the strap.

Attach the lens cap cord to prevent losing the lens cap.



# Attaching the lens cap


Attach the lens cap to the lens by pressing in on both sides of the cap.



Make sure that the lens cap does not appear in your shot when taking a picture, attach it to the lens cap holder.

13

# ATTACHING THE STRAP, LENS CAP AND LENS HOOD




# Attaching the lens hood

When attaching the lens hood, it is effective for reducing ghost images and flare in backlit scenes. Camera provides crisp, clear shots.


1) Align the indicators on the camera and lens hood, and fit the lens hood to the lens.

The lens hood cannot be attached when the optional wideangle conversion lens is used.

②Turn the lens hood clockwise until it clicks.



# ♦ Storing lens hood ♦



As in storing lens hood into the soft case, the lens hood can be attached upside down.

# **LOADING THE BATTERIES**

# Compatible batteries

- AA-size alkaline batteries (4) or AA-size Ni-MH rechargeable batteries (4) (sold separately)
- Use the same brand and grade AA-size alkaline batteries as those supplied with the camera.

### ♦ How to use the batteries ◆


- Never use the following types of batteries, as they could cause serious problems such as battery fluid leakage or overheating:
- 1. Batteries with split or peeling outer casings
- 2. Combinations of different types of batteries or new and used batteries
- Do not use manganese or Ni-Cd batteries.
- Soil, such as fingermarks on the poles of the batteries can shorten time for which the batteries
- The time for which AA-size alkaline batteries (referred to hereafter simply as alkaline batteries) can be used varies depending on the brand. Some brands of alkaline batteries may stop providing power more quickly than those supplied with the camera. Note also that due to their nature, the time for which alkaline batteries can be used decreases in cold conditions (0°C to +10°C/+32°F to +50°F). The use of AA-size Ni-MH batteries is better for this reason.
- Use Fujifilm Battery charger (sold separately) to charge AA-size Ni-MH batteries.
- See P.137-138 for other notes on using batteries.
- When first purchased or if left unused for a long period, the amount of time which AA-size Ni-MH batteries can be used may be short. See P.138 for more information.



Check that the camera is turned off (set the Power switch to "OFF") before opening the battery cover.

- If opening the battery cover while the camera is still on, the camera will turn off.
- Do not apply force to the battery cover.

Do not open the battery cover while the camera is on. This could damage the media or ruin the image files on the media.



Load the batteries correctly as indicated by the polarity icons.



Press on the battery cover to push the batteries


Slide the cover closed.

j Ready

# **INSERTING THE MEDIA**

Use either **xD-Picture Card** (sold separately) or CF/Microdrive (sold separately) as recording media in the IS-1.


- If an xD-Picture Card and a CF/Microdrive are inserted at the same time, images will be recorded onto the media selected as the "■" MEDIA (⇒P.100).
- Data cannot be copied between the two media types on the IS-1.




- ① Set the Power switch to "OFF".
- 2 Open the slot cover.

If opening the slot cover while the camera is still on, the camera will turn off.

Do not open the slot cover while the camera is on. This could damage the media or ruin the image files on the media.




Align the gold marking on the xD-Picture Card slot with the gold contact area on the **xD-Picture Card** and push the card firmly all the way into the slot.



Push the CF/Microdrive firmly all the way into the CF/Microdrive slot.

Compatibility is listed on Fujifilm website: http://www.fujifilm.com/products/digital/

- Insert only the appropriate media types into the xD-Picture Card and CF/Microdrive slots. Inserting the incorrect media will damage the camera or media.
- If the media is oriented incorrectly, it will not go all the way into the slot. Do not apply force when inserting an xD-Picture Card or a CF/Microdrive.
- If the media is not fully inserted into the slot, [CARD ERROR] appears.



Close the slot cover.

# ♦ How to replace the xD-Picture Card ♦

Push the **xD-Picture Card** into the slot and then slowly remove your finger. The lock is released and the **xD-Picture Card** is pushed out.

# How to replace the CF/Microdrive CF / Microdrive eject button


Open the slot cover, press the CF/Microdrive eject button and remove the CF/Microdrive.

When storing CF/Microdrives, always use the special protective case.

# Checking the battery charge

Turn the camera on and check the battery charge.

- No iconLit redBlinking red
- 1) There is ample battery charge.
- ② There is insufficient charge left in the batteries. The batteries will soon run out. Have a new set of batteries ready.
- 3 The batteries are depleted. The display will shortly go blank and the camera will stop working. Replace or recharge the batteries.



"•• appears as a small icon on the left-hand side of the screen. •• appears as a large icon in the center of the screen.

- Depending on the camera mode and the type of batteries used, the transition from "" to "" may occur more quickly.
- Due to the nature of the battery, the battery level warning may appear early when the camera is used in cold locations. This is normal. Try warming the batteries in your pocket or a similar location before use.
- \* Battery level warning
- 1) The camera's estimation of the remaining battery charge varies greatly depending on the camera operation mode. Consequently, even if ""

  " or ""


  " is not displayed in Playback mode, one of them may appear when you change to Photography mode.
- 2) Depending on the battery type and the level of charge in the batteries, the camera may run out of power without first displaying a battery level warning. This is particularly likely to happen when batteries that have run out of charge once are re-used.
  - In situation 2), immediately load new or fully charged replacement batteries.

# ♠ Auto power off function ◆

If the camera is left unused for 2 or 5 minutes, the Auto power off function turns the camera off (➡P.104). To turn the camera back on, set the Power switch to "OFF" briefly and then back to "➡".

To turn the camera on, set the Power switch to "a"


To turn the camera off, set the Power switch to




When using the camera for the first time after purchasing, the date and time are cleared.


Press the "MENU/OK" button to set the date and time.

- The message also appears when the batteries have been removed and the camera has been left for a long period.
- To set the date and time later, press the "DISP/BACK" button. If you do not set the date and time, this message will appear each time you turn the camera on.



- ① Press "◀" or "▶" to select Year, Month, Day, Hour or Minute.
- ② Press "▲" or "▼" to correct the setting.







Once you have set the date and time, press the "MENU/OK" button. Pressing the "MENU/OK" button changes the camera to Photography or Playback mode.

At the time of purchase and after leaving the camera for a long period with the batteries removed, settings such as the date and time are cleared. Once the AC power adapter has been connected or the batteries have been installed for 2 hours or more, the camera settings will be retained for roughly 6 hours even if both sources of power are removed.


# CORRECTING THE DATE AND TIME / CHANGING THE DATE FORMAT




Press the "MENU/OK" button to display the menu on the screen.



- ① Press "▲" or "▼" to select "™ " SET-UP.
- ② Press "▶".



- ① Press "◀" to move to page number.
- ② Press "▲" or "▼" to select "PAGE 3".




- 1) Press ">" to move to menu item.
- ② Press "▲" or "▼" to select "⑤ " DATE/TIME.
- ③ Press "▶".

# **CORRECTING THE DATE AND TIME / CHANGING THE DATE FORMAT**

# **™** DATE/TIME 2008 2006 6.24 12:00 YY.MM.DD 2005 2004 OKSET BACK CANCEL MENU /OK MENU /OK

# Correcting the date and time

- ① Press "◀" or "▶" to select Year, Month, Day, Hour or Minute.
- ② Press "▲" or "▼" to correct the setting.
- 3 Always press the "MENU/OK" button after the settings are completed.
- Holding down "▲" or "▼" changes the numbers continuously. When the time displayed passes "12", the AM/PM setting




# Changing the date format


- -① Press "◀" or "▶" to select the date format.
- ② Press "▲" or "▼" to set the format. Refer to the table below for details of the settings.
- 3 Always press the "MENU/OK" button after the settings are completed.

Date format	Sample settings
YY.MM.DD	2006.6.24
MM/DD/YY	6/24/2006
DD.MM.YY	24.6.2006


# **SELECTING THE LANGUAGE**



- ① Press the "MENU/OK" button to display the menu on the screen.
- ② Press "▲" or "▼" to select "웹 " SET-UP.
- ③ Press "▶".





- ① Press "◀" to move to page number.
- ② Press "▲" or "▼" to select "PAGE 3".



- ① Press "▶" to move to menu item.
- ② Press "▲" or "▼" to select "言語/LANG.".
- ③ Press "▶".


The screens in this manual are shown in English.






Press "▲" or "▼" to select the language.


This section describes the camera's functions.





Up, down, left and right are indicated by black triangles in the Owner's Manual. Up or down is shown as "▲" or "▼", and left or right is shown as "◀" or "▶".

# **BASIC OPERATION GUIDE**



# ◆ Displaying the on-screen Help ◆


Instructions for the next step in the procedure appear at the bottom of the screen. Press the button indicated.

In the right side screen, press the "MENU/OK" button to erase the displayed frame. To cancel erasing, press the "DISP/BACK" button.





# PHOTOGRAPHY MODE TAKING PICTURES (AUTO MODE)



- 2 Set the Mode dial to "AUTO".
- 3 Set the Focus mode selector switch to "S-AF".

# Focal range

Wide-angle: approx. 40 cm (1.3 ft.) to infinity Telephoto: approx. 2 m (6.6 ft.) to infinity

- When [CARD ERROR], [CARD NOT INITIALIZED], [CARD FULL] or [NO CARD] appears, see P.142.



Press the Flash pop-up button to pop up the flash.

- ♦ When the flash pops up, the image may disappear and go

   The flash pops up, the image may disappear and go

   The flash pops up, the image may disappear and go

   The flash pops up, the image may disappear and go

   The flash pops up, the image may disappear and go

   The flash pops up, the image may disappear and go

   The flash pops up, the image may disappear and go

   The flash pops up, the image may disappear and go

   The flash pops up, the image may disappear and go

   The flash pops up, the image may disappear and go

   The flash pops up, the image may disappear and go

   The flash pops up, the image may disappear and go

   The flash pops up, the image may disappear and go


   The flash pops up, the image may disappear and go

   The flash pops up, the image may disappear and go

   The flash pops up, the image may disappear and go

   The flash pops up, the flash pops up, the image may disappear and go

   The flash pops up, the flash p dark briefly due to flash charging. The indicator lamp blinks orange during charging.
- If the flash is used in dusty conditions or when it is snowing, white dots may appear in the image due to flash reflecting off the dust particles or snowflakes. Use Suppressed flash mode to fix the problem.



Press the "EVF/LCD" button to alternate the display between the viewfinder (EVF) and the LCD

When the AF frame in the viewfinder (EVF) is difficult to see, adjust the viewfinder using the Diopter adjustment dial.

The EVF/LCD selection is retained even when the camera is off or the mode setting is changed.

Brace your elbows against your sides and hold the camera with both hands.

- Moving the camera while shooting gives a blurred picture (camera shake). Use a tripod to prevent camera shake, particularly for shots in the dark when the selected flash mode is Suppressed flash.
- There may be some uneven brightness at the lower edge of the screen. This is normal and does not affect the photographed image.



Hold the camera so that your fingers or the strap do not cover the lens, flash and AF-assist illuminator. If the lens, flash or AF-assist illuminator is obscured by your fingers or the strap, subjects may be out of focus or the brightness (exposure) of your shot may be incorrect.

Check that the lens is clean. If it is dirty, clean the lens as informed on P.137.

Frame the shot so that the subject fills the entire AF (Autofocus) frame.



- may differ in brightness, color, etc. from the image actually recorded. Play back the recorded image to check it (⇒P.31).
- When the subject is not in the AF frame, use AF/AE lock to take the picture (⇒P.28).




Press the shutter button down halfway. When a short double-beep is heard, the camera focuses on your subject. The AF frame on the screen becomes smaller and the camera sets the shutter speed and aperture. The indicator lamp (green) changes from blinking to lit.

- When a short double-beep is not heard and "!AF" appears on the screen, the camera cannot focus.
- Pressing the shutter button down halfway freezes the image on the screen briefly. This image is not the recorded image.
- When "!AF" appears on the screen, press again the shutter button down halfway or try standing about 2 m (6.6 ft.) from your subject to take the picture.
- The flash fires several times (pre-flashes and the main flash). When pressing the shutter button halfway, a lens operation
- sound may be heard.

When pressing the shutter button down halfway, "


appears on the screen before the flash fires. When selecting a slow shutter speed that will cause camera shake, "! "" appears on the screen. Use the flash to take pictures. According to the scene or mode being shot, use a tripod.



Press the shutter button down fully. When a clicking sound is heard, the camera records the

- ♣ There is a slight delay between the shutter button being pressed and the picture being taken. Play back the shot to check the image.
- When pressing the shutter button down fully in one motion, the camera takes the picture without the AF frame changing.
- When pressing the shutter button fully, the indicator lamp lights orange (shooting disabled) and next picture can be taken after turning off the indicator lamp.
- When taking a picture using flash, the image may disappear and go dark briefly due to flash charging. The indicator lamp blinks orange during charging.
- See P.142-144 for information on the warning displays.





Use a mechanical cable release with this camera. To prevent camera shake, use a tripod (sold separately) and cable release (sold separately).

## Compatible cable releases

ISO 6053: 1979-compliant cable releases

Do not apply force to a cable release attached to the camera. This could damage the camera.

# ◆ Compatible filters ◆

58 mm-diameter commercial available filters can be attached.

- Do not use more than one filter at a time.
- The lens cap (included) may not be used when attaching the filter.

# Subjects not suitable for autofocus


The IS-1 uses a high-precision autofocusing mechanism. However, it may have difficulty focusing on the following:

- Very shiny subjects such as a mirror or car body
- Subjects photographed through glass
- Subjects that do not reflect well, such as hair or fur
- Subjects with no substance, such as smoke or flames
- Dark subjects
- Fast moving subjects
- Subjects with little or no contrast between the subject and the background (such as white

- walls or subjects dressed in the same color as the background)
- Shots where another high-contrast object (not the subject) is close to the AF frame and is either closer or further away than your subject (such as a shot of someone against a background with strongly contrasting elements)

For such subjects use AF/AE lock (⇒P.28) or "MF" Manual focus mode (⇒P.49).

# ◆ Using LCD monitor ◆



You can adjust any angle of the LCD monitor. It is useful to shoot the subject that is in a high or low location.


# **INDICATOR LAMP DISPLAY**

Display	Status					
Lit green	AF/AE lock in progress, Setting video output					
Blinking green Camera shake warning, AF warning or AE warning (ready to shoot)						
Blinking green and orange alternately Recording to media (ready to shoot)						
Lit orange	Recording to media (not ready)					
Blinking orange	Charging the flash (flash will not fire)					
Blinking red	Media Warnings     No card inserted, card not formatted, incorrect format, card full and media error     Lens operation error					

telephoto shots.

\* Detailed warning messages appear on the screen (⇒P.142-144).


# **AF-ASSIST ILLUMINATOR**



Press the shutter button down halfway in dimly lit conditions. The camera fires the AF-assist illuminator (green) to allow easier focusing. Note that the effective range decreases for

- Leven when the AF-assist illuminator fires, the camera may have difficulty focusing in some conditions.
- Deven though there is no danger to safety, do not expose it directly in someone's eyes from a short distance.
- The camera focuses most easily when a picture is taken at a distance of around 3.5 m (11.5 ft.) with wide-angle and 2 m (6.6 ft.) with telephoto.
- When using the AF-assist illuminator in Macro mode, the camera may have difficulty focusing to take close-up shots.
- See P.100 for information on turning the AF-assist illuminator

# NUMBER OF AVAILABLE FRAMES



The number of available frames appears on the

See P.59 for information on changing the quality setting. The default quality "■" set at shipment is "■ N".

# ■ Standard number of frames per media

The table below shows the standard number of frames for a new media formatted on the camera. The larger the media capacity, the bigger the difference between the actual number of frames and the number shown here. Also, the size of an image file varies depending on the subject. So the number of remaining shots may decrease by 2 or may remain the same. For this reason, the number displayed may not show the actual number of frames.

Quality setting		9M F	9M N	3:2	5M	ЗМ	2M	03M	RAW
Number of	recorded pixels	3488 >	< 2616	3696 × 2464	2592 × 1944	2048 × 1536	1600 × 1200	640 × 480	_ *
	16 MB	3	6	6	12	19	25	122	0
	32 MB	6	13	13	25	40	50	247	1
xD-Picture	64 MB	13	28	28	50	81	101	497	3
Pict	128 MB	28	56	56	102	162	204	997	6
ure	256 MB	56	113	113	204	325	409	1997	13
Card	512 MB	113	227	227	409	651	818	3993	27
<u> </u>	1 GB	228	456	456	819	1305	1639	7995	54
	2 GB	456	913	913	1640	2558	3198	15992	108
Microdrive 340 MB		77	155	155	279	445	559	2729	18
Microdrive 1 GB		234	469	469	842	1313	1642	8212	55

\* Number of recorded pixel is 4864 × 3648 when displaying images on PC by using FinePixViewer.



In this shot, the subjects (two people in this case) are not in the AF frame. Taking the picture at this point will result in the subjects being out of focus.



Move the camera slightly so that one of the subjects is in the AF frame.



Press the shutter button down halfway (AF/AE lock). When a short double-beep is heard, the camera focuses on your subject. The AF frame on the screen becomes smaller and the camera sets the shutter speed and aperture. The indicator lamp (green) changes from blinking to lit.



Continue to hold the shutter button down halfway. Move the camera back to the original image and press the shutter button fully.




- AF/AE lock can be applied repeatedly before the shutter is
- excellent results.

# → AF (Autofocus)/AE (Auto-exposure) lock ◆ ·

On the IS-1, pressing the shutter button down halfway locks the focus and exposure settings (AF/AE lock). To focus on a subject that is off to one side or to set the exposure before composing the final shot, locks the AF and AE settings. Then take the picture to get the best result.

 When the camera cannot focus and AF/AE lock does not give the correct exposure Position the AF frame over the main subject and apply the AE lock (=P.46). Then position the AF frame over another subject at roughly the same distance. Press the shutter button down halfway. Recompose the shot and then take the picture.

# **USING ZOOM FUNCTION**




Turn the zoom ring to take pictures with zoom

The zoom bar appears on the screen during zooming.

# Optical zoom focal length (35 mm camera equivalent)

Approx. 28 mm to 300 mm Max. zoom scale: 10.7×



Press "▲" to change to Digital zoom mode (2×). When using digital zoom, "Q" appears in the bottom left corner of the screen and the zoom bar turns blue.

Use the zoom ring to adjust digital zoom operation as well as optical zoom. Press the "▼" button to cancel the digital zoom.

Select the framing guideline and post shot assist window in Photography mode.

Pressing the "DISP/BACK" button changes the screen display.

# **Best framing**



The framing guideline display consists of horizontal and vertical lines that divide the image on the screen into 9 frames.

# - 🌢 Important 🔷 -

Always use AF/AE lock when composing a shot. The image may be out of focus if AF/AE lock is not used.

### Scene



Position the main subject at the intersection of two lines in this frame or align one of the horizontal lines with the horizon. Use this frame as a guide to the subject's size and the balance of the shot while composing a shot.

- The framing guideline is not recorded on the image.
- roughly equal parts horizontally and vertically. The resulting printed image may be shifted slightly from the scene frame.

### Post shot assist window



When using the post shot assist window, the last photographed image appears as a thumbnail in the bottom left corner of the screen (post shot assist

Up to the last 3 photographed images appear on the post shot assist window. This serves as a guide for taking other shots with similar compositions.

- Any of the following clears the image in the post shot assist
- Setting the camera to Playback mode
- . Turning the camera off
- Using the PictBridge function
- . Using the DSC mode etc.


# Single-frame playback

- Set the Power switch to "▶".
- ② Press "▶" to scan forward through the images. Press "◀" to scan backwards.
- Set the Power switch to "▶" to play back the last shot.




# Selecting images

To select images on the thumbnail lists screen, hold down "◀" or "▶" for 1 second during playback.



# Multi-frame playback

In Playback mode, press the "DISP/BACK" button to change the display shown on the screen. Press the "DISP/BACK" button until the multi-frame playback screen (9 frames) appears.




- ① Press "A". "▼". "◄" or "▶" to move the cursor (colored frame) to the selecting frame. Press "▲" or "▼" repeatedly to jump to the next page.
- 2 Press the "MENU/OK" button again to enlarge the image.

# ◆ Still images viewable on the IS-1 ◆

This camera will display still images recorded on the IS-1 or still images (excluding some uncompressed images) recorded on any FUJIFILM digital camera that supports xD-Picture Cards or CF/Microdrives.

Clear playback or playback zooming may not be possible for still images shot on cameras other than the IS-1.




PLAYBACK MODE VIEWING THE IMAGES ( PLAYBACK)


# Sorting by date

In Playback mode, press the "DISP/BACK" button to change the display shown on the screen. Press the "DISP/BACK" button until the sorting by date screen appears.


Large number of images may take longer to appear.



Changing to Sorting by date mode displays the images taken on the same day as the image selected in Multi-frame playback mode.




Press "▲", "▼", "◀" or "▶" to move the cursor (colored frame) to the selecting frame.




To select the date:

- ① Press "▲", "▼", "◄" or "▶" to move the cursor (colored frame) to "+" on the upper left frame.
- ② Press "◀" to display the selecting date.



Press "▲", "▼", "◀" or "▶" to move the cursor (colored frame) to the selecting frame.



Press the "MENU/OK" button to enlarge the selected image.



# Playback zoom

Press "▲" or "▼" during single-frame playback to zoom the image. A zoom bar appears on the screen.

- Press the "DISP/BACK" button to cancel playback zoom.
   Playback zoom cannot be used with multi-frame playback.





- ① Press "◀" or "▶" to select to "PANNING". ② Press "▲", "▼", "◄", or "▶" to display another
- part of the image.

The current displayed image appears on the navigation screen.




Navigation screen

Press the "DISP/BACK" button to return to the zoom setting.


### ■ Zoom scales

Quality mode	Max. zoom scale
■M (3488 × 2616 pixels)	Approx. 5.5×
32 (3696 × 2464 pixels)	Approx. 5.8×
5M (2592 × 1944 pixels)	Approx. 4.1×
M (2048 × 1536 pixels)	Approx. 3.2×
2M (1600 × 1200 pixels)	Approx. 2.5×




- ① Set the Power switch to "▶".
- 2 Press the "MENU/OK" button to display the menu on the screen.

Erased frames (files) cannot be recovered. Back up important frames (files) onto your PC or another



- ① Press "▲" or "▼" to select " iii " ERASE.
- ② Press "▶".



- ① Press "▲" or "▼" to select "FRAME".
- 2 Press the "MENU/OK" button.
- See P.75 for information on "ALL FRAMES".



- ① Press "◀" or "▶" to select the erasing frame
- ② Press the "MENU/OK" button to erase the displayed frame (file).
- To erase another frame (file), repeat steps ① and

When erasing frames (files) is completed, press the "DISP/BACK" button.

consecutive frames (files). Take care not to erase a frame (file) by mistake.

Using the Camera

**EXPOSURE (SHUTTER SPEED AND APERTURE)** 

The distance from the subject to the camera is referred to as the shooting distance. When the shooting distance is set correctly and the image appears sharp, the image is focused.

# ■ Three focusing methods

The mechanisms for focusing are S-AF (Single AF), C-AF (Continuous AF) and MF (Manual focus).

S-AF: Use S-AF for normal photography. In this mode, the camera focuses each time the shutter button is pressed down halfway. Select the AF mode (→P.68) when the Mode dial is set to "P", "S", "A" or "M" mode.

### - ◆ The AF sensor ◆ -

The IS-1 uses an external AF sensor (external-light passive phase difference AF) that features faster AF operation than previous models. The external AF sensor does not function when Macro mode, Super macro mode, the digital zoom, AREA or C-AF focusing is used. It may take longer to focus if the external AF sensor is soiled (➡P.145).

**C-AF:** Use C-AF to photograph moving subjects. When this mode is set, the camera focuses continuously on the subject in the center of the screen. See P.48 for details.

MF: The focus is adjusted by turning the focusing ring manually. See P.49 for details.


### ■ Causes of focusing errors and the solutions


Cause	Solution
The subject is not in the AF frame.	Use AF lock (AF mode: AF (CENTER)) *1 or MF.
The subject is not suited to AF.	Use AF lock (AF mode: AF (CENTER)) *1 or MF.
The subject is outside the shooting range.	Turn Macro mode on or off *2.
The subject is moving too quickly.	Use MF (pre-setting the shooting distance for a shot )


# \*1 Taking pictures using AF lock



### \*2 Turning Macro mode ON/OFF







# Subjects not suitable for autofocus


in the center of screen

- Very shiny subjects such as a mirror or car body
- Subjects photographed through glass
- Subjects that do not reflect well, such as hair or fur
- Subjects with no substance, such as smoke or flames
- Dark subjects
- Fast moving subjects

- Subjects with little or no contrast between the subject and the background (such as white walls or subjects dressed in the same color as the background)
- Shots where another high-contrast object (not the subject) is close to the AF frame and is either closer or further away than your subject (such as a shot of someone against a background with strongly contrasting elements)

Exposure refers to the light that hits the CCD or the total amount of captured light and determines the brightness of the image.

The exposure is determined by the combination of aperture and shutter speed. In AE (Auto-exposure), the camera determines the correct exposure, allowing for factors such as the brightness of the subject and the sensitivity setting.



PHOTOGRAPHY FUNCTIONS

The graph at left shows the way the aperture and shutter speed settings can be changed while maintaining the same exposure level.

- When the aperture is decreased by one step, the shutter speed also decreases by one step (the dot moves upper left).
- When the aperture is increased by one step, the shutter speed also increases by one step (the dot moves lower right).
- Combinations that result in the shutter speed or aperture being outside the available range of settings cannot be selected (white dots).
- In the "P", "S" and "A" Photography modes, it is easy to select different settings along this line.
- Selecting settings that run parallel to this line by adjusting the brightness of the photographed image is referred to as exposure compensation.

# ♦ When you cannot get the correct exposure ◆

AE lock: Determines and fixes the exposure at a target level. Use the following procedure to take a picture using AE lock:

Press the "AE-L" button (sets and locks the exposure). ➡ Press the shutter button down halfway (sets and fixes the focus). ➡ Press the shutter button down fully (takes the picture).







### Exposure compensation:


This function uses the exposure level set by

the AE function as a reference (0) and then brightens (+) or darkens (-) the image

By selecting auto bracketing, you can shoot 3 frames, one underexposed (-), one at the reference exposure (0) and one overexposed (+).

# Shutter speed

When shooting a moving subject, you can either "freeze the motion" or "capture the sense of movement" by adjusting the shutter speed.




Freezes the motion of the subject.



Photographs the traces left by the subject's movement.

# Aperture

By adjusting the aperture, you can change the depth of focus (depth of field).



The area in front of and behind the subject is also in focus in the shot.



The area in front of and behind the subject is out of focus.

6

Advanced Features

# TAKING PICTURES — SELECTING THE CAMERA SETTINGS

Specify the camera settings for taking pictures to get the best result. A general quide is given below.

Select the Photography mode (⇒P.40-44). I

Specifies all settings other than "Quality", "Sensitivity" and "FinePix AUTO

COLOR" on the camera.

P/S/A

Changes the aperture or shutter speed setting so that the action is frozen, the flow of the motion is conveyed, or the background is out

of focus.

Adjusts all the camera settings yourself.

Specify the photography settings (⇒P.45-47, 50-56). □

Exposure compensation Uses the AE exposure as a reference value of 0. This

function brightens (+) or darkens (-) the shot.

AE-L AE lock Fixes the exposure settings.

Used for shots where the brightness of the subject Photometry

and background differ markedly and the light is not

metered as desired.

Macro/**№** Super macro Used for close-up shots.

Flash Used for shots in dark locations or for backlit subjects.

Continuous shooting Used to take a series of continuous shots or to use

auto bracketing (with exposure compensation).

Take the pictures (check the exposure and focus → adjust the shot composition ⇒ press the shutter button down fully).



You can use the menus for more detailed settings (⇒P.59-73).

The table below provides a number of sample settings. Use the settings effectively.

To achieve this result	Sample settings					
To express the motion of the subject	Set the Mode dial to "S" and select a slow shutter speed. Use a tripod to prevent camera shake.					
To freeze the subject's movement	Set the Mode dial to "S" and select a fast shutter speed.					
To make the subject stand out by having the area in front of and behind the subject out of focus	Set the Mode dial to "A" and select a wide aperture setting.					
To get a very large depth of focus	Set the Mode dial to "A" and select a narrow aperture setting. Use a tripod to prevent camera shake because shutter speed decreases.					
To prevent the image from having a red or blue cast due to the light source	Change the "White balance" setting in the photography menu.					
To avoid missing snapshot opportunities	Take pictures in AUTO mode (see "Using the Camera"). Shoot with HIGH-SPEED SHOOTING.					
To prevent the subject from being overexposed or underexposed and to show the substance and textures of the subject clearly	Use exposure compensation. Select (+) if the background is pale and (-) if the background is dark.					

### ■ List of functions available in each mode

√: YES , —: NO

		_	Photography	y mode	AUTO	Picture Stabilization	Natural light	Portrait	<b>▲</b> Landscape	* Night	Р	S	А	М
Ļ	Function						Р	.40				P.4	1-44	
L			mpensation	P.45				_			1	1	1	_
L	AE-L AE loc	k		P.46	1			✓			1	1	1	_
L	Photometry		P.47	1	✓					1	1	1	/	
L	Focus mode (S-AF/C-AF/MF)		P.22	1	/					1	1	1	1	
l	■ Macro/®	<b>S</b> u	per macro	P.50	1	1	1	_	_	_	1	1	1	1
		A4	Auto flash	P.52	1	1	_	1	_	_	1	_	_	_
1		0	Red-eye reduction	P.52	1	1	_	1	_	_	1	1	1	1
l	<b>\$</b> Flash	4	Forced flash	P.52	1	1	_	1	_		1	1	1	1
l		S#	Slow synchro	P.52	<b>—</b>	_	_	1	_	1	1	_	1	_
l		SLOT	Red-eye reduction+ Sow synchro	P.52	_	_	_	1	_	1	1	_	1	_
l		٩	Top 4-frame	P.55	1			1			1	1	1	1
	Oti	3	Auto bracketing	P.55	_		_				1	1	1	1
	Continuous shooting	r <sub>o</sub>	Final 4-frame	P.55	1			1			1	1	1	1
	00019	-	Long-period (up to 40 frames)	P.56	1			/			_	_	_	_
_				* Tho									$\overline{}$	

\* The flash cannot be used for Continuous shooting and Super macro.

# ■ List of menu options available in each mode

J: YES —: NO

Elst of		, , , , , , , , , , , , , , , , , , ,	tione avail		Factory					120,	1
					default	AUTO	<b>₩/•</b> /\$/ <b>▲</b> /♦	Р	S	Α	M
	•	€ QUALITY			9M N	1	✓	1	1	1	1
FinePix Photo mode	ISO	ISO		P.61	_	1	<b>√</b> *1	1	1	1	1
		FinePix COLOR			STD	1	✓	1	1	1	1
	Self-timer     Self-timer			P.65	OFF	1	✓	1	1	1	1
	WB	White ba	hite balance		.66 AUTO		_	1	1	1	1
	ÓΞ	High-spe	eed shooting	P.67	OFF	1	✓	1	1	1	1
	_		■ CENTER	P.68		1	✓	1	1	1	1
	AF I	mode	± MULTI	P.68	CENTER	_	_	1	1	1	1
	, ·		☑ AREA	P.69	OZ.T.Z.T	_	_	1	1	1	1
Photography menu	Flash bright adjustment			P.69	0	_	_	1	1	1	1
	8	Sharpness		P.69	STD	_	_	1	1	1	1
	3	Saturation		P.70	STD			1	1	1	1
	0	Contrast	t	P.70	STD	-	_	1	1	1	1
	d	■ Bracketing		P.70	±1/3EV	_	_	1	1	1	/
		Multiple	exposure	P.71	OFF	_	<u> </u>	1	1	1	1
	<b>/</b> *€	<u> </u>		P.72	OFF		<u> </u>	1	1	1	1


\* MULTI, AREA and Continuous AF (C-AF) cannot be used together.

When shutter speed and aperture adjustments alone do not give the correct exposure.

When the image is too bright Lower the sensitivity setting. Use an ND filter (sold separately). When the image is too dark Raise the sensitivity setting. Use flash or the brightness adjustment function.

# PHOTOGRAPHY FUNCTIONS SELECTING PHOTOGRAPHY MODE

# AUTO AUTO




Set the Mode dial to "AUTO".

This is the easiest mode to use and can be used for most types of shots.

See P.39 for information on available flashes.

# **SCENE POSITION**




Set the Mode dial to "♣N", "T", "F", "A" or "E". This mode provides the best Scene position setting for the scene being shot.

", "A" and "C" cannot be selected Macro mode.

Scene position settings	Explanation	Available flash modes
Picture Stabilization	Using this mode selects a fast shutter speed that reduces camera shake and moving-subject blurring.	A\$ / • / \$
<b>ଐ</b> Natural light	This mode produces beautiful images that retain the natural ambience when shots are taken in low-light conditions. This mode is also ideal for shooting indoor or situations where the flash cannot be used.  Sample uses:  Portraits of sleeping children, pets and birthday cakes  Candlelit services (weddings, etc.) and school concerts  Restaurants, aquariums, museums and churches	Flash not available. When the flash is popped up, "*(3)" appears.
Portrait	Used for photography getting beautiful skin tones and soft overall tone.	A\$ / • / \$\$ / \$\$
▲ Landscape	Used for shooting scenery in daylight and provides crisp, clear shots of scenery such as buildings and mountains.	Flash not available. When the flash is popped up, "3" appears.
<b>♥</b> Night	Used for shooting evening and night scenes. This mode allows you to take shots where priority is given to slow shutter speeds of up to 4 seconds. To prevent camera shake, always use a tripod.	S\$ / SS


🜓 In Picture Stabilization or Natural light mode, when you have been used for long periods in places subject to extreme temperature rises, it will lower your image quality and streaking may also be visible in your images. If this occurs, turn the camera off several times to prevent heating the camera. Setting High-speed shooting mode to "OFF" is

# ◆ Changing the Photography mode ◆



When turning the Mode dial, the Mode dial appears on the screen to check the selected mode. You can operate watching the screen. It is useful such as when taking pictures using viewfinder (EVF).

# PHOTOGRAPHY FUNCTIONS P PROGRAMMED AUTO



Set the Mode dial to "P".

This is an automatic mode to specify the settings except for the shutter speed and aperture setting. This is a simple way to take pictures the same as the Shutter-priority Auto and Aperture-priority Auto modes (Program shift).

# Command dial 9M N 6 ISO 200 $\begin{bmatrix} + \end{bmatrix}$ 遭 (IP 320 F5.6


# **Program shift**

Turn the Command dial to select different shutter speed and aperture setting combinations without changing the exposure setting. The shutter speed and aperture setting appear in yellow when the camera is in Program shift mode.

Any of following cancels Program shift:

- Changing the Mode dial setting
- Popping the flash up
- Setting "F" EXTERNAL FLASH to "ON" in the Photography menu
- · Setting the camera to Playback mode
- Turning the camera off

# ◆ The shutter speed and aperture setting display ◆



When the brightness of the subject is outside the camera's brightness metering range, "---" appears as the shutter speed and aperture setting on the screen.


3

**Advanced Features** 

# **Advanced Features**


43

# PHOTOGRAPHY FUNCTIONS S SHUTTER-PRIORITY AUTO



Set the Mode dial to "S".

This is an automatic mode to set the shutter speed. Use this mode to freeze a moving subject (fast shutter speed) or convey the impression of movement (slow shutter speed).



# Setting the shutter speed

Turn the Command dial to select the shutter speed.


# Shutter speed setting

Wide-angle:

4 sec. to 1/4000 sec. in 1/3 EV increments Telephoto:


4 sec. to 1/2000 sec. in 1/3 EV increments

# ◆ The shutter speed and aperture setting display ◆



In scenes that are extremely overexposed, the aperture setting (F8) appears in red. When this occurs, select a faster shutter speed (up to 1/4000 sec.).






In scenes that are extremely underexposed, the aperture setting (F2.8) appears in red. When this occurs, select a slower shutter speed (down to 4 sec.).


Metering failed

42




When the brightness of the subject is outside the camera's brightness metering range, "F---" appears as the aperture setting. When this occurs, press the shutter button down halfway to measure the light level again and display a value.

# PHOTOGRAPHY FUNCTIONS A APERTURE-PRIORITY AUTO



Set the Mode dial to "A".

This is an automatic mode to set the aperture. Use this mode to have the area in front of and behind the subject out of focus (large aperture) or have both near and far subjects in focus (small aperture).




# Setting the aperture

Turn the Command dial to select the aperture.

### Aperture settings


Wide-angle: F2.8 to F8 in 1/3 EV increments Telephoto: F4.9 to F8 in 1/3 EV increments

# ◆ The shutter speed and aperture setting display ◆




In scenes that are extremely overexposed, the shutter speed setting (1/2000 sec. or 1/4000 sec.) appears in red. When this occurs, select a larger number of aperture (up to F8).





In scenes that are extremely underexposed, the shutter speed setting (4 sec.) appears in red. When this occurs, select a smaller number of aperture.

Metering failed



When Forced flash mode is selected, the slowest available shutter speed is 1/45 sec.

When the brightness of the subject is outside the camera's brightness metering range, "----" appears as the shutter speed setting. When this occurs, press the shutter button down halfway to measure the light level again and display a value.

Set the Mode dial to "M".

Use Manual mode to set any shutter speed and aperture setting.

# 9M N 6 ISO 200 Shutter speed

# Setting the shutter speed


Turn the Command dial to select the shutter speed.

- Shutter speed setting
- 30 sec. to 1/4000 sec. in 1/3 EV increments Bulb (B)
- See P.151 for information on EVs.
- Use a tripod or cable release to prevent camera shake.
- In shots with long exposures, noise (dots) may appear on the
- If the shutter speed is set to a speed faster than 1/2000 sec., smearing (white stripes) may appear in the image (⇒P.151).
- If the shutter speed is set to a speed faster than 1/1000 sec., the image may appear dark even if the flash is used.

# ◆ Bulb photography ◆

**M** 320 F5.6

Setting shutter speed to "B" (Bulb) allows bulb shots to be taken. In bulb photography, the shutter stays open for as long as the shutter button is held down (up to 30 seconds). Use a tripod or a cable release to keep the camera steady.




# Setting the aperture

- 1) Hold down the "" button.
- 2 Turn the Command dial to select aperture.
- Aperture settings

Wide-angle: F2.8 to F11 in 1/3 EV increments Telephoto: F4.9 to F11 in 1/3 EV increments

# ◆ The exposure indicator ◆




Use the exposure indicator on the screen as a guide when setting the exposure.


When the brightness of the subject is outside the camera's brightness metering range, the exposure indicator disappears on the screen.

PHOTOGRAPHY FUNCTIONS


Use this function for shots to get the correct brightness (exposure), such as shots with extremely high contrast between the subject and the background.



Set the Power switch to "a".



Set the Mode dial to "P". "S" or "A" mode.



- ① Hold down "■" button.
- 2 Turn the Command dial to set the compensation

The symbol indicating the compensation direction (- or +) turns yellow. The "" icon also turns yellow while exposure compensation is being set and then turns blue after setting is completed.

### Compensation range

-2 EV to +2 EV (13 steps in 1/3 EV increments)

- Exposure compensation cannot be used in the "AUTO". "\*\". "๋๋๋๋๋๋", "�", "▲", "໕", "M" and "ゐ" modes.
- The screen brightness will increase or decrease depending on the exposure compensation setting.
- The following disables exposure compensation: Shooting dark scenes in "4" Forced flash or "@" Red-eye reduction mode.

This setting is retained when the mode is changed or the camera is turned off ("" icon appears). Set the exposure compensation to "0" unless compensation is required.

# ◆ To obtain the optimum brightness ◆


Adjust the exposure compensation according to the level of brightness or darkness in the image.

- When the subject appears too bright Try a negative (-) compensation setting. This will make the overall image darker.
- When the subject appears too dark Try a positive (+) compensation setting. This will make the overall image brighter.


- Guide to compensation
- Backlit portraits: +2 steps to +4 steps  $(+\frac{2}{3})$  EV to +1 $\frac{1}{3}$  EV)
- Very bright scenes (such as snowfields) and highly reflective subjects: +3 steps (+1 EV)
- Shots made up predominantly of sky: +3 steps (+1 EV)
- Spotlit subjects, particularly against dark backgrounds: -2 steps ( $-\frac{2}{3}$  EV)
- Scenes with low reflectivity, such as shots of pine trees or dark foliage: -2 steps ( $-\frac{2}{3}$  EV)

**Available Photography modes:** 

Use this function to take pictures with the exposure locked for a particular subject.



Set the Power switch to "a".



Set the Mode dial to "AUTO", "A", "O", "O", "A", "**(**\* ", "P", "S" or "A" mode.

AE lock cannot be used when Long-period continuous




Position the subject in the center of the screen and press the "AE-L" button.

"\begin{align\*}" appears on the screen and the exposure is locked while you hold down the "AE-L" button.


AE-L1	The exposure is locked while holding down the "AE-L" button.
AE-L2	Pressing the "AE-L" button locks the exposure. Press the "AE-L" button again to cancel the setting.

- See P.100 for information on changing the setting to AE-
- AE lock can be canceled when zooming the subject during




With the "AE-L" button held down, press the shutter button down halfway to focus the shot and then compose the shot again.

- Once you press the shutter button down halfway, the exposure remains locked even if you release the "AE-L"
- ♦ When the AE lock is applied, pressing the shutter button down halfway only sets the focus.




PHOTOGRAPHY FUNCTIONS

Set the Power switch to "a".



Set the Mode dial to Photography mode.

Available Photography modes: AUTO, AN,



Turn the Photometry selector dial to select the light metering method.

[O] Multi (Pattern): Light metering where the camera assesses the scene and selects the correct

exposure. [•] Spot: Light metering where the exposure is optimized for the center of the image.

[ ] Average: Light metering where an average value for the entire image is used.

# ◆ To use the photometry modes effectively ◆

### Multi

In this mode, the camera uses automatic scene recognition to analyze the subject and provide optimum exposure in a wide range of shooting conditions.

Spot

This mode is useful for subjects with strongly contrasting light and dark areas where you want to achieve the correct exposure for a particular feature.

Average

The advantage of this mode is that the exposure tends not to change for different compositions or subjects. This mode is particularly effective for shots of people wearing black or white clothing and shots of scenery.

**Advanced Features** 


Use this button to take pictures of a moving subject. Using Continuous AF mode reduces the time required for focusing.

Set the Focus mode selector switch to "C-AF".




Frame the shot so that the subject fills the entire AF frame

The camera continues to focus on the main subject in the AF frame.



Press the shutter button down halfway. When a short double-beep is heard, the camera focuses on your subject. The AF frame on the screen becomes smaller and the camera sets the shutter speed and aperture. The indicator lamp (green) changes from blinking to lit.



Press the shutter button down fully. When a clicking sound is heard, the camera records the image.


# ◆ Notes on continuous AF ◆

Because the camera focuses continuously without pressing the shutter button, note the following:

- Watch the battery level carefully since the camera consumes more power in this mode than in other Focus modes (S-AF and MF).
- If the Auto power off function is set to "OFF", particular attention must be given to the battery level.

Use manual focus to lock the focus for a shot.


PHOTOGRAPHY FUNCTIONS



- ① Set the Focus mode selector switch to "MF".
- ② The "III" appears on the screen.
- If the focus is set to infinity using manual focusing, position the "O" mark on a subject close to infinity. Continuing to turn the focus ring will move the focus position beyond infinity and defocus the image.

# Using manual focus effectively

The image is unfocused when the camera moves. Use a tripod to prevent camera shake.



- Press "▶●◄" button to focus on the subject in the focus frame.
   A focusing indicator mark appears on the
- screen. Check whether "()" mark appears in yellow.

  ③ When the "()" mark is not yellow, turn the focus
- ring until the "()" mark appears in yellow.

# ■ Focusing indicator marks


The focusing mark appears when the focus is close to the focused position. Use the mark to focus the shot.

() (Yellow)	The shot is focused.	
(,)	The focus is set too close. Turn the focus ring clockwise.	
( <b>,</b> )	The focus is set too far. Turn the focus ring counterclockwise.	

# ♦ One-touch AF function ♦ -

Use this function to focus the shot quickly.

Pressing the "> < " button, the camera uses the autofocus function to focus on the subject.



# Focus check function

Use this function when it is difficult to see whether the image is focused.

Pressing the "[\*\*]" button, the center of the image is shown enlarged and can be focused using the enlarged image. Take the picture or press the "[\*\*\*]" button again to return to normal display.

- Focus check function can be used in the "□" CENTER and
   "MF" mode.
- √ Focus check function is disabled when setting the High-speed shooting mode or setting "□" EVF/LCD MODE to "60 fps" in the "☑" SET-UP menu.

Advanced Feature

**Available Photography modes: АUTO**, **М**, **О**, P, S, A, M


PHOTOGRAPHY FUNCTIONS

modes according to the type of shot.


**Available Photography modes: AUTO**, ₩, ♥, ♥, P, S, A, M

Use this mode to take close-up shots.

Set the Power switch to "a".



Set the Mode dial to "AUTO", "A", "P", "S", "A" or "M" mode.




The Macro mode setting changes each time you press the "\$" button.

- Any of the following cancels Macro mode:
- Changing the Mode dial to "♥", "▲", "♥" or "\" mode
- Turning the camera off
- If the flash is too bright, use flash brightness adjustment
- Use a tripod to prevent camera shake when shooting in the dark (when "! "" appears).
- Selecting MULTI in the AF mode, the focusing position remains near the center of the screen.

	Focal range	Effective flash range
<b>♥</b> Macro	Wide-angle: Approx. 10 cm-3 m (3.9 in. to 9.8 ft.) Telephoto: Approx. 90 cm-3 m (3.0 ft. to 9.8 ft.)	Wide-angle: Approx. 30 cm-3 m (1.0 ft9.8 ft.) Telephoto: Approx. 90 cm-3 m (3.0 ft9.8 ft.)
& Super macro	Approx. 1 cm-1 m (0.4 in3.3 ft.) (Wide-angle only)	Flash not available

◆ Super macro ◆



Use the lens at the wide-angle zoom setting in Super macro mode. If your camera select any other settings, "♣" appears on the screen. Turn the zoom ring to adjust zoom setting as indicated "♣".

Flash photography is useful for taking pictures at night or indoor dark locations. Choose from 5 flash

Set the Power switch to "a".



Set the Mode dial to "AUTO". "\*". "V". "P". "S". "A". or "M" mode.

 If the shutter speed is set to a speed faster than 1/1000 sec., the image may appear dark even if the flash is used.

Press the Flash pop-up button to pop-up the flash.


• Effective flash range (" I ": AUTO) Wide-angle: approx. 30 cm to 5.6 m (1.0 ft. to 18.4 ft.)

Telephoto: approx. 90 cm to 3 m (3.0 ft. to 9.8 ft.)

- When the flash pops up, the image may disappear and go dark briefly due to flash charging. The indicator lamp blinks orange during charging.
- 4 0 9M N ▣ AUTO
- ① Hold down the "4" button.
- 2 Turn the Command dial to select the flash mode setting.

See P.72 for information on using an external flash.

The available flash modes are limited depending on the Photography mode selected (⇒P.39).



When pressing the shutter button down halfway, "3" appears on the screen before the flash fires.

- "A\$", "•", "\$\$" or "\$\mathbb{A}" appears on the screen when using flash.
- If the flash is used in dusty conditions or when it is snowing, white dots may appear in the image due to flash reflecting off the dust particles or snowflakes. Use Suppressed flash mode to fix the problem.
- The flash charging time may increase when the batteries are
- When taking a picture using flash, the image may disappear and go dark briefly due to flash charging. The indicator lamp blinks orange during charging.
- The flash fires several times (pre-flashes and the main flash). Do not move the camera until the picture is taken.

Continued



# A4 Auto flash

Use this mode for ordinary photography. The flash fires as required by the shooting conditions.

If pressing the shutter button while the flash is charging, the picture will be taken without the flash.



# Red-eve reduction

Use this mode to guarantee that the subject's eyes appear normal when taking pictures of people in low-light conditions. The flash fires a pre-flash just before the picture is taken and then fires again to take the actual picture. The flash fires as required by the shooting conditions.

If pressing the shutter button while the flash is charging, the picture will be taken without the flash.

# Red-eve effect ◆

When using the flash to take a picture of people in low-light conditions, their eyes sometimes appear red in the picture. This is caused by the light of the flash reflecting off the inside of the eye. Use Red-eye reduction flash to minimize the likelihood of this effect.

Take the following measures to make Red-eve reduction more effective:

Get the subjects to look at the camera.
 Get as close as possible to the subjects.



# **4** Forced flash

Use this mode in backlit scenes, such as a subject against a window or in the shade of a tree, or to get the correct colors when taking a picture under bright lighting. In this mode, the flash fires in bright as well as dark conditions.



52

# \$\$ Slow synchro

This is a flash mode that uses a slow shutter speed. This allows you to take pictures of people at night that clearly show both your subjects and the night time backdrop. To prevent camera shake, always use a tripod.

- Slowest shutter speed
- " V " Night: up to 4 sec.


# Red-eye reduction + Slow synchro

Use this mode for Slow synchro shots with Red-eye reduction.

The image may be overexposed when shooting bright scenes.

To take a picture of a main subject at night with the background brightly lit, use the "&" Night setting in Photography mode (⇒P.40).






Pressing the flash down changes the camera to Suppressed flash mode.


Use this mode for taking pictures using indoor lighting, for shots taken through glass, and for photography in places such as theaters or at indoor sporting events where the distance is too great for the flash to be effective. When you use Suppressed flash, the selected white balance function (⇒P.66) operates so that natural colors are captured along with the ambience of the available light.

- Use a tripod to prevent camera shake when shooting in Suppressed flash mode in the dark condition.
- See P.142 for information on the camera shake warning.


# PHOTOGRAPHY FUNCTIONS CONTINUOUS SHOOTING



Set the Power switch to "a".



- 1 Hold down the "a" button.
- ② Turn the Command dial to select the Continuous shooting mode.
- ③ Release the "• button to confirm your selection.



When setting the Continuous shooting mode (except for "OFF"), the selected mode appears on the screen.

- ■: Top 4-frame continuous shooting
- ♣: Auto bracketing
- **a**: Final 4-frame continuous shooting
- ■: Long-period continuous shooting

# ◆ Notes on using the Continuous shooting modes ◆

- Shooting continues as long as holding the shutter button down. In auto bracketing mode however, just press the shutter button once to shoot 3 frames.
- Number of available frames is limited depending on the available space on the media. When auto bracketing, if there is insufficient space on the media to record 3 frames, no pictures are taken.
- The focus is determined in the first frame and cannot be changed in mid-sequence (excluding Longperiod continuous shooting).
- The exposure is determined in the first frame, however, in Long-period continuous shooting the exposure is adjusted for the scene being shot.
- The speed of continuous shooting varies depending on the shutter speed.
- The speed of continuous shooting does not change with the quality setting.
- The flash cannot be used as the flash mode is set to "3" Suppressed flash.
- For top 4-frame continuous shooting, final 4-frame continuous shooting and pictures taken using auto bracketing, the results are always displayed after you shoot.


# **O** Top 4-frame continuous shooting

Available Photography modes: AUTO, 🗥, 🕦, 🦜, 🛕, 😢, P, S, A, M



This mode shoots up to 4 frames (max. 1.5 frames/sec.). When taking the pictures, the images appear and are recorded.

# Auto bracketing



# Available Photography modes: P, S, A, M

This mode shoots the same image with different exposure settings. Bracketing shoots 3 continuous frames, each with a different exposure setting.


(A) is correctly exposed, (B) is overexposed and (C) is underexposed.

The settings (exposure range) can be changed in the photography menu.

# Auto bracketing settings (3)

±1/3 EV, ±2/3 EV, ±1 EV

- If the underexposed or overexposed frame is outside the camera's control range, the picture is not taken with the specified setting increments.
- Auto bracketing cannot be used in "AUTO", "AN", "O", "T", "A", "C" or "A" mode.




# Changing the setting (exposure range)

Press the "MENU/OK" button to display the menu and change the setting in the "➡" BRACKETING menu option (➡P.70).

# **T**inal 4-frame continuous shooting

Available Photography modes: AUTO, 🧥, 🗣, 🗘, 😢, P, S, A, M



This mode allows you to release the shutter up to 40 times (max. 1.5 frames/sec.) and record the last 4 frames. If you take your finger off the shutter button before 40 shots have been taken, the camera records the final 4 frames shot before you released the shutter button.

If there is insufficient space on the media, the camera records as many of the shots taken just before the shutter button was released as will fit on the media.

- Final 4-frame continuous shooting cannot be used in the "#" Movie mode.
- Only 1 frame can be shot when using the Final 4-frame continuous shooting mode and Self-timer mode together.

Available Photography modes: AUTO, M, N, N, A, &




This mode allows you to take up to 40 continuous shots (max. 1.1 frames/sec.).

- Long-period continuous shooting cannot be used in the "P", "S", "A", "M" and "₽" modes.
- Only 1 frame can be shot when using the Long-period continuous shooting mode and Self-timer mode together.
- Continuous shooting mode and assist window (→P.30) can be used together.

◆ Focusing on a moving subject ◆

If you press the shutter button down halfway to focus on the subject at the starting point (A), the subject may no longer be in focus when it reaches point ® where you want to take the shot. In such situations, focus on point ® beforehand and then lock the focus so that it does not shift.




# ◆ Continuous shooting and flash ◆

When a Continuous shooting mode is selected, the flash mode is forcibly set to "3" Suppressed flash. However, when the mode is changed back to normal photography, the flash setting specified before continuous shooting was selected is restored.


**₹**, ▲, **ℰ**, P, S, A, M

This is useful when checking the shot composition for outdoor scenes.




PHOTOGRAPHY FUNCTIONS

Set the Power switch to "a".



Set the Mode dial to Photography mode.



① Hold down the "" button.

② Press the "DISP/BACK" button.

" $\mathring{\mathbf{r}}$ " appears on the screen and the subject is displayed brightly.

To cancel increased brightness:

① Hold down the "" button.

2 Press the "DISP/BACK" button again.

This function is automatically canceled after each

♦ When this function is active, it will increase the amount of speckling in images on the screen. This is normal and does not affect the photographed image.


This function is purely for checking the composition of your shot. It does not increase the brightness of the image.

Even if you increase the brightness in low-light conditions, you cannot check the subject.

The color tones may vary depending on the subjects.

# PHOTOGRAPHY FUNCTIONS PHOTOGRAPHY INFORMATION

This function displays the histogram for an image and allows the brightness distribution during shooting to be checked. This function can also be used to check the current photography settings.




- ① Set the Power switch to "a".
- 2 Set the Mode dial to Photography mode.



Press the "INFO" button to display the histogram. Press the "INFO" button again to display the current settinas.




Histogram (Quick display)



- The histogram that appears on the screen during shooting is a quick display. The shape of the graph may differ from that shown during playback. Play back the image to check the histogram after shooting (→P.74).
- A quick display of the brightness distribution is shown when taking a picture. The exposure cannot be checked.
- Information for the photography settings does not appear in "AUTO", "AN", "O", "D", "A" and "&" mode.


# F PHOTO MODE PHOTOGRAPHY

# **QUALITY MODE (NUMBER OF RECORDED PIXELS)**




- ① Set the Power switch to "a".
- 2 Set the Mode dial to Photography mode.
- 3 Press the "F" button to display the menu on the

The quality setting is retained even when the camera is off or the mode setting is changed.



- ① Press "▲" or "▼" to select " " QUALITY.
- ② Press "▶".



- ① Press "▲" or "▼" to change the setting.
- 2 Press the "MENU/OK" button to confirm the setting.

- The numbers to the right of setting show the number of available frames.
- ♦ When changing the quality setting, the number of available

   When changing the quality setting, the number of available

   Property of the property of the number of available.

   Property of the number of the number of available.

   Property of the number of the number of available.

   Property of the number of the number of available.


   Property of the number of th frames also changes (⇒P.27).

### **ISO SENSITIVITY** F PHOTO MODE PHOTOGRAPHY


**QUALITY MODE (NUMBER OF RECORDED PIXELS)** 

Quality mode	Sample uses
9M F (3488 × 2616)	Printing at up to 10R (25.4 × 30.5 cm) / A3 size For better quality, select "SM F"
9M N (3488 × 2616)	
3:2 (3696 × 2464)	To Social quality, soloci 🗷 l
5M (2592 × 1944)	Printing at up to 10R (25.4 × 30.5 cm) / A4 size
3M (2048 × 1536)	Printing at up to 6R (15.2 × 20.3 cm) / A5 size
2M (1600 × 1200)	Printing at up to 4R (10.2 × 15.2 cm) / A6 size
03M (640 × 480)	To use for e-mail or web site

# ◆ Area shot and quality setting ◆











Normal shooting provides an aspect ratio of 4:3 and "32" shooting provides an aspect ratio of 3:2 (same aspect ratio as 35 mm film and post card).




- ② Set the Mode dial to "AUTO", "♥", "▲", "♥", "P", "S". "A" or "M".
- ③ Press the "F" button to display the menu on the screen.
- light, only "AUTO" can be selected in the "ID" (sensitivity)
- In "♣" Movie mode, do not set the "♠" (sensitivity) setting.

Sensitivity is retained even when the camera is off or the mode setting is changed.



- ① Press "▲" or "▼" to select "™" (sensitivity).
- ② Press "▶".



- ① Press "▲" or "▼" to change the setting.
- 2 Press the "MENU/OK" button to confirm the setting.
- Settings

AUTO /80/100/200/400/800/1600

- Although higher sensitivity settings will allow you to take pictures in darker locations, they will also increase the amount of speckling in your images. Streaking may also be visible in shots of scenes such as the night sky.
- Choose the sensitivity setting that best suits the conditions. ♦ When selecting "P", "S", "A" or "M", AUTO cannot be selected in the "ISD" (sensitivity) setting.

When selecting "AUTO" as the sensitivity setting, the camera selects the best sensitivity setting for the subject's brightness.



When the sensitivity is set to "80", "100", "200", "400", "800" or "1600", the selected sensitivity setting appears on the screen.


- ① Set the Power switch to "a".
- ② Set the Mode dial to Photography mode.
- 3 Press the "F" button to display the menu on the

¶ In "\mathbb{#}" Movie mode, do not set the "\mathbb{\pi}" FinePix COLOR. settina.

The FinePix COLOR setting is retained even when the camera is off or the mode setting is changed.

( : 9M N OTUA: DE FinePix PHOTO MODE

- ① Press "A" or "▼" to select "II" FinePix COLOR.
- ② Press "▶".



- ① Press "▲" or "▼" to change the setting.
- 2 Press the "MENU/OK" button to confirm the setting.
- **F-CHROME** may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with some subjects

   F-CHROME may have little visible effect with subjects

   F-CHROME may have or the scene being shot. You may not be able to see any difference on the screen.
- Because the effects on the image differ depending on the scene being shot in F-CHROME mode, take pictures in F-STANDARD mode as well as this mode. Note that you may not be able to see any difference on the screen.
- For shots taken in F-CHROME mode or F-B&W mode, automatic quality adjustment will be suppressed on Exif Print compliant printers.

F-STANDARD The contrast and color saturation are set to standard. Use this mode for normal photographics of the contrast and color saturation are set to standard.	
F-CHROME	The contrast and color saturation are set to high. This feature is effective for taking more vivid shots of subjects such as scenery (blue sky and greenery) and flowers.
F-B&W	This setting converts the colors in the photographed image to black and white.


0

When setting F-CHROME or F-B&W, the icon appears on the screen.


F-CHROME: CF F-B&W: **₫**₽

- 1) Press the "MENU/OK" button to display the menu on the screen.
- ② Press "▲" or "▼" to select the menu item.


When the top or bottom of the menu item is selected, press "A" or "▼" to change the page.



Press "▶".




- ① Press "▲" or "▼" to change the setting.
- 2 Press the "MENU/OK" button to confirm the setting.



When the setting is enabled, an icon appears in the top-left corner of the screen.

The settings available in the menu screen vary depending on the Photography mode.

- 1) Press the "MENU/OK" button to display the menu on the monitor.
- ② Press "◀" to move to page number.
- ③ Press "▲" or "▼" to select the page.



1) Press ">" to move to menu item.

② Press "▲" or "▼" to select the menu item.

# **Self-timer**

⇒P.65

Use this setting for taking pictures such as group shots where the photographer is included in the shot.

### W White balance

⇒P.66

Change this setting to suit for the surroundings and lighting.

# ☐ High-speed shooting ⇒P.67

Use this setting to reduce the time required for focusina.

# AF mode

⇒P.68

Set the focusing method.

# Flash brightness adjustment ⇒P.69

Change this setting to adjust the amount of light emitted by the flash to suit the photography conditions or to achieve a desired effect.

# Sharpness

⇒P.69

Use this setting to soften or emphasize outlines or to adjust the quality of the image.

### Saturation

⇒P.70

Use this setting to adjust the lightness of color.

### (Contrast

⇒P.70

Use this setting to adjust the contrast.

# Bracketing

⇒P.70

Use this setting to photograph the same image with different exposure settings.

### ■ Multiple exposure ⇒P.71

Multiple exposure provides a way of overlaying images on top of each other to give a final

### External flash ⇒P.72

Select the external flash setting to use an external flash.

Available Photography modes: AUTO, 🗥, 🕦, 🗣, 🗘, 😉, P, S, A, M

OFF ৩ 🛭 9M N 6  $\begin{bmatrix} + \end{bmatrix}$ AUT0

The self-timer is used in situations where the photographer is included in the shot.

When selecting the self-timer setting, the self-timer icon appears on the screen.


- ి: The picture is taken after 10 seconds.
- : The picture is taken after 2 seconds.

Any of the following cancels the self-timer setting:


- Completing the shooting
- · Changing the Mode dial setting
- Setting the camera to Playback mode
- . Turning the camera off

# ◆ Using the 2-second self-timer ◆

This is useful when you have the camera on a tripod and you want to prevent camera shake.



- 1) Position the AF frame over the subject.
- 2 Press the shutter button down halfway to focus on the subject.
- 3 Without releasing the shutter button, press the button all the way down (fully pressed) to start the self-timer.
- The AF/AE lock can be used (⇒P.28).
- Take care not to stand in front of the lens when pressing the shutter button as this can prevent the correct focus or brightness (exposure) from being achieved.



The self-timer lamp lights and then starts blinking until the picture is taken.

# ■ Self-timer lamp display

Ö	Lit for 5 seconds ➡ Blinking for 5 seconds
(3)	Blinking for 2 seconds

To stop the self-timer, once it has started running, press the "DISP/BACK" button.



time remaining until the picture is taken.

Self-timer mode is canceled after each shot.

A countdown appears on the screen indicating the

65

# **WE WHITE BALANCE (SELECTING THE LIGHT SOURCE)**

Available Photography modes: P, S, A, M



Change the white balance setting to suit for the surroundings and lighting.

In "AUTO" mode, the correct white balance may not be achieved for subjects such as close-ups of people's faces and pictures taken under a special light source. Select the correct white balance for the light source. See P.151 for more information on the white balance.

AUTO: Automatic adjustment (shooting to show the ambience of the light source)

Ei: Custom white balance type 1 Custom white balance type 2

Shooting outdoors in good weather

🟝: Shooting in shade

岩: Shooting under "Daylight" fluorescent


Shooting under "Warm White" fluorescent lamps

端: Shooting under "Cool White" fluorescent lamps

A: Shooting in incandescent light

\* When the flash fires, the white balance setting (excluding custom white balance) for the flash is used. Consequently, to achieve a particular effect, the flash mode should be set to Suppressed flash (→P.53).


The color tones may vary depending on the shooting conditions (light source, etc.).



### **Custom white balance**

Use this setting to set the white balance for the ambient natural or artificial lighting in images. Use this setting to achieve special effects also.


- ① Select custom white balance "" or "".
- 2 Press the "MENU/OK" button.



Hold a piece of white paper under the light source for setting the white balance, so that it fills the entire screen. Then press the shutter button to set the white balance.

The white balance setting does not affect the image shown


To use the white balance set previously, press the "MENU/OK" button without pressing the shutter



When the correct exposure is measured. "COMPLETED!" appears.

Press the "MENU/OK" button to confirm the setting.

- reset. This setting is retained even if the batteries are removed
- Adjust the custom white balance again when changing the sensitivity setting.
- After taking the picture, check the color (white balance) setting for the image.
- Set "IMAGE DISP." to "1.5 SEC", "3 SEC" or "CONT" in the "SET-UP" menu (⇒P.101).
- Set the Power switch to "▶" (⇒P.31).




When [OVER] or [UNDER] appears, the white balance was not measured at the correct exposure. Set the exposure compensation again, using a negative value (-) when [OVER] appears and a positive value (+) when [UNDER] appears.

### ♠ Example ◆

You can change the white balance for a photographed image by using colored paper instead of white

# I HIGH-SPEED SHOOTING

Available Photography modes: AUTO, AN, O, D, A, C, P, S, A, M



High-speed shooting mode reduces the time required for focusing when pressing the shutter button down halfway.


# Focal range

Wide-angle: approx. 2 m (6.6 ft.) to infinity Telephoto: approx. 4 m (13.1 ft.) to infinity


- ♦ When this function is active, higher sensitivity settings will

   The property of the increase the amount of speckling in your images. This is normal and does not affect the photographed image.
- When taking pictures while the HIGH-SPEED SHOOTING mode is set to "ON", the batteries will run down more quickly.

### AF MODE Available Photography modes: P, S, A,



The AF mode can only be selected when the focus mode is S-AF (⇒P.23).



# **■ CENTER**

The camera focuses on the center of the screen. Use this setting when taking pictures using AF/AE lock (⇒P.28).



### **⊞** MULTI

Press the shutter button down halfway. The camera recognizes any strongly contrasting subject near the center of the screen and displays the AF frame over the subject in focus.

When taking pictures in Macro mode, the camera focuses on the center of the screen.




# For a high-contrast subject in the center of the screen

Press the shutter button down halfway. The AF frame appears positioned on the high-contrast subject near the center of the image.



# When there is no high-contrast subject in the center of the screen


When the camera has difficulty focusing on the subject in "MULTI" mode, set the AF mode to "CENTER" and use AF/AE Lock (⇒P.28).



# 

The camera changes the focusing position on the screen. Use this setting when composing the shot using a tripod and changing the focusing position.

- ① Hold down the "▶●◀" button.
- ② Press "▲", "▼", "◄" or "▶" to move the "∰" (target point) to the focusing position.
- ③ Release the "▶●◀" button.



The AF frame appears in the location to which the target point was moved.


Take the picture in the normal way.

To reposition the AF frame, repeat step 1.

Regardless of the AF frame location, the exposure is always set using the area in the center of the screen. To expose the shot for your main subject, use AE lock.

# **经 FLASH BRIGHTNESS ADJUSTMENT**

# Available Photography modes: P, S, A, M



Use this setting to change the amount of light emitted by the flash to suit the photography conditions or to achieve a desired effect.

### Compensation range:

-2/3 EV to +2/3 EV in approx. 1/3 EV increments (total: 5 levels selectable) See P.151 for information on EVs.

- Depending on the type of subject and the shooting distance. brightness adjustment may have no effect.
- The image may appear dark when setting the shutter speed to higher than 1/1000 sec.

# **S** SHARPNESS

# ③:STD .±1/3 EV □ : OFF - OFF

# Available Photography modes: P, S, A, M

Use this setting to soften or emphasize outlines or to adjust the quality of the image.

HARD: Emphasizes the outlines.

Best for shots of subjects such as buildings or text where sharp images are desirable.

STANDARD: Best for ordinary photography.


Provides edge sharpness that is ideal for most picture taking situations.

SOFT: Softens the outlines.

Best for shots of subjects such as people, where a softer image is desirable.

# **⊗** SATURATION

# Available Photography modes: P, S, A, M



Use this setting to adjust the quality of the image. including making the colors more vivid or toning the colors down.

HIGH: Obtains deep and vivid color. This setting is effective for taking more vivid shots of subjects such as scenery (blue sky and greenery etc.).

STANDARD: The camera determines the correct saturation.

LOW: Obtains soft color. This setting produces beautiful images that retain the natural ambience in low-light conditions.

♣ This setting is disabled when selecting "♠F" F-CHROME or "➡r" F-B&W in the "□" FinePix COLOR setting.

# **O** CONTRAST

CONTRAST

SE :STD

(STD: STD


OI STD

□ :0FF

7 :OFF

.±1/3 EV

# Available Photography modes: P, S, A, M




provides crisp, clear images. STANDARD: The camera determines the correct

SOFT: Lowers the contrast. Bright areas are less likely to be washed out and dark areas are less likely to turn completely black.

♣ This setting is disabled when selecting "♠F" F-CHROME or "ĒF" F-B&W in the "□" FinePix COLOR setting.

# **BRACKETING**


# Available Photography modes: P, S, A, M



Use this setting to photograph the same image with different exposure settings. Bracketing shoots 3 continuous frames, one of which is correctly exposed while the remaining two are underexposed and overexposed respectively by a set amount.

Bracketing settings (3) ±1/3 EV. ±2/3 EV. ±1 EV See P.151 for more information on EVs.

- # If the underexposed or overexposed frame is outside the camera's control range, the picture is not taken with the specified setting increments.
- Flash photography cannot be used.
- This feature always takes 3 shots. However, if there is insufficient space on the media for 3 shots, no picture will be



# Auto bracketing

After setting the exposure for bracketing:

- 1 Hold down the "Q" button.
- 2 Turn the Command dial to select "%".

### ☐ MULTIPLE EXPOSURE

# Available Photography modes: P, S, A, M



Multiple exposure provides a way of overlaying images on top of each other to give a final image that cannot be got through normal photography.

- ♦ When the image is overexposed, use negative compensation

   The image is overexposed. The image is overexposed. The image is overexposed.

   The image is overexposed. The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.

   The image is overexposed.


   The image is overexposed.

   The image is ov in the brightness (exposure compensation) setting to correct the exposure (⇒P.45).
- Only the optical zoom can be used for multiple exposure shots. The digital zoom (⇒P.29) does not function.
- This mode is canceled when changing the Mode dial to "AUTO", "♣\", "♥", "▲", "♥" or "₽", and turning the camera off.
- Continuous shooting and auto bracketing are disabled when MULTI-EXPOSURE is selected.
- You cannot change the photography menu settings and the quality setting during shooting.
- There is no limit on the number of multiple exposures.



A preview screen appears when taking a picture.

- To overlay more images Press "▶".
- To record the image Press the "MENU/OK" button.
- To return to the previous image
- Press "◀".
- To stop without recording any images Press the "DISP/BACK" button.
- A preview image is always shown, regardless of the IMAGE DISPLAY setting (⇒P.101).
- Changing the Photography mode exits multiple exposure mode without recording the images.



From the 2nd shot onwards, the vellow "\endsymbol" icon appears on the screen.

#### USING AN EXTERNAL FLASH

#### Available Photography modes: P, S, A, M


EXTERNAL FLASH SE :STD SI:STD STD:STD ■ ±1/3 EV D: OFF

Select "ON" in this setting when using an external flash unit. Synchronized shutter speeds up to 1/1000 sec. can be used.


- The image may appear dark when the shutter speed is set to speeds higher than 1/1000 sec.
- Set the white balance (→P.66) to "AUTO" or custom white
- 2 Hot shoe
- 1 Close the built-in flash.
- 2 Mount the external flash on the camera's hot shoe and tighten the locking screw.
- If you pop up the built-in flash when the external flash is set to "ON", the built-in flash fires once as a signal for the external flash to fire. The hot shoe and the Synchronizing terminal do not make a signal for flash.

Ordinary external flash units can be used. However, some camera-specific flash units cannot be used.

#### ◆ Using a Synchronizing terminal ◆



Attach the synchronization cord from the external flash to the Synchronizing terminal on the camera by pushing the cord into the terminal securely.




The mode can be set to "P", "S", "A" (⇒P.41, 42, 43) or "M" (⇒P.44), but the use of "A" or "M" is better.

Flash photography cannot be used when Top 4-frame continuous shooting (⇒P.54) or auto bracketing (⇒P.54) is

## ◆ Compatible Flash Units ◆

Flash units that can be used with this camera must meet the following 3 conditions:

- The aperture can be set.
- External flash synchronization can be used.
- •The sensitivity can be set.




\* Illustration is display of the external flash (commercial available).

### External flash settings (for flashes with automatic flash control)

For external flash, refer to the user's manual for the flash and specify the settings as described below.

- Select external flash mode (TTL mode cannot be
- Match the settings to the camera aperture setting. Set the flash for the aperture setting measured by
- Match the sensitivity setting (⇒P.61) to the setting on the camera.

#### When the white balance is incorrect Adjust the white balance to match the external flash. In "III" WHITE BALANCE in the photography menu Ęi, (⇒P.66), select "₽. ₽" custom white balance. \* Press the "MENU/OK" button. E 岩




MENU /OK

Hold a sheet of white paper so that it fills the entire


When pressing the shutter button, the flash fires and the white balance is set.

- After taking the picture, check the color (white balance) setting for the image.
- Set "IMAGE DISP." to "1.5 SEC". "3 SEC" or "CONT" in the SET-UP menu (⇒P.101).
- Set the Power switch to "▶" (⇒P.31).




When [OVER] or [UNDER] appears, the white balance was not measured at the correct exposure. Set the exposure compensation again, using a negative value (-) when [OVER] appears and a positive value (+) when [UNDER] appears.

## PLAYBACK FUNCTIONS PLAYBACK INFORMATION



Use this function to check the photography information. Hold down the "INFO" button to check the information.

This function cannot be used during multi-frame playback





Highlight warning: When the image is overexposed, areas where white blooming has occurred flash

The Highlight warnings displayed during playback and during photographed image checking may differ.

### - ♦ Histograms ♦


A histogram is a chart showing the distribution of brightness in an image (horizontal axis: brightness; vertical axis: pixels).

- ① Optimal exposure: There is an ample distribution of pixels overall with a peak in the middle range.
- 2 Overexposed: The number of highlight pixels is high with the distribution sloping upwards to the
- 3 Underexposed: The number of shadow pixels is high with the distribution sloping upwards to the




The shape of the graph will vary depending on the subject.

## PLAYBACK MENU **ERASING SINGLE / ALL FRAMES**




- Set the Power switch to "▶".
- 2 Press the "MENU/OK" button to display the menu on the screen.

Erased frames (files) cannot be recovered. Back up important frames (files) onto your PC or another



- ① Press "▲" or "▼" to select " " ERASE.
- ② Press "▶".




- ① Press "▲" or "▼" to select "FRAME" or "ALL
- 2 Press the "MENU/OK" button.

Erases only the selected frame (file).

#### **ALL FRAMES**

Erases all unprotected frames (files). Back up important frames (files) onto your PC or another media.

"DPOF SPECIFIED. ERASE OK?" appears when erasing a frame (file) with DPOF setting.




#### FRAME

- ① Press "◀" or "▶" to select the erasing frame
- 2 Press the "MENU/OK" button to erase the currently displayed frame (file).

To erase another frame (file), repeat steps ① and

When erasing frames (files) is completed, press the "DISP/BACK" button.

- Pressing the "MENU/OK" button repeatedly erases consecutive frames (files). Take care not to erase a frame
- Protected frames (files) cannot be erased. Unprotect the frames (files) before erasing them (>P.84).




#### **ALL FRAMES**

Pressing the "MENU/OK" button erases all the frames (files).

Protected frames (files) cannot be erased. Unprotect the frames (files) before erasing them (⇒P.84).

◆ To stop the procedure midway ◆




Press the "DISP/BACK" button to cancel erasing of all the frames (files). Some unprotected frames (files) will be left unerased.

Even if you stop the procedure immediately, some frames (files) will be erased.

MENU /OK


Use this mode to rotate an image photographed with IS-1.

- ① Set the Power switch to "▶".
- 2 Press the "MENU/OK" button to display the menu on the screen.



- ① Press "▲" or "▼" to select "②" IMAGE ROTATE.
- ② Press "▶".

 ♦ When [PROTECTED FRAME] appears, unprotect the frame (⇒P.84).



- ① Press "▲" or "▼" to rotate and display the image.
- 2 Press "MENU/OK" button to confirm your selection. Press the "DISP/BACK" button to cancel rotating the image.

An image can be rotated when playing back using IS-1 and FinePixViewer (included).

♦ Images that can be rotated ◆

You may not be able to rotate images that were shot with a camera other than the IS-1.

## F PHOTO MODE PLAYBACK HOW TO SPECIFY PRINT OPTIONS (DPOF)



DPOF stands for Digital Print Order Format and refers to a format that is used for recording printing specifications for images shot using a digital camera on media such as an xD-Picture Card and CF/Microdrive. The recorded specifications include information on which frames are to be printed.

This section gives a detailed description of how to order your prints with the IS-1.

- \* Some printers do not support date and time imprinting or specification of the number of
- \* The warnings shown below may appear while specifying the prints.

"DPOF SPECIFIED. ERASE OK?"

"DPOF SPECIFIED. ERASE ALL OK?" (⇒P.75)

When erasing the image, the DPOF setting for that image is deleted at the same time.


"RESET DPOF OK ?" (⇒P.79)

When inserting a media that contains images specified for printing on by another camera, those print specifications are all reset and replaced by the new print specifications.

[DPOF FILE ERROR] (⇒P.143)


Up to 999 images can be specified on the same media.

## F PHOTO MODE PLAYBACK SPECIFYING DPOF SETTINGS EASILY




- Set the Power switch to "▶".
- ② Press the "F" button.

"WITH DATE" is selected at factory default setting. See P.81 for information on selecting "WITH DATE" or "WITHOUT DATE".



Press the "F" button.

If there were previous DPOF settings, perform step




- ① Press "◀" or "▶" to display the frame (file) for specifying DPOF settings.
- ② Press "▲" or "▼" to set a value up to 99 as the number of copies of the frame (file) to be printed. For frames (files) that you do not want printed, set the number of prints to 0 (zero).

To specify more DPOF settings, repeat steps ① and 2.

- Prints of up to 999 image frames (files) can be ordered on the same media.
- DPOF settings cannot be specified for movie and CCD-RAW. Images photographed with a camera other than IS-1 may not be specified DPOF settings.

Pressing the "DISP/BACK" button while choosing settings will cancel all current settings. If there were previous DPOF settings, only the modifications are canceled

♦ When DPOF settings were specified on another camera ◆




When the data includes a frame (file) with DPOF settings that were specified on another camera, "RESET DPOF OK?" appears.

Pressing the "MENU/OK" button erases all of the DPOF settings already specified for each frame (file). Specify the DPOF setting for each frame (file) again.

Press the "DISP/BACK" button to leave the previous settings unchanged.


F PHOTO MODE PLAYBACK

#### SPECIFYING DPOF SETTINGS EASILY



Always press the "MENU/OK" button after the settings are completed.

Pressing the "DISP/BACK" button cancels those settings.




- ①Press the "F" button.
- ②Press "◀" or "▶" to select the frame (file) with the DPOF setting you want to cancel.
- 3 Set the number of prints to 0 (zero).

To cancel the DPOF setting for another frame (file), repeat steps 2 and 3.


Press the "MENU/OK" button to complete the settings.

DPOF ALL RESET (⇒P.83).

## PLAYBACK MENU DPOF SET FRAME



- ① Set the Power switch to "▶".
- ② Press the "MENU/OK" button to display the menu on the screen.




- ① Press "▲" or "▼" to select "▶" PRINT ORDER (DPOF).
- ② Press "▶".




"

appears on the screen during playback when the image has specified DPOF settings."



- ① Press "▲" or "▼" to select "WITH DATE" or "WITHOUT DATE". Selecting "WITH DATE" will cause the date to be imprinted on your prints.
- 2 Press the "MENU/OK" button.
- When selecting the "WITH DATE" setting, the date is imprinted on your shots using the Print Service or a DPOFcompatible printer (depending on the printer specifications, the date may not be printed in some cases).



- ① Press "◀" or "▶" to display the frame (file) for specifying DPOF settings.
- ② Press "▲" or "▼" to set a value up to 99 as the number of copies of the frame (file) to be printed. For frames (files) that you do not want printed. set the number of prints to 0 (zero).

To specify more DPOF settings, repeat steps ① and 2.


- Prints of up to 999 image frames (files) can be ordered on the same media.
- # "G" appears on the screen when selecting "WITH DATE".
- DPOF settings cannot be specified for movie and CCD-RAW.
- Images photographed with a camera other than IS-1 may not be specified DPOF settings.

## MENU /OK PRINT ORDER (DPOF) □ DPOF:00009 Total number of prints Setting for that frame **⇒** 01 SHEETS STEPRAME OKSET

#### Always press the "MENU/OK" button after the settings are completed.

Pressing the "DISP/BACK" button cancels those settings.

Pressing the "DISP/BACK" button while choosing settings will cancel all current settings. If there were previous DPOF settings, only the modifications are canceled.



Total number of prints appears on the screen. Press the "MFNU/OK" button.

## ◆ Canceling DPOF setting ◆

To cancel the DPOF setting for a specified frame (file):


- ①Press the "F" button.
- ②Press "◀" or "▶" to select the frame (file) with the DPOF setting you want to cancel.
- 3 Set the number of prints to 0 (zero).

To cancel the DPOF setting for another frame (file), repeat steps ② and ③.


Press the "MENU/OK" button to complete the settings.

DPOF ALL RESET (⇒P.83).


#### **P** DPOF ALL RESET PLAYBACK MENU




- Set the Power switch to "▶".
- 2 Press the "MENU/OK" button to display the menu on the screen.




- ① Press "A" or "▼" to select "A" PRINT ORDER (DPOF).
- ② Press "▶".



"A" appears on the screen during playback when the image has specified DPOF settings.




- Press "▲" or "▼" to select "RESET ALL".
- 2 Press the "MENU/OK" button.



A message appears on the screen.


To reset all the DPOF settings, press the "MFNU/OK" button.



- Set the Power switch to "▶".
- 2 Press the "MENU/OK" button to display the menu on the screen.

Protection is a setting that prevents frames (files) from being accidentally erased. However, the "FORMAT" function erases all the frames (files), including protected frames (files) (⇒P.104).

- 1 e∄ SET
- ① Press "▲" or "▼" to select " □ " PROTECT.
- ② Press "▶".



- ① Press "▲" or "▼" to select "FRAME", "SET ALL" or "RESET ALL".
- 2 Press the "MENU/OK" button to confirm your selection.

#### **FRAME**


Protects or unprotects only the selected frame (file).

#### **SET ALL**

Protects all the frames (files).

#### RESET ALL


Removes the protection from all the frames (files).



#### **FRAME SET**


- ① Press "◀" or "▶" to select the protecting frame
- 2 Press the "MENU/OK" button to protect the currently displayed frame (file).

To protect another frame (file), repeat steps ① and 2. When protecting frames (files) is completed, press the "DISP/BACK" button.




#### FRAME RESET

- ① Press "◀" or "▶" to select the protected frame
- 2 Press the "MENU/OK" button to unprotect the displayed frame (file).



#### **SET ALL**

Press the "MENU/OK" button to protect all the frames (files).



#### **RESET ALL**

Press the "MENU/OK" button to unprotect all the frames (files).


◆ To stop the procedure midway ◆




If the images are very large, protecting or unprotecting all the frames (files) may take some

If you want to take a picture or record a movie during the procedure, press the "DISP/BACK" button. To return to protecting or unprotecting all the frames (files), see the procedure on P.84 and begin at step


## 



- ① Set the Power switch to "▶".
- ② Press the "MENU/OK" button to display the menu on the screen.



- ① Press "▲" or "▼" to select " " PLAYBACK.
- ② Press "▶".




- ① Press "▲" or "▼" to select the playback interval and the type of image transition.
- ② Press the "MENU/OK" button. The image frames are advanced and played back.

Press "◀" or "▶" to advance or go back through the images when selecting "NORMAL" and "FADE-IN".

To interrupt automatic playback, press "MENU/OK" button.

- Press the "DISP/BACK" button once during playback to display on-screen help.
- The Auto power off function does not operate during playback.
- Movie starts automatically. When the movie ends, the playback function moves it on.

## PLAYBACK MENU RECORDING VOICE MEMOS



Voice memos of up to 30 seconds can be added to still images.

#### Audio recording format


WAVE (⇒P.151)

PCM recording format

Audio file size

Approx. 480 KB (for a 30-second voice memo)


- ① Set the Power switch to "▶".
- ② Press "◀" or "▶" to select the image to add a voice memo.




- ① Press the "MENU/OK" button to display the menu on the screen.
- ② Press "▲" or "▼" to select "☑" VOICE MEMO.




When [PROTECTED FRAME] appears, unprotect the frame (⇒P.84).



Press "▶".



"REC STANDBY" appears on the screen. Press the "MENU/OK" button to begin recording.



## PLAYBACK MENU RECORDING VOICE MEMOS

RECORDING

| 28s |
| Blinking red |
| Remaining time |

The remaining recording time appears during recording.

To end your comment during recording, press the "MENU/OK" button.

FINISH

OKS REC GACKS RE-REC

MENU DISP BACK

After 30 seconds of recording, "FINISH" appears on the screen.


#### To finish

Press the "MENU/OK" button.

#### To re-record your comment

Press the "DISP/BACK" button.


♦ When the image already has a voice memo ♦ -



When you select an image that already has a voice memo, a screen appears in which you can select whether to re-record the voice memo.


♦ When [PROTECTED FRAME] appears, unprotect the frame (→P.84).

## PLAYING BACK VOICE MEMOS



- ① Set the Power switch to "▶".
- ② Press "◀" or "▶" to select an image file that has a voice memo.
- √ Voice memos cannot be played back using multi-frame playback. Press the "DISP/BACK" button to select singleframe playback.
- "

  " appears on the screen when an image file with a voice memo is selected.



- ① Press "▼" to play the voice memo.
- ② The playback time appears on the screen along with a progress bar.
- ♦ When the sound is difficult to hear, adjust the volume (⇒P.90, 102)




#### ■ Playing back voice memos

	Control	Description
Playback	(MSHA)	Playback begins. The voice memo stops when playback ends.
Pause/Resume	(MENU) (OK)	Pauses the voice memo during playback. Press "▼" again to resume playback.
Stop		Stops playback.  * Press "•" or "•" while voice memo playback is stopped to go back to the previous file or advance to the next file respectively.
Fast forward/ Rewind	(CO)	Press "◀" or "▶" during playback to skip forwards or backwards through the voice memo.  * These buttons do not function while playback is paused.


#### ◆ Playing voice memo files ◆ -

You may not be able to play back some voice memo files recorded on other cameras.






Press the "MENU/OK" button while playing back voice memo. The voice memo is paused during playback.




Press "◀" or "▶" to adjust the volume.




Press the "MENU/OK" button to confirm the new setting. Camera starts to play back the voice memo.

- ① Set the Power switch to "▶".
- ② Press "◀" or "▶" to select the trimming frame (file).



- ① Press the "MENU/OK" button to display the menu on the screen.
- ② Press "▲" or "▼" to select "□ " TRIMMING.




Press "▶".



Press "▲" or "▼" to zoom in or out on an image. A zoom bar appears on the screen.

Press the "DISP/BACK" button to return to single-frame playback.

A saved image size varies depending on the zoom scale. For 0.3M, the "OK YES" option appears in vellow.





- ① Press "◀" or "▶" to select to "PANNING".
- ② Press "A". "▼". "◄" or "▶" to display another part of the image.

The current displayed image appears on the navigation screen.

3 Press the "MENU/OK" button to trim the image.

Navigation screen

Press the "DISP/BACK" button to return to the zoom setting.

→ OSEM REC OK? OK REC BACK CANCEL MENU

Check the saved image size and press the "MENU/OK" button. The trimmed image is added as a separate file in the final frame.


#### ■ Image sizes

	Sample uses	
5M	Printing at up to 10R (25.4 × 30.5 cm) / A4 size	
ЗМ	Printing at up to 6R (15.2 × 20.3 cm) / A5 size	
2M	Printing at up to 4R (10.2 × 15.2 cm) / A6 size	
03M	To use for e-mail or web site	

When "32" quality setting is selected, the image is trimmed to normal size (4:3 aspect ratio).

## ♦ Images that can be trimmed ◆

You may not be able to trim images that were shot with a camera other than the IS-1.



Set the Mode dial to "#".

Use "" Movie mode to record movies with sound.

Specifications

Motion JPEG (⇒P.151) with monaural sound


- Quality selection method
- 640 (640 × 480 pixels) 320 (320 × 240 pixels)
- Frame rate (⇒P.151)

30 frames per second (fixed)

See P.95 for information on changing the quality mode.


Because a movie is recorded onto the media as it is saved, it cannot be recorded correctly if the camera suddenly loses power (if you open the battery cover or slot cover, or disconnect the AC power adapter).

It may not be possible to playback your movies on other cameras.



The available recording time and "STANDBY" appear on the screen.

Because sound is recorded concurrently with the images, make sure that you do not cover the microphone with a finger, etc. (⇒P.10).



Turn the zoom ring to zoom in or out during shooting. Refocus on the subject after zooming.

 Optical zoom focal length (35 mm camera equivalent)

Approx. 28 mm to 300 mm Max. zoom scale: 10.7×

Focal range

Wide-angle: approx. 40 cm (1.3 ft.) to infinity Telephoto: approx. 2 m (6.6 ft.) to infinity



Press the shutter button down fully to start

- The brightness and color of the screen shown during movie recording may differ from those shown before recording
- There is no need to hold down the shutter button.
- The noises made by camera operations such as focusing and aperture control may be recorded during movie shooting.


During shooting, the exposure and white balance are adjusted to the scene being shot.



During recording, "

REC" appears in the bottomleft corner of the screen and a counter that shows the remaining time appears in the top-right corner

- # If the brightness of the subject changes during movie recording, the sound of lens operation may be recorded.
- Some wind noise may be recorded in shots taken outdoors. When the remaining time runs out, recording ends and the movie is saved onto the media.



Press the shutter button down halfway during recording, the recoding ends.

If recording is stopped immediately after it begins, 1 second of the movie is recorded onto the media

### Available recording times

#### ■ Recording times per media

\* These figures are the available recording times using a new media formatted on the camera. The actual recording times will vary depending on the free space available on the media.

Media capacity		Quality	
		640 (30 frames per second)	(30 frames per second)
	16 MB	13 sec.	26 sec.
	32 MB	27 sec.	54 sec.
	64 MB	55 sec.	109 sec.
xD-Picture Card	128 MB	111 sec.	219 sec.
	256 MB	223 sec.	7.3 min.
	512 MB	7.4 min.	14.6 min.
	1 GB	14.9 min.	29.3 min.
	2 GB	29.8 min.	58.6 min.
Microdrive	340 MB	5.1 min.	10.0 min.
wicroarive	1 GB	15.3 min.	30.1 min.


#### Notes on using Microdrives for movie shooting

If the camera's internal temperature rises too high, movie shooting stops to protect the media. Because Microdrives tend to generate heat (for mechanical reasons), long periods of continuous movie shooting may not be possible when the ambient temperature is high. As a general guide to shooting times, you can shoot movies for around 20 minutes at an ambient temperature of +30°C/+86°F and for around 30 minutes at +25°C/+77°F.



94





- ① If the camera's internal temperature rises during shooting, "MICRODRIVE IS OVERHEATING. MOVIE RECORDING WILL AUTOMATICALLY STOP SOON" appears.
- 2 This then changes to "PLEASE STOP MOVIE RECORDING!". If you continue shooting, the movie is saved and the camera shuts down.
- ③ If you then immediately try to start shooting again, "MOVIE RECORDING HAS STOPPED CANNOT RESTART A WHILE" appears and you cannot start shooting. Turn the camera off and do not use it for roughly 30 minutes until it has cooled down. Note that you can still shoot still images during this period.
- Because the Microdrive is hot just after a movie is recorded, do not remove the Microdrive immediately.


- ① Set the Mode dial to "#".
- 2 Press the "F" button to display the menu on the screen.

¶ In "♣" Movie mode, do not set the "☒" (sensitivity) setting. In "♣" Movie mode, do not set the "□ " FinePix COLOR

The quality setting is retained even when the camera is off or the mode setting is changed.

MENU /OK € 640 ▶ FinePix PHOTO MODE

Press "▶".



- ① Press "▲" or "▼" to change the setting.
- 2 Press the "MENU/OK" button to confirm the

## Quality settings in Movie mode

Quality mode	Sample uses
640 (640 × 480)	For better quality
320 (320 × 240)	To record longer movies


When used media is 4GB or more, a movie up to 60 minutes long (at the "640" setting) or 120 minutes long (at the "320" setting) can be recorded.

Visit website for information on available Microdrive / CompactFlash card:

http://www.fujifilm.com/products/digital/


**Advanced Features** 

## PLAYBACK MODE PLAYING BACK MOVIES



- Set the Power switch to "▶".
- ② Press "◀" or "▶" to select the movie file.
- Movies cannot be played back using multi-frame playback. Press the "DISP/BACK" button to select single-frame playback.

Indicated by the "₽" icon.



- ① Press "▼" to play the movie.
- 2 The playback time appears on the screen along with a progress bar.
- Uncover the speaker. The sound is difficult to hear.
- When the sound is difficult to hear, adjust the volume (⇒P.97,
- If the subject of the shot is very bright, white vertical streaks or black horizontal streaks may appear in the image during playback. This is normal.

## ■ Playing back movies

△STOP PAUSE


	Control	Description
Playback	(WEND)	Playback begins. Playback stops when the end of the movie is reached.
Pause/Resume	(WENU)	Pauses the movie during playback. Press "♥" again to resume playback.
Stop		Stops playback.  * Press "-d" or "-b" while playback is stopped to go back to the previous file or advance to the next file respectively.
Fast forward/Rewind	WESS)	Press "◀" or "▶" during playback to skip forwards or backwards through the movie.
Skip playback	When paused	Press "◀" or "▶" when the movie is paused, the movie advances or goes back one frame.  Hold down "◀" or "▶" to move through the frames quickly.

## ◆ Playing movie files ◆ -


- You may not be able to play back some movie files recorded on other cameras.
- To play back movie files on a PC, save the movie file on the media to the PC's hard disk and then play back the saved file.

## Adjusting volume of movies


Volume can be adjusted while playing back movies. Adjust the volume to suit your condition.



Press the "MENU/OK" button while playing back movie. The movie is paused during playback.




Press "◀" or "▶" to adjust the volume.




Press the "MENU/OK" button to confirm the new setting. Camera starts to play back the movie.


## **III USING THE SET-UP SCREEN**




Press the "MENU/OK" button to display the menu on the screen.




- ① Press "▲" or "▼" to select "ஊ" SET-UP.
- ② Press "▶".



- ① Press "◀" to move to page number.
- ② Press "▲" or "▼" to select the page.



- ① Press "▶" to move to menu item.
- ② Press "▲" or "▼" to select the menu item.



- ① Press "▶" to select a menu option.


  Press "▲" or "▼" to change the setting. Press "▶" for " ™ " PLAYBACK VOLUME, " ™ " LCD BRIGHTNESS, " ™ " FORMAT, " ™ " DATE/TIME, " ™ " TIME DIFFERENCE, " ™ BACKGROUND COLOR, " ™ " DISCHARGE or " ™ " RESET.
- ② After you have changed the settings, press the "MENU/OK" button to confirm the changes.

100

	Settings	Display	Factory default	Explanation	Page
	☑IMAGE DISP.	CONT/3 SEC/ 1.5 SEC/OFF	1.5 SEC	Specifies whether an image checking screen (photography result) appears after taking a picture. The image appears for a few moments and is then recorded. The color tones in images recorded may differ from actual color. Play back the recorded images to check them.	101
	SHUTTER VOLUME	OFF/1/2/3	2	Sets the volume of the sound emitted when the shutter operates.	-
1	™ BEEP VOLUME	OFF/1/2/3	2	Sets the volume of the tone emitted when the camera controls are used.	-
	IN PLAYBACK VOLUME	SET	7	Sets the volume of playing back movie and voice memo.	102
	FRAME NO.	CONT./RENEW	CONT.	Specifies whether frame numbers are assigned consecutively from previous numbers or begin again.	102
	ERIGHTNESS	SET	0	Sets the screen brightness.	103
	<b>™</b> MEDIA	(xD-Picture Card) (CF/Microdrive)		Sets the media to be used when an <b>xD-Picture Card</b> and a CF/Microdrive are loaded in the camera.	-
	RAW CCD-RAW	OFF/ON	OFF	Sets the image quality to CCD-RAW. Because no image processing is performed on the camera for CCD-RAW images, images must be processed on a PC.	103
2	■EVF/LCD MODE	30fps/60fps	30fps	The screen is displayed smoothly in any situations such as immediately after moving the camera.	-
	AE-LOCK MODE	AE-L1/AE-L2	AE-L1	Selects the AE lock setting.	-
	AF AF ILLUMINATOR	ON/OFF	ON	Specifies whether the AF-assist illuminator is ON or OFF.	-
	MAUTO POWER OFF	5 MIN/2 MIN/OFF	2 MIN	Sets the time of turning camera off when camera is not used.	104
	■ FORMAT	ОК	-	Initializes a media. Select this menu to erase all the frames (files).	104
	DATE/TIME	SET	-	Corrects the date and time.	17
	TIME DIFFERENCE	SET	_	Specifies the time difference settings.	105
3	题言語/LANG.	ENGLISH/FRANCAIS/ DEUTSCH/ESPAÑOL/ ITALIANO/中文/한글	ENGLISH	Specifies the language used for screen display.	19
•	BACKGROUND COLOR	SET	-	Specifies the colors of menu and cursor.	-
				□=: DSC (Mass storage device) mode Provides a simple way to read images from a media and store images onto a media.	126
	MODE	<b>□</b> ⇔/ <b>≜</b> ⇔	ॎ□≒	□ =: PictBridge If a printer that supports PictBridge is available, images can be printed by connecting the camera directly to the PictBridge-compatible printer without using a PC.	122
	₩ VIDEO SYSTEM	NTSC/PAL	-	Specifies whether video output is set to NTSC or PAL.	-
	DISCHARGE	OK	-	Discharges Ni-MH batteries.	139
4	☐ RESET	ОК	-	Resets all the camera settings (other than the DATE/TIME, TIME DIFFERENCE, 言語/LANG., VIDEO SYSTEM and BACKGROUND COLOR) to the factory default values set at shipment. A confirmation message appears when you press "▶". To reset the camera settings, press the "MENU/OK" button again.	-

#### Always turn the camera off when replacing the batteries. Opening the battery cover or disconnecting the AC power adapter without turning the camera off may cause the camera settings to revert to the factory default values set at shipment.

## ☑ IMAGE DISPLAY



Use this setting to specify whether images are displayed after shooting.

CONT: The results are always displayed after you shoot. The display changes between the histogram and photography information each time you press the "INFO" button. Press the "MENU/OK" button to take another picture.

3 SEC/1.5 SEC: The image appears for about 3 or 1.5 seconds and is then recorded.


**OFF:** Images are recorded without being displayed.

- In Long-period continuous shooting, the images do not
- In top 4-frame continuous shooting, auto bracketing and final 4-frame continuous shooting, the images appear for a set time before being recorded even when "OFF" is selected.
- When selecting "CONT", information for the photography settings does not appear in "AUTO", "A", "O", "T", "A" and
- The color tones in images displayed when "3 SEC" or "1.5 SEC" is selected may differ slightly from those in the images actually recorded.

Adjust volume while playing back movie and voice

- ① Press "◀" or "▶" to adjust the volume. The larger the number, the larger the volume is emitted. "0" indicates a sound deadening.
- 2 Press the "MENU/OK" button to confirm the new settina.

### I FRAME NO.




Specifies whether frame numbers are assigned consecutively from previous numbers or begin again.

**CONT.:** Pictures are stored beginning from the highest file number stored on the last media used.

RENEW: Pictures are stored on each media beginning with a file number "0001".

Setting this function to "CONT." makes file management easier as it makes sure that file names are not duplicated when images are downloaded to a PC.


- ♦ When the camera settings are "■ RESET", the frame number setting ("CONT." or "RENEW") is changed to "CONT." and the frame number itself does not return to "0001".
- When the media already contains image files with file numbers higher than the highest file number on the last media, images are stored beginning from the highest file number on the current media.



Check the file number by viewing the image. The last 4 digits of the 7-digit number in the top right corner of the screen are the file numbers, while the first 3 digits show the directory number.

- When changing the media, always turn the camera off before opening the slot cover. Opening the slot cover without turning the camera off may cause the frame number memory to not function.
- File number runs from 0001 to 9999. Once 9999 is exceeded, the directory number changes from 100 to 101. The maximum number is 999-9999.
- photographed on other cameras.
- ♦ When [FRAME NO. FULL] appears, see P.142.

#### ADJUSTING SCREEN BRIGHTNESS



To adjust screen brightness:

- ① Press "◀" or "▶" to adjust the screen brightness.
- 2 Press the "MENU/OK" button to confirm the new settina.

#### RAW CCD-RAW

Setting CCD-RAW to ON disables the signal processing functions (reconstituting the data received from the CCD as an image) performed on the camera. Consequently, this task must be performed on the PC.

Conversion using FinePixViewer also provides a simple way to create TIFF-format images.

Conversion using Hyper-Utility2 also provides you to specify parameters such as image format, tone, white balance, sharpness, saturation, and brightness during file conversion.

\* To rebuild images. FinePixViewer (on the bundled CD-ROM "Software for FinePix CX") or Hyper-Utility2 (on the bundled CD-ROM "Hyper-Utility Software HS-V2") must be installed on your PC.


#### ■ The functions listed below cannot be used in CCD-RAW mode.

During shooting	Digital zoom, Continuous shooting and Quality are unavailable.	
During playback	Playback can be zoomed up to 2.5x, but cropped images cannot be saved.	

When this function is enabled and the camera remains unused for 2 or 5 minutes, it is turned off. Auto power off function prevents leaving the power

playing back and discharging, and when a USB connection is being used.

◆ To restore power to the camera ◆



- 1) Set the Power switch to "OFF".
- ② Set the Power switch back to "♠" or "▶".

#### FORMAT




Initialize (format) the media for use with the camera. Because initializing the media erases all the frames (files), including protected frames (files). Back up important frames (files) onto your PC or another media.

- ① Press "◀" or "▶" to select "OK".
- 2 Pressing the "MENU/OK" button erases all the frames (files) and initializes the media.
- Always check the media to be formatted on the screen before proceeding.
- Formatted media
- "■ FORMAT OK?": xD-Picture Cards
- "

   FORMAT OK?": CF/Microdrives
- or [CARD NOT INITIALIZED] appears, see P.142 for information before formatting the media.
- Do not open the battery cover during formatting, as formatting will be interrupted.

#### TIME DIFFERENCE


This function sets a time difference relative to the date and time currently set. When this setting is enabled, the specified time difference is applied when pictures are taken. Use this function when traveling to destinations in different time zones.



- Press "▶".
- ② Press "▲" or "▼" to change between "♠" HOME and "+" LOCAL.

To set the time difference, select "♣" LOCAL.

- ♠ HOME: Your home time zone
- + LOCAL: Your destination time zone




- Press "◀".
- ② Press "▲" or "▼" to select "TIME DIFFERENCE".

TIME DIFFERENCE → TIME DIFFERENCE LOCATION: -

> TIME DIFFERENCE > S OKSET BACK CANCEL


Press "▶".

5




- ① Press "◀" or "▶" to select +. -. hour and minute. ② Press "▲" or "▼" to correct the setting.
- Available time setting

-23:45 to +23:45 (in 15-minute increments)



Always press the "MENU/OK" button after the settings are completed.



When the Photography mode is selected with world time set. "+" appears on the screen for 3 seconds and the date turns vellow.

Upon returning from a trip, always change the time difference setting back to "A" HOME and then check the date and time again.

#### About FinePixViewer

FinePixViewer is a software application that enables you to save still images, movies and sound files that you have recorded using a digital camera onto your computer, and then organize, modify and print the saved files. This section provides a brief overview of these FinePixViewer functions. Saving camera data on your computer / Viewing and organizing files and folders / Displaying or sorting by year / Modifying image files / Working with batches of images /


Registering your favorite applications / Printing images / And a huge range of other functions

#### About Hyper-Utility2

Hyper-Utility2 is a software application that enables you to save still images, movies and sound files that you have recorded using a digital camera onto your computer, and then organize, modify and print the saved files.

#### ■ Software Configuration

Hyper-Utility2 consists of 2 types of application: the core applications and the helper applications. Supplementing the core applications with the helper applications allows a range of additional functionality to be achieved.



#### ■ View/Organize files and folders

Folders and files such as still images, movies and sound are shown as thumbnails to allow quick and easy checking.

#### **■** Compare 2 images

The Preview split-window mode splits the screen horizontally or vertically to allow 2 images to be compared or checked.

#### ■ Analyze images

A range of image analysis tasks can be performed, including viewing the image histogram (the area can be specified) and displaying warnings for problems such as under- and overexposure.

#### ■ A host of other useful functions

Hyper-Utility2 also offers a range of other functions for utilizing photography data that can be used as required, including functions for printing, creating contact sheet files, displaying slide shows, converting CCD-RAW files and controlling the camera.

#### Adobe RGB (1998)

Hyper-Utility2 includes a function for the saving image files in the Adobe RGB (1998) color space, which is best suited for commercial printing.

## **5.2 INSTALLATION ON A Windows PC (FinePixViewer)**

#### Pre-installation checklist

To run this software, you must have the hardware and software described below. Check your system before you begin the installation.

Operating System*1	Windows 98 SE Windows Millennium Edition (Windows Me) Windows 2000 Professional SP4*2 Windows XP Home Edition SP2*2 Windows XP Professional SP2*2
CPU	200 MHz Pentium or better recommended (800 MHz Pentium III or better recommended for Windows XP)
RAM	64 MB minimum (128 MB minimum for Windows XP), Minimum 256 MB when converting CCD-RAW Data
Hard disk space	Amount required for installation: 450 MB minimum Amount required for operation: 600 MB minimum (When using ImageMixer VCD2 LE for FinePix: 2 GB or better) Minimum 2 GB when converting CCD-RAW Data (must specified in the OS as virtual memory or paging files)
Display	$800 \times 600$ pixels or better, 16-bit color or better (When using ImageMixer VCD2 LE for FinePix: $1024 \times 768$ or better)
Internet connection*3	To use the FinePix Internet Service or mail attachment function: An Internet connection or e-mail transmission software is needed Connection speed: 56 k or better recommended

- \*1 Models with one of the above operating systems pre-installed.
- \*2 When you install the software, login using a system administrator account (e.g. "Administrator").
- \*3 Required to use the FinePix Internet Service. The software can still be installed even if you do not have an Internet connection.

#### ■ Recommended system

Operating System	Windows XP	
CPU	2 GHz Pentium 4 or better recommended	
RAM	512 MB or better recommended	
Hard disk space	2 GB or better	
Display	1024 × 768 pixels or better, Highest (32 bit)	
Internet connection	Broadband (ADSL, FTTH, CATV, etc.)	

#### ♠ Notes ◆

- Connect the camera directly to the PC using the USB cable (mini-B). The software may not operate correctly when you use an extension cable or connect the camera via a USB hub.
- When your PC has more than one USB port, the camera can be connected to either port.
- Push the USB connector fully into the socket to ensure that it is securely connected. The software may not operate correctly if the connection is faulty.
- Additional USB interface board is not guaranteed.
- Windows 95 and Windows NT cannot be used.
- Operation is not guaranteed on home-built PCs or on PCs running updated operating system software.
- When you reinstall or remove FinePixViewer, the Internet menu and your user ID and password for the FinePix Internet Service are deleted from your PC. Click the [Register now] button, enter your registered user ID and password and download the menu again.
- To connect the camera to a computer, select "DSC" as the USB setting.(⇒ P.126)
  To download images on the camera using FinePixViewer, go to "How to use FinePixViewer" in the Help menu and then select Basic Operation > Downloading Images > Saving camera images on a computer (Auto) and refer to the section titled "Using a 'PTP-incompatible camera' (camera with a DSC function)".

#### Do not connect the camera to your PC until the software installation is completed.

Install FinePixViewer as instructed in the Quick start guide.

## Launching the installer manually

- ① Double-click the "My Computer" icon.
- \* Windows XP users should click "My Computer" in the "Start" menu.
- ② Right-click "FINEPIX" (CD-ROM drive) in the "My Computer" window and select "Open".
- 3 Double-click "SETUP" or "SETUP.exe" in the CD-ROM window.





SETUP

SETUP.exe

- \* The way file names are displayed differs as described below depending on your PC settings.
  - File extensions (3-letter suffixes indicating the file type) may be shown or hidden. (e.g. Setup.exe or Setup)
  - Text may be shown normally or all in uppercase (e.g. Setup or SETUP).

#### - ♦ Installing other applications ♦

You may see messages for installing ImageMixer VCD2 LE for FinePix. Install this application as directed by the on-screen instructions.

- 2 Install DirectX as directed by the on-screen instructions and then restart your PC. If the latest version of DirectX is already installed on your PC, this installation is not performed.
  - If the latest version is already installed, this window does not appear.
  - Do not remove the CD-ROM during this procedure.
- 3 After restarting, the USB Video Class Driver would be installed.
  - If the latest version is already installed, this window does not appear.
  - The driver is only installed on Windows XP SP1.



4 After restarting the PC, a message appears stating "Installation of the FinePixViewer has been completed".

## 5.3 INSTALLATION ON A Mac OS X (FinePixViewer)

#### Pre-installation checklist

#### ■ Hardware and software requirements

To run this software, you must have the hardware and software described below. Check your system before you begin the installation.

Compatible Mac*1	Power Macintosh G3*2, PowerBook G3*2, Power Macintosh G4, iMac, iBook, Power Macintosh G4 Cube, or PowerBook G4, Power Macintosh G5 MacBook, MacBook Pro, Mac mini
Operating System	Mac OS X (compatible with version 10.2.8 to 10.4.6)
RAM	192 MB minimum Minimum 256 MB when RAW FILE CONVERTER LE is used
Hard disk space	Amount required for installation: 200 MB minimum Amount required for operation: 400 MB minimum (When using ImageMixer VCD2 LE for FinePix: 2 GB or better) Minimum 2 GB when converting CCD-RAW Data (required on the system disk)
Display	$800\times600$ pixels or better, at least 32,000 colors (When using ImageMixer VCD2 LE for FinePix: 1024 $\times$ 768 or better)
Internet connection*3	To use the FinePix Internet Service or mail attachment function An Internet connection or e-mail transmission software is needed Connection speed: 56 k or better recommended

- \*1 PowerPC. Intel processor loaded
- \*2 Models with a USB port as a standard feature
- \*3 Required to use the FinePix Internet Service. The software can still be installed even if you do not have an Internet connection.

#### Notes •

- Connect the camera directly to the Macintosh using the USB cable (mini-B). The software may not operate correctly if you use an extension cable or connect the camera via a USB hub.
- Push the USB connector fully into the socket to ensure that it is securely connected. The software may not operate correctly if the connection is faulty.
- Additional USB interface board is not guaranteed.
- On Macintosh PCs, allocate at least 400 MB of virtual memory to RAW FILE CONVERTER LE when converting CCD-RAW Data. If other applications will be used at the same time, allocate the additional amount required for those applications also.
- To connect the camera to a computer, select "DSC" as the USB setting (➡ P.126) To download images on the camera using FinePixViewer, go to "How to use FinePixViewer" in the Help menu and then select Basic Operation > Downloading Images > Saving camera images on a computer (Auto) and refer to the section titled "Using a 'PTP-incompatible camera' (camera with a DSC function)".

- Turn your Macintosh on and start up Mac OS X. Do not launch any other applications.
- 2 When the bundled CD-ROM is loaded into the CD-ROM drive, the "FinePix" icon appears. Double-click the "FinePix" icon to open the "FinePix" volume window.



- 2 Double-click on "Installer for MacOSX".
- 4 The Installer setup dialog appears. Click the [Installing FinePixViewer] button.
  - For more information on what is installed, click the [Read Me First] button and [Using FinePixViewer] button.




- The "Authenticate" dialog appears.
- Enter the name and password for the administrator account and then click the [OK] button.\*
- \* The administrator account is the user account used for Mac OS X installation and you can confirm the user account in the Accounts dialog in the System Preferences.
- The "License" dialog appears. Read the agreement carefully and then, if you agree to the terms of the Agreement, click the [Accept] button.
- The "Read me" dialog appears. Click the [Continue] button.

Continued

## **5.3 INSTALLATION ON A Mac OS X (FinePixViewer)**

The "FinePixInstallOSX" window appears.
Click the [Install] button to install FinePixViewer and RAW FILE CONVERTER LE.





- **9** The ImageMixer VCD2 LE for FinePix installer automatically starts up and a window showing the installation progress appears (Installation may take several minutes).
- The "FinePixViewer installation completed" message dialog appears. Then click exit button and close it.
  - When Safari is used as the Web browser, a message may be displayed and the CD-ROM may not be removed. If this happens, click the Safari icon in the Dock to make Safari the active application and then select "Quit Safari" in the "Safari" menu to shut down Safari.
- 11 Launch "Image Capture" from the "Applications" folder.
- 12 Change the Image Capture settings.

  Select "Preferences..." from the "Image Capture' menu.



- 13 Select "Other..." from "When a camera is connected, open".
- 14 Select "FPVBridge" from "FinePixViewer" folder in the "Applications" folder and click the [Open] button.



## 5.4 INSTALLATION ON A Windows PC (Hyper-Utility2)

#### Hardware and software requirements

To run this software, you must have the hardware and software described below. Check your system before you begin the installation.

Compatible PCs	IBM PC/AT or compatible*1
Operating System	Windows 2000 Professional SP4*2 Windows XP Professional SP2*2 Windows XP Home Edition SP2*2
CPU	Pentium 4, Celeron, Pentium M
RAM	256 MB minimum (512 MB or more recommended)
Hard disk space	Amount required for installation: 100 MB minimum Amount required for Hyper-Utility2: Drive for operating system: 1 GB or larger Drive for temporary file creation: 1 GB or larger
Display	1024 $\times$ 768 to 3840 $\times$ 2400 pixels, High Color (16 bit) or higher (1600 $\times$ 1200 pixels, True Color (32 bit) recommended)
Sound functions*3	Speaker and sound card or built-in sound
CD-ROM drive	Required for software installation
IEEE 1394 interface*4	OHCI-compliant IEEE1394 interface card

- \*1 One of the above operating systems preinstalled.
- \*2 When you install the software, log in using a system administrator account (e.g. "Administrator")
- \*3 Sound functions are required to play background music for slide shows.
- \*4 Required to connect the FinePix S2 Pro, FinePix S3 Pro or FinePix S20 Pro and use the Remote Shooting function
- Operation is not guaranteed on home-built computers or on computers running updated operating system software.

## 5.4 INSTALLATION ON A Windows PC (Hyper-Utility2)


### Installing Hyper-Utility2

Switch on your PC and start up Windows. If you have already switched on your PC, restart your PC at this point.

Log on using a computer administrator's account (e.g. "Administrator").

Quit all other active applications until no applications are shown in the taskbar.

#### <Taskbar>



- ① Click the right mouse button on the application icon in the taskbar.
- ② Click "Close" in the menu that appears to quit the application.
- If a "----dll file not found." message appears during installation, there is another application running in the background. Forcibly shut down the application. Refer to your Windows manuals for information on how to forcibly shut down an application.
- 2 Load the enclosed CD-ROM into the CD-ROM drive. The installer starts up automatically.

#### - ♦ Launching the Installer Manually ♦

- ① Double-click the "My Computer" icon. Windows XP users should click "My Computer" in the "Start" menu.
- ② Right-click "HS\_V2" (CD-ROM drive) in the "My Computer" window and select "Open".
- 3 Double-click "SETUP" or "SETUP.EXE" in the CD-ROM window.



SETUP

- $\P$  The way file names are displayed differs as described below depending on your computer settings.
- File extensions (3-letter suffixes indicating the file type) may be shown or hidden. (e.g. Setup.exe or Setup)
- Text may be shown normally or all in uppercase (e.g. Setup or SETUP).

4 Pre-installation checking begins. If the window shown below appears, follow the instructions in the window.







5 The Setup screen appears. Click the [Next] button.



The User License Agreement is displayed.

Read the Agreement carefully and then click
[Yes] if you accept the terms of the Agreement.

Clicking [No] cancels the installation.



## 5.4 INSTALLATION ON A Windows PC (Hyper-Utility2)

**7** The software version is checked. If the window shown at right appears, click the [Next] button to uninstall the software.



- 8 Hyper-Utility2 is then installed.
- **9** In Windows 2000 Professional, if the latest version of Windows Media Player is not installed, install Windows Media Player as directed by the on-screen instructions and then restart the PC.
  - ① In this window, tick the "I have read the Privacy Statement" checkbox and then click the [Next] button.



- ② When you click the [Finish] button, your PC is restarted.
- 10 In Windows 2000 Professional, if the latest version of DirectX is not installed, install DirectX as directed by the on-screen instructions and then restart the PC.



11 The window shown at right appears. Select "Yes, I want to restart my computer now" and then click the [Finish] button.



 $12^{\,\mathrm{This}}$  completes the entire installation procedure. Remove the CD-ROM from the PC and store it in a safe place.

J

## 5.5 INSTALLATION ON A Mac OS X (Hyper-Utility2)

### Hardware and software requirements

To run this software, you must have the hardware and software described below. Check your system before you begin the installation.

Compatible Mac*1	Power Mac G4 (except for PCI Graphic)/G5, PowerBook G4/MacBook, MacBook Pro/Mac mini
Operating System	Mac OS X (compatible with version 10.3 to 10.4.6)*2
RAM	256 MB minimum (512 MB or more recommended)
Hard disk space	Amount required for installation: 100 MB minimum Amount required for operation: 1 GB minimum
Display	1024 $\times$ 768 to 3840 $\times$ 2400 pixels, Thousands color or higher (1600 $\times$ 1200 pixels, Millions Color recommended)
Sound functions*3	Speakers
CD-ROM drive	Required for software installation
Interface*4	FireWire 400 (IEEE 1394) interface

- \*1 PowerPC, Intel processor loaded
- \*2 This software will not run correctly in the Mac OS X Classic environment.
- \*3 Sound functions are required to play background music for slide shows.
- \*4 Required to connect the FinePix S2 Pro, FinePix S3 Pro or FinePix S20 Pro and use the Remote Shooting function.

## Installing Hyper-Utility2

- Switch your Macintosh on and start up Mac OS X. Do not launch any other applications.
- Load the enclosed CD-ROM into the CD-ROM drive. The "HS\_V2" window opens.
- Double-click "Installer".
- A confirmation message appears asking whether you want to continue with the installation. Click the [OK] button.



Enter the administrator name and password. Then click the [OK] button.



The installer setup window appears.



Click the [Continue] button.

## 5.5 INSTALLATION ON A Mac OS X (Hyper-Utility2)

**8** The Software User License Agreement is displayed.

Read the Agreement carefully. If you accept the terms of the Agreement, click the [Agree] button.

Clicking [Disagree] cancels the installation.

9 Click the [OK] button as directed by the onscreen instructions. The software is installed in the HyperUtility folder inside the application folder on the startup volume.

Remove the CD-ROM from the PC and store it in a safe place.





6 Viewing Images


## **6.1 CAMERA CONNECTION**

#### 6.1.1 Using the AC power adapter

Always use a FUJIFILM AC Power Adapter AC-5VX (sold separately) (⇒P.136).

Use the AC power adapter to prevent losing power at inconvenient times, such as when downloading photographed images to your PC. You can take pictures and play back images without worrying about depleting the batteries.

Only connect or disconnect the AC power adapter when the camera is off. Connecting or disconnecting the AC power adapter while the camera is turned on temporarily interrupts the power supply to the camera, so that images or movies being shot at the time are not recorded. Failing to turn the camera off first can also result in damage to the media or malfunctions during PC connection.




Check that the camera is off. Plug the AC power adapter connector into the "DC IN 5V" socket and then plug the AC power adapter into the power outlet.

- The socket-outlet shall be installed near the equipment and shall be easily accessible.
- The shape of the plug and socket-outlet depends on the country of use.
- See P.138 for notes on using the AC power adapter.


Do not connect the AC power adapter to charge the AA-size Ni-MH (nickel-metal hydride) batteries. Use the optional charger (⇒P.136) to charge the Ni-MH batteries.

### 6.1.2 Connecting to a TV



Turn off the camera and TV. Plug the A/V cable (included) into the "A/V OUT" (Audio/Visual output) socket.

- Plug the A/V cable (included) and the AC power adapter correctly and push them in the terminals.
- When there is a power outlet available, connect the AC Power Adapter AC-5VX.




Plug the other end of the cable into the audio / video input socket on the TV. Then turn the camera and TV on and take pictures or play back images normally.

- When connecting the A/V cable to TV, the camera's screen is turned off
- Refer to the instructions provided with your TV for more information on audio/video input for your TV.
- The image quality for movie playback is lower than for still images.


When a printer that supports PictBridge is available, images can be printed by connecting the camera directly to the PictBridge-compatible printer without using a PC.




### 6.2.1 Specifying images for printing on the camera



- ① Set the Power switch to "▶" to turn the camera on.
- ② Select "♣⇒" PICTBRIDGE in "➡" USB MODE in the "➡" SET-UP menu (➡P.100).
- 3 Set the Power switch to "OFF" to turn the camera off.
- ② Do not connect to a PC when the "■" USB MODE setting is set to "➡⇒" PICTBRIDGE. See P.146 if you connect to a PC by mistake.




- ① Connect the camera to the printer using the USB cable (mini-B).
- 2 Turn the printer on.
- The camera cannot be used to specify printer settings such as the paper size and print quality.
- Please connect the AC Power Adapter AC-5VX (sold separately) to your camera.
- Use a media that was formatted on IS-1.




Set the Power switch to "▶".

"CHECKING USB" appears and then the menu is displayed on the screen.


- If the menu does not appear, check whether the "■" USB MODE setting is "♣=" PICTBRIDGE.
- Depending on the printer, some functions are disabled.



- ① Press "▲" or "▼" to select "♣ PRINT DPOF".
- ② Press "▶".
- When [NOT SET DPOF] appears, the DPOF settings are not specified.
- To use DPOF printing, the DPOF settings must be specified on IS-1 beforehand (→P.79).
- Even when "WITH DATE" is specified in the DPOF settings, the date is not inserted on printers that do not support date printing.



"♣PRINT DPOF OK?" appears on the screen. Press the "MENU/OK" button to begin printing.




The specified frames (files) are printed continuously.


Press the "DISP/BACK" button to cancel the printing. Depending on the printer, the printing may not be canceled immediately or printing may stop midway through. When printing stops midway, briefly turn the camera off and then on again.




## 6.2.2 Specifying images for printing without using DPOF (single-frame printing)



- ① Set the Power switch to "E" to turn the camera on.
- ② Select "♣≒" PICTBRIDGE in "➡" USB MODE in the "➡" SET-UP menu (➡P.100).
- 3 Set the Power switch to "OFF" to turn the camera off.
- Do not connect to a PC when the "■" USB MODE setting is set to "■⇒" PICTBRIDGE. See P.146 if you connect to a PC by mistake.




- ① Connect the camera to the printer using the USB cable (mini-B).
- 2 Turn the printer on.
- The camera cannot be used to specify printer settings such as the paper size and print quality.
- Please connect the AC Power Adapter AC-5VX (sold separately) to your camera.
- Use a media that was formatted on IS-1.




Set the Power switch to "▶".

"CHECKING USB" appears and then the menu is displayed on the screen.

- If the menu does not appear, check whether the "➡" USB MODE setting is "➡≒" PICTBRIDGE.
- Depending on the printer, some functions are disabled.



- ① Press "▲" or "▼" to select "PRINT WITH DATE" or "PRINT WITHOUT DATE". If "PRINT WITH DATE" is selected, the date is imprinted on your prints.
- ② Press "▶".



- ① Press "◄" or "▶" to display the frame (file) for which you want to specify PRINT settings.
- ② Press "▲" or "▼" to set a value up to 99 as the number of copies of the frame (file) to be printed. For frames (files) that you do not want printed, set the number of prints to 0 (zero).
- To specify more PRINT settings, repeat steps ① and ②.
- ③ Always press the "MENU/OK" button after the settings are completed.
- Movies and images with CCD-RAW cannot be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.


   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.


   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a camera other than IS-1 may not be printed.

   Images photographed with a came




"PRINT OK?" appears on the screen. Press the "MENU/OK" button to begin printing.



Printer starts printing the specified number of prints.

Press the "DISP/BACK" button to cancel the printing. Depending on the printer, the printing may not be canceled immediately or printing may stop midway through. When printing stops midway, briefly turn the camera off and then on again.

## Disconnecting the printer



- ① Check that "PRINTING" is not displayed on the camera's screen.
- ② Turn the camera off. Unplug the USB cable (mini-B).



### 6.3.1 Connecting to a PC

The "Connecting to a PC" section explains how to connect the camera to your PC using the USB cable (mini-B) and describes the functions you can use once the camera and PC are connected.

If the power cuts out during data transmission, the data will not be transmitted correctly. Always use the AC power adapter when connecting the camera to a PC.

#### Refer to Section 5 the first time you connect the camera to your PC.


Install the software first. Do not connect the camera to the PC before installing all the software.




CD-ROM (Software for FinePix CX)

## □⇒ DSC (Mass storage device) mode


This mode provides a simple way to read images from a media and store images onto a media.



Insert the media into the camera.



- ① Set the Power switch to "E" to turn the camera on.
- ② Select "□⇒" DSC in "■" USB MODE in the "Ⅶ" SET-UP menu (➡P.100).
- 3 Turn the camera off.
- Use the AC Power Adapter AC-5VX (sold separately) for the connection (→P.121). If shutting off power supply during communication, the files on the media may be damaged.
- If inserting an xD-Picture Card and a CF/Microdrive into the camera at the same time, images will be recorded onto the media selected as the "■" MEDIA (→P.100).




- 1 Turn your PC on.
- ② Connect the camera to the PC using the USB cable (mini-B).
- Make sure that the USB cable (mini-B) is connected correctly and pushed in.




Set the Power switch to "▶".

#### **Camera operation**



- When the camera and PC are exchanging data, the indicator lamp blinks orange.
- "□⇒DSC" appears on the screen.
- Auto power off is disabled during USB connection.
- Before replacing the media, always disconnect the camera from the PC. See P.129 for information on the disconnection procedure.
- ☑ Do not disconnect the USB cable (mini-B) when the camera is communicating with a PC. See P.129 for information on the disconnection procedure.

## ◆ When displaying [COMMUNICATION ERROR] ◆



If "CHECKING USB" appears and then [COMMUNICATION ERROR] is displayed on the screen, "□≒" (DSC mode) is not selected in "➡" USB MODE. Disconnect the USB cable (mini-B) to the camera and restart the procedure from step 1.



## 5 Set a PC

#### Windows 98 SE / Me / 2000 Professional / Macintosh

The Windows CD-ROM may also be required during installation. In this event, change CD-ROMs as directed by the on-screen instructions.

 FinePixViewer automatically starts up and the Save Image Wizard window (Save Image dialog box) appears. Follow the instructions provided on screen to save the images. To proceed without saving the images, click the [Cancel] button.



\* Screen for Windows 2000 Professional

 A removable disk icon appears and you can use your PC to transfer files to and from the camera.



If the above operations do not occur, you do not have the required software programs or drivers installed on your PC. Complete the required PC setup procedures. Then reconnect the camera to your PC.

#### Windows XP

① The "Found New Hardware" help message appears in the bottom-right corner of your screen. This message will close when the settings are completed. No action is required.



This step is not required for subsequent connections.

② A new removable disk icon appears in the "My Computer" window. FinePixViewer automatically starts up and the Save Image Wizard window (Save Image dialog box) appears. Follow the instructions provided on screen to save the images. To proceed without saving the images, click the [Cancel] button.

## Regarding the icons

The next time you connect the camera, the removable disk drive icon's name changes to the "FinePix" icon and name.

Proceed to "USING FinePixViewer" on P.130.

## 6.3.2 Disconnecting the camera

## 1 Windows


Once the image has been saved, the window below appears (Save Image Wizard Windows). To disconnect the camera, click the [Remove] button.



#### Macintosh

Once the image has been saved, the window below appears. To disconnect the camera, click the  $[\mathsf{OK}]$  button.





When the "It is now safe to disconnect the camera" message appears, click the [OK] button and disconnect the camera.

Set the Power switch to "OFF" to turn the camera off



## **6.4 USING FinePixViewer**

#### 6.4.1 Mastering FinePixViewer

For all information on FinePixViewer functions, refer to "How to Use FinePixViewer" in the Help menu for details

- What is explained in "How to Use FinePixViewer"...
- "How to Use FinePixViewer" covers a range of topics, including batch processing and ordering prints.

#### **■** Example: Looking up slide shows

- ① Click "How to Use FinePixViewer" in the FinePixViewer Help menu.
- ② Click "Basic Operation" and then click "Slide Show" in the menu that appears.
- ③ The "Slide Show" information appears. Press the "<<<" key to view the previous page or the ">>>" key to view the next page.

## 6.4.2 Uninstalling the software

Only perform this operation when you no longer require the installed software or when the software was not installed correctly.

#### Windows

- ① Check that the camera is not connected to the PC.
- 2 Quit all currently running applications.
- ③ Open the "My Computer" window. Then open the "Control Panel" and double-click on "Add/Remove Programs".



The "Add/Remove Programs Properties" window appears. Select the software to be uninstalled (FinePixViewer or the driver) and then click the [Add/Remove] button. (5) When the message appears, click the [OK] button. Check your selection carefully since the process cannot be canceled once you click the [OK] button.



Automatic uninstallation begins.

When uninstallation ends, click the [OK] button.

#### Macintosh

#### ■ Uninstalling FinePixViewer

Quit FinePixViewer. Then drag the installed FinePixViewer folder to the Trash and select "Empty Trash" in the "Finder" menu.



## Launching Hyper-Utility2

Use the procedure below to launch Hyper-Utility2.

#### Windows

 Double-click the [Hyper-Utility2] icon on the desktop.



 • In the "Start" menu, click "All Programs" → "Hyper-Utility2".



In Windows, specifying the use of ICM will slow down image display.

### Mac OS X

Double-click the [Hyper-Utility2] icon.

In Mac OS X, specifying the use of ColorSync will slow down image display.

## **Using the Online Help**

The Online Help provides additional information on Hyper-Utility2 functions that is not included in this Installation Guide.

## To Read "Hyper-Utility2 Help"


The version of browser provided with your operating system is required to view the Hyper-Utility2 Help.

### To view the Online Help

Click [How to Use Hyper-Utility2 (Hyper-Utility2 Help)] in the Help menu.



 $2 \, \mbox{The Internet browser software starts up and displays the Help.}$ 



3 Click the topic you want to view in the menu on the left.



## 6.5 USING Hyper-Utility2

## **Uninstalling Hyper-Utility2**

Only perform this operation when you no longer require the installed Hyper-Utility2.

#### Windows

Switch on your PC.

Disconnect the camera.

**3** Quit all currently running applications.

If the camera is connected, disconnect it.
Refer to the Owner's Manual for your camera for information on disconnecting the camera.

Close all files.

If the Hyper-Utility Software HS-V2 CD-ROM is loaded in the CD-ROM drive, remove the CD-ROM.

5 Open the "My Computer" window, open the "Control Panel", and double-click "Add or Remove Programs".

The "Add or Remove Programs" Properties window opens. Select "FUJIFILM Hyper-Utility Software" and click the [Change/Remove] button.




7 Automatic uninstallation begins.


#### Mac OS X

Hyper-Utility2 cannot be deleted in Mac OS X.

## **System Expansion Options**

▶ By using the IS-1 together with other optional FUJIFILM products, your system can be expanded to fill a wide range of uses. Accessory availability may vary by country. Please check with your local Fujifilm representative to confirm product availability.







## **Accessories Guide**

▶ Visit the FUJIFILM web site for the latest information on camera accessories.

http://www.fujifilm.com/products/digital/index.html

Accessory availability may vary by country. Please check with your local Fujifilm representative to confirm product availability.

#### xD-Picture Card

Use the following xD-Picture Cards:

16MB/32MB/64MB/128MB/256MB/512MB/1GB/2GB

There are two types of **xD-Picture Card**: standard type and Type M (containing "M" in the model number, such as DPC-M1GB).

IS-1 is compatible with Type M, however they may not be compatible depending on the device used (Image Memory Card Reader, etc.).



#### AC Power Adapter AC-5VX

Use the AC-5VX when taking pictures or play back images for long periods or when  $\mbox{\it (the IS-1 is connected to a PC.}$ 

\*The shape of the AC power adapter, the plug and power outlet depend on the country.



#### Soft Case SC-FXS9

This is a special case made of polyester that protects the camera against soil, dust and minor impacts when it is being carried.

#### Wide Conversion Lens WL-FXS6

This accessory converts the focal length of your lens by 0.8 times (equal to a 30 mm wide-angle lens) without changing its F-stop value.

Wide conversion lens specifications

Magnification: × 0.8

Lens configuration: 3 lenses in 3 groups

Shooting range (Wide-angle only): Normal approx. 40 cm (1.3 ft.) to infinity/ Macro approx. 10 cm (3.9 ft.) to 3 m (9.8 ft.) / Super macro approx. 2 cm (0.8 ft.) to 1 m (3.3 ft.)


Dimensions: ø95 mm (3.7 in.) × L37.5 mm (1.5 in.)

Weight: approx. 214 g (7.5 oz.)

Accessories: lens caps (front and rear), Lens pouch



The DPC-R1 provides a quick and easy way to transfer images back and forth between your PC and an image memory card (**xD-Picture Card** and SmartMedia). The DPC-R1 uses the USB interface for highspeed file transfer.





#### PC Card Adapter DPC-AD

The PC Card Adapter allows the  ${\bf xD\text{-}Picture}$  Card and SmartMedia to be used as a PC Card Standard ATA-compliant (PCMCIA 2.1) PC card (Type II).

 Compatible with xD-Picture Card of 16 MB to 512 MB, and SmartMedia of 3.3 V, 2 MB to 128 MB.



#### CompactFlash™ Card Adapter DPC-CF

Loading an  ${\bf xD\text{-}Picture~Card}$  into this adapter allows you to use the card as a CompactFlash card (Type I).



## **Using Your Camera Correctly**

▶ Read this information and the "Safety Notes" (⇒P.160), to make sure you use your camera correctly.

#### ■ Places to Avoid

Do not store or use the camera in the following types of locations:

- In the rain or in very humid, dirty or dusty places
- In direct sunlight or in places subject to extreme temperature rises, such as in a closed car in summer
- Extremely cold places
- Places with strong vibration
- Places with smoke or steam
- Places subject to strong magnetic fields (such as near motors, transformers or magnets)
- In contact with chemicals such as pesticides
- Next to rubber or vinyl products

#### ■ Damage by Water or Sand

The IS-1 can be damaged on the inside and outside by water and sand. When you are at the beach or close to water, make sure that the camera is not damaged by water or sand. Take care not to place the camera on a wet surface.

#### ■ Damage by Condensation

If the camera is carried from a cold location into a warm place, water droplets (condensation) may form on the inside of the camera or on the lens. When this occurs, turn the camera off and wait an hour before

using the camera. Condensation may also form on the media. In this event, remove the media and wait a short time

#### ■ When the Camera is Not Used or is stored Periods of Time

If you do not intend to use the camera for a long period of time, remove the batteries and the media.

#### ■ Cleaning Your Camera

- Use a blower brush to remove any dust on the lens, LCD monitor, viewfinder or external AF sensor and then gently wipe the camera with a soft, dry cloth. If any soil remains, apply a small amount of lens cleaning liquid to a piece of FUJIFILM lens cleaning paper and wipe gently.
- Do not scratch hard objects against the lens, LCD monitor or viewfinder.
- Clean the body of the camera with a soft, dry cloth.
   Do not use volatile substances or cleaning products these items can cause damage.

#### ■ Using the Camera When Traveling

When traveling overseas, do not place your camera in the check-in baggage. Baggage can be subjected to violent shocks, and the camera may be damaged inside or outside.

## **Power Supply and Batteries**

## Applicable Batteries

- In the camera, use AA-size alkaline or Ni-MH (nickel-metal hydride) rechargeable batteries. Do not use AA-size manganese or nickel-cadmium (Ni-Cd) batteries in your IS-1 because the heat created by the batteries could damage the camera or cause it not to work.
- The life of alkaline batteries varies between brands.
   The life of batteries you purchase may be shorter than those provided with the camera.

#### Notes on the Batteries

Incorrect use of the batteries could cause them to leak, become hot, ignite or burst. Always observe the precautions given below.

- Do not heat the batteries or throw them into a fire.
  Do not carry or store batteries with metal objects
- bo not carry or store batteries with metal object such as necklaces or hairpins.
- Do not expose the batteries to water, and keep batteries from getting wet or stored in moist locations.
- Do not attempt to take apart or change the batteries, including battery casings.
- Do not subject the batteries to strong impacts.
- Do not use batteries that are leaking, deformed, discolored.
- Do not store batteries in warm or humid places.
- Keep the batteries out of reach of babies and small children.
- Make sure that the battery polarity (⊕ and ⊝) is correct.

- Do not use new with used batteries. Do not use charged and discharged batteries together.
- Do not use different types or brands of batteries at the same time.
- If you do not intend to use the camera for a long period of time, remove the batteries from the camera. Note if the camera is left with the batteries removed, the time and date settings are cleared.
- The batteries feel warm right after being used.
   Before removing the batteries, turn the camera off and wait for the batteries to cool down.
- Since batteries do not work well in cold weather or locations, warm the batteries by placing them inside your garments before use. Batteries do not work well when cold. They will work again when the temperature returns to normal.
- Soil (such as fingerprints) on the battery terminals makes the batteries charge less reducing the number of images. Carefully wipe the battery terminals with a soft dry cloth before loading.
- ⚠ If any liquid at all leaks from the batteries, wipe the battery compartment thoroughly and then load new batteries.
- ⚠ If any battery fluid comes into contact with your hands or clothing, flush the area thoroughly with water. Note that battery fluid can cause loss of eyesight if it gets into your eyes. If this occurs, do not rub your eyes. Flush the fluid out with clean water and contact your physician for treatment.

# Using the AA-size Ni-MH batteries correctly

- As a power source in digital cameras, AA-size Ni-MH batteries (referred to hereafter as Ni-MH batteries) are superior to alkaline batteries in several ways, such as allowing more shots to be taken with the camera. However, care must be taken with the way Ni-MH batteries are used if their original performance is to be maintained.
- Ni-MH batteries left unused in storage for long periods can become "deactivated". Also, repeatedly charging Ni-MH batteries that are only partially discharged can cause them to suffer from the "memory effect".

Ni-MH batteries that are "deactivated" or affected by "memory" suffer from the problem of only providing power for a short time after being charged. To prevent this problem, discharge and recharge them several times using the camera's "Discharging rechargeable batteries" function. By repeating this cycle several times, the temporary reduction in performance caused by "memory" or "deactivation" can be remedied and the batteries can be restored to their original performance levels.

Deactivation and memory are specific to Ni-MH batteries and are not in fact battery faults. See P.139 for the procedure for "Discharging rechargeable batteries".

Do not use the "Discharging rechargeable batteries" function when alkaline batteries being used.

- To charge Ni-MH batteries, use the quick battery charger (sold separately). Refer to the instructions supplied with the charger to make sure that the charger is used correctly.
- Do not use the battery charger to charge other batteries.
- Note that the batteries feel warm after being charged.
- Due to the way the camera is constructed, a small amount of current is used even when the camera is turned off. Note in particular that leaving Ni-MH batteries in the camera for a long period will overdischarge the batteries and may render them unusable even after recharging.
- Ni-MH batteries will self-discharge even when not used, and the time for which they can be used may be shortened as a result.
- Ni-MH batteries will deteriorate rapidly if overdischarged (e.g. by discharging the batteries in a flashlight). Use the "Discharging rechargeable batteries" function provided in the camera to discharge the batteries.
- Ni-MH batteries have a limited service life. If a battery can only be used for a short time even after repeated discharge-charge cycles, it may have reached the end of its service life.

#### ■ Disposing of Batteries

When disposing of batteries, do so in accordance with your local waste disposal regulations.

#### AC Power Adapter

Always use the AC Power Adapter AC-5VX with the camera.

The use of an AC Power adapter other than AC-5VX can be damaged to your digital camera.

- Use the AC power adapter for indoor use only.
- Plug the connection cord plug securely into the DC input terminal of the FUJIFILM Digital camera.
- Turn off the FUJIFILM Digital camera before disconnecting the cord from the FUJIFILM Digital camera's DC input terminal. To disconnect, pull out the plug gently. Do not pull on the cord.
- Do not use the AC power adapter with any device other than your camera.
- During use, the AC power adapter will become hot to the touch. This is normal.
- Do not take apart the AC power adapter. Doing so could be dangerous.
- Do not use the AC power adapter in a hot and humid place.
- Do not subject the AC power adapter to strong shocks.
- The AC power adapter may emit a humming. This is normal.
- If used near a radio, the AC power adapter may cause static. If this happens, move the camera away from the radio.


### Discharging rechargeable batteries

The "Discharging rechargeable batteries" function can only be used with Ni-MH batteries.


The "Discharging rechargeable batteries" function should not be used with alkaline batteries as it will completely drain the battery charge.

Use the "Discharging rechargeable batteries" function in the following situations:

- When the batteries only last for a short time after being charged normally
- When the batteries have not been used for a long period
- When you purchase new Ni-MH batteries




Set the Power switch to "▶".



Press the "MENU/OK" button to display the menu on the screen.

Do not use the procedure for discharging rechargeable batteries with alkaline batteries.




① Press "▲" or "▼" to select "웹" SET-UP.


② Press "▶".

138 Continued

## **Power Supply and Batteries**




- ① Press "◀" to move to page number.
- ② Press "A" or "▼" to select "PAGE 4".



- ① Press "▶" to move to menu item.
- ② Press "▲" or "▼" to select "■" DISCHARGE.
- ③ Press "▶".



Press the "MENU/OK" button.



- Press "◀" or "▶" to select "OK".
- 2 Press the "MENU/OK" button.

The screen changes and discharging begins. When the battery level indicator blinks red and discharging ends, the camera turns off.

#### To cancel discharging, press the "DISP/BACK" button.

## **Notes on the Media**

#### ■ Image Memory Card

 This Image Memory Card is a new image recording media (xD-Picture Card) developed for digital cameras.
 The Image Memory Card consists of a semiconductor memory (NAND-type flash memory) to record digital image data.

The recording process is electrically performed and enables erasure of existing image data as well as rerecording of new image data.

 When using a new Memory Card, or a Memory Card that has been formatted by a PC, be sure to format the card with your digital camera before using it.

#### ■ Microdrives

Microdrives are compact, lightweight hard disk drives that conform to the CF+ Type II standard. Due to their ample capacity for large image data files and their low permegabyte recording cost, Microdrives provide a more economical way to save high-resolution image files.

#### ■ Protecting Your Data

- Images and movies may be lost or destroyed in the following situations. Please note that FUJIFILM assumes no responsibility for data that is lost or destroyed.
- Removal of the memory card or turning the power off while the memory card is being accessed (i.e., during record, erase, initialization, and playback operations).
- Improper handling and use of the memory card by the user or third party.
- Save your important data to another media (i.e., MO disk, CD-R, hard disk, etc.).

#### ■ Handling Media (all types)

- When inserting the media into the camera, hold the media straight as you push it in.
- Never remove the media or turn the camera off during data recording or erasing (media formatting) as this could be damaged to the media.
- Do not bend, drop or otherwise subject the media to strong force or shocks.
- Do not use or store these media in places with affected by strong static electricity or electrical noise.
- Do not use or store media in hot humid places or in places where they are exposed to corrosive substances.

#### ■ Handling xD-Picture Card

- When storing xD-Picture Cards, make sure that they are kept out of the reach of children. An xD-Picture Card could be swallowed cause suffocation. If a child swallows an xD-Picture Card, seek medical attention or call emergency number right away.
- Do not expose an xD-Picture Card to shock. Do not apply pressure, and avoid bending.
- Do not use the **xD-Picture Card** in a hot or humid place.
- Clean the xD-Picture Card with a soft dry piece of cloth when dirty.
- When carrying or storing an xD-Picture Card, keep it in the special protective case.
- The xD-Picture Card will work well for long time, but will sooner or later lose its ability to store and play back images or movies. If this happens replace it with a new xD-Picture Card.
- The use of xD-Picture Cards is recommended with the IS-1.

The recording quality cannot be guaranteed when **xD- Picture Cards** other than those manufactured by
FUJIFILM are used.

- The **xD-Picture Card** may feel warm when it is removed from the camera after taking pictures. This is normal.
- Do not put labels on the xD-Picture Card. Peeling labels can cause the camera not to work properly.

There are two types of xD-Picture Card:

standard type and Type M (containing "M" in the model number such as DPC-M1GB)

IS-1 is compatible with Type M, however they may not be compatible depending on the device used (Image Memory Card Reader, etc.).

#### ■ Using Microdrive

- Do not use hard-pointed pens to write on the Microdrive label.
- Do not peel off the Microdrive label.
- Do not stick additional labels onto a Microdrive.
- When carrying or storing a Microdrive, keep it in the protective case provided.
- When a Microdrive is used, vibration or impacts during image data recording may prevent the image data from being recorded correctly. Put the camera down carefully when placing it on a desk or table, etc.
- Do not use Microdrive in CF+ Type II slots that do not have an eject function.
- Take care when handling Microdrive that have been used for long periods as they may become hot.
- Do not place Microdrives close to strong magnetic fields.
- Keep Microdrive dry.
- Do not apply strong pressure to the Microdrive cover.

#### ■ Using Compact Flash

Contact the CompactFlash card manufacturer for information on the CompactFlash functions, operation details and system requirements.

Card types approved for use with the IS-1 are listed on the FUJIFILM website.

http://www.fujifilm.com/products/digital/

- The CompactFlash card may be not immediately after being used in the camera and should be handled with care
- Do not touch the card contact area with your fingers or metal objects.
- Unused CompactFlash cards should be formatted before being used.

#### ■ Using media with a PC

- When taking pictures using a media that has been used on a PC, reformat the media using your camera for best quality.
- When formatting a media, a directory (folder) is created.
   Image data is then recorded in this directory.
- Do not change or delete the directory (folder) or file names on the media because this will make it impossible to use the media in your camera.
- Always use the camera to erase image data on a media.
- To edit image data, copy the image data to the PC and edit the copy.

#### ■ Specifications

Type

| Image memory card for digital cameras (xD-Picture Card)
| Memory type | Conditions for use | Temperature:
| O°C to +40°C |
| (+32°F to +104°F) |
| Humidity:
| 80% max. (no condensation)
| 25 mm × 20 mm × 2.2 mm |
| (0.98 in. × 0.79 in. × 0.09 in.) |
| (W × H × D)

Warning Displayed	Explanation	Remedy	
(Lit red)	The camera batteries are low or completely out of charge.	Load new or fully charged batteries.	
! <b>ш</b> "	There is a strong likelihood of camera shake because the shutter speed is slow.	Use flash photography. However, use a tripod for some scenes and modes.	
!AF	The AF (autofocus) cannot work effectively.	If the image is too dark, take the picture at a distance of around 2 m (6.6 ft.) from the subject. Use AF lock to take the picture. Select Macro mode when taking close-up shots.	
Aperture/Shutter speed display (Lit red)	Outside the AE continuous range.	The picture can be taken, but the correct brightness (exposure) will not be obtained.	
FOCUS ERROR ZOOM ERROR	Camera malfunction or fault.	Turn the camera on again, taking care not to touch the lens. Turn the camera off and on again. If the message still appears, contact your FUJIFILM dealer.	
NO CARD	No media is inserted.	Insert a media.	
CARD NOT INITIALIZED	The media is not formatted. The xD-Picture Card contact area is soiled.  Camera fault.	Format the media on the camera.     Wipe the contact area on the xD-Picture Card with a soft dry cloth. It may be necessary to format the xD-Picture Card. If the message still appears, replace the xD-Picture Card.     Contact your FUJIFILM dealer.	
CARD ERROR	The xD-Picture Card contact area is soiled. The media format is incorrect. Camera fault. The media is damaged.	Wipe the contact area on the xD-Picture Card with a soft dry cloth. It may be necessary to format the xD-Picture Card. If the message still appears, replace the xD-Picture Card.     Contact your FUJIFILM dealer.	
CARD FULL	The media is full.	Erase some images or use a media that has ample free space.	
WRITE ERROR	The data could not be recorded due to a media error or a connection error between the media and camera. The image cannot be recorded as it is too large to fit in the available space on the media. The xD-Picture Card is not formatted.	Re-insert the media or turn the camera off and then on again. If the message still appears, contact your FUJIFILM dealer.  Use a new media.  Format the xD-Picture Card on the camera (⇒P.104).	
BUSY	The timing for recording was incorrect because the media was formatted on a PC.	Use a media that was formatted on the camera.	
FRAME NO. FULL	The frame number has reached 999-9999.	Insert a formatted media into the camera.     Set "RENEW" as the FRAME NO. setting in the "SET-UP" menu.     Start taking pictures (The frame number starts from "100-0001").     Set "CONT." as the FRAME NO. setting in the "SET-UP" menu.	
READ ERROR	The played back file was not recorded correctly. The xD-Picture Card contact area is soiled.  Camera fault. An attempt was made to play a movie or display an image that was not recorded on this camera.	Images cannot be played back.      Wipe the contact area on the xD-Picture Card with a soft dry cloth. It may be necessary to format the xD-Picture Card. If the message still appears, replace the xD-Picture Card.      Contact your FUJIFILM dealer.      Movies and images cannot be played back.	
TOO MANY FRAMES	An attempt was made to show 5,000 or more images by date sorting.	No more than 4,999 images can be shown by date sorting.	

Maminu Diantarral	Funlametica	Dama du	
Warning Displayed	Explanation	Remedy	
PROTECTED FRAME	A protected file was encountered.      An attempt was made to add a voice memo to protected file.      An attempt was made to rotate a protected file.	Protected files cannot be erased. Remove th protection. Protected files cannot be added to voic memos. Remove the protection. Protected files cannot be rotated. Remove th protection.	
<b>⊕</b> ERROR	The voice memo file is faulty. Camera fault.	The voice memo cannot be played back. Contact your FUJIFILM dealer.	
GAM CAN NOT TRIM	An attempt was made to trim a 0.3M image or an image shot with the RAW setting.	The image cannot be trimmed.	
CAN NOT TRIM	An attempt was made to trim an image shot using a camera other than IS-1.     The image is damaged.	The image cannot be trimmed.	
DPOF FILE ERROR	Prints were specified for 1000 or more frames in the DPOF frame settings.	The maximum number of frames for which prints can be specified on the same media is 999. Copy the images for which you want to order prints onto another media and then specify the DPOF settings.	
CAN NOT SET DPOF CAN NOT SET DPOF CAN NOT SET DPOF	An attempt was made to specify DPOF settings for an image that is not supported by DPOF.		
CAN NOT ROTATE	An attempt was made to rotate a movie.	These images cannot be rotated by image formats.	
COMMUNICATION ERROR	The camera is not connected to a PC or printer.	Check that the USB cable (mini-B) is connected correctly.     Check that your printer is turned on.	
PRINTER ERROR	Displayed for PictBridge.	Check that the printer is not out of paper or out of ink. Turn the printer off briefly and then turn it back on. Refer to the user manual supplied with your printer.	
PRINTER ERROR RESUME?	Displayed for PictBridge.	Check that the printer is not out of paper or out of ink. Printing automatically restarts when the error is cleared. If the message still appears after checking, press the "MENU/OK" button to restart printing.	
CANNOT BE PRINTED	Displayed for PictBridge.	Refer to the user manual for the printer being used and check whether the printer supports the JFIF-JPEG or Exif-JPEG image format. If not, the printer cannot print the images.  Movies and images with CCD-RAW cannot be printed.  Was the image data photographed using IS-1? You may not be able to print some images photographed on other cameras.	
₽ PRINTING	Displayed for PictBridge.	This message appears when printing is performed from a FUJIFILM printer that supports PictBridge. Refer to the Owner's Manual for the printer for details.	

Warning Displayed	Explanation	Remedy
MICRODRIVE IS OVERHEATING MOVIE RECORDING WILL AUTOMATICALLY STOP SOON	An attempt was made to shoot a movie when the Microdrive was too hot.	Turn the camera off and stop using it for about 30 minutes until it has cooled down. Note that you can shoot still images during this period.
MOVIE RECORDING HAS STOPPED CANNOT RESTART A WHILE		

# **Troubleshooting**

▶ If you think the camera is faulty, check the following once more.

Troubleshooting	Possible causes	Solutions
No power.	The batteries have run out. The AC power adapter plug has come out of the power outlet. The batteries are loaded backwards. The battery cover is not closed correctly. The camera has been left for a long period with batteries and AC power adapter	Load new or fully charged batteries.     Plug the adapter back in.      Load the batteries in the correct direction.     Close the battery cover correctly.     Load the batteries or connect the AC power adapter, and wait a short time before turning
Power cuts out during operation.	removed.  The batteries have run out.	the camera on.  Load new or fully charged batteries.
Batteries run out quickly.	Camera is being used in extremely cold conditions.  The terminals are soiled.  The batteries can no longer be recharged.  The rechargeable batteries (if used) have become deactivated, or the battery capacity has diminished due to the memory effect.	Put the batteries in your pocket or another warm place to heat them and then load them into the camera just before you take a picture. Wipe the battery terminals with a clean, dry cloth. Load new or fully charged batteries. Use the rechargeable battery discharging function to restore the rechargeable batteries to full capacity.
No photograph is taken when pressing the shutter button.	No media is inserted. The media is full.  The media is not formatted. The xD-Picture Card contact area is soiled. The media is damaged. The batteries have run out.	Insert a media. Insert a new media or erase some unwanted frames. Format the media on the camera. Wipe the xD-Picture Card contact area with a clean, dry cloth. Insert a new media. Load new or fully charged batteries.
Focusing is slow.	The external AF sensor is dirty.	Use a blower brush to brush away any dust and then gently wipe the sensor with a soft, dry cloth.
Cannot set the camera to Macro (close-up) mode.	Photography mode is set to "♠", "▲" or "﴾".	Change the Photography mode to "AUIO", "《N", "O", "P", "S", "A" or "M".
Cannot select continuous shooting.	Multiple exposure mode is selected.	Set multiple exposure mode to "OFF".
Cannot set exposure compensation.	The Mode dial is set to "AUTO", "♣", "♠", "♠", "♠", "♠", "♠", "♠", "♠", "♠	Change the Photography mode.
Cannot use the flash.	The shutter button was pressed while the flash was charging. The flash is not popped up. The batteries have run out. The camera is set to "\" or "\" in Photography mode. Continuous shooting is selected.	Wait until the charging is completed before pressing the shutter button.     Pop up the flash.     Load new or fully charged batteries.     Change the Photography mode.      Set continuous shooting to "OFF".     Cancel Super macro mode.
The flash settings are restricted and cannot be selected.	The Photography mode is set to "AUIO", "A", "A", "C", "S", "A" or "M".	The flash settings are restricted because the camera settings are tailored to the scene being shot. Change the Photography mode for a wider range of flash settings.
The playback image is dark even though the flash was used.	The subject is too far away.  Your finger was covering the flash.	Move to within the effective flash range before taking the picture.     Hold the camera correctly.
The image is blurred.	The lens is dirty. You photographed scenery with Macro mode selected. You took a close-up shot without selecting Macro mode. You are shooting a subject that is not suited to autofocusing.	Clean the lens. Cancel Macro mode. Select Macro mode. Use AF/AE lock or "MF" Manual focus mode to take the picture.
There is speckling on the image.	The picture was taken with a slow shutter speed (long exposure) in a high-temperature environment.	This is a characteristic of CCDs and does not indicate a camera fault.

Troubleshooting	Possible causes	Solutions
The camera does not emit any sound.	The camera volume is set too low. The microphone was blocked during shooting/recording. There is something covering the speaker during playback.	Adjust the volume.     Take care not to block the microphone during shooting/recording.     Make sure that the speaker is uncovered.
Frame erase does not erase the frame.	Some frames may be protected.	Unprotect frames using the camera on which the protection was first applied.
The ERASE ALL function does not erase all the frames.		
Screens are not displayed in English.	A language other than English is selected in the "靈" 言語/LANG. setting in the "" SET-UP menu (ᆃP.100).	①Press the "MENU/OK" button to display the menu. ②Press "▲" or "▼" to select "圙" SET-UP and press "▶". ③Press "▲" or "▼" to select "圙" 言語/LANG ④Press "▶". ⑤Press "▲" or "▼" several times to select "ENGLISH". ⑥Press the "MENU/OK" button.
There is no image or sound on the TV.	The included A/V cable was connected during movie playback. The camera is not connected to the TV correctly. The "B" video output setting is incorrect. The TV volume is turned down.	After the movie playback mode is stopped, connect the camera and TV correctly.     Connect the camera and TV correctly.     Set the TV input to "VIDEO".     Change the setting to "NTSC" or "PAL" (→P.100).     Adjust the volume.
The TV image is black and white.	The "" video output setting is incorrect.	Change the setting to "NTSC" or "PAL" (⇒P.100).
When connecting the camera to a PC, the photographed image or playback image appears on the camera's screen.	The USB cable (mini-B) is not correctly connected to the PC or camera. The PC is not turned on.	Set up the camera, and connect the USB cable (mini-B) correctly.     Turn the PC on.
Nothing happens when using the Mode dial.	Camera malfunction.      The batteries have run out.	Briefly remove the batteries or disconnect the AC power adapter. Then reload the batteries or reconnect the AC power adapter and try again.     Load new or fully charged batteries.
The camera no longer works correctly.	The camera has suffered an unforeseen problem.	Briefly remove the batteries or disconnect the AC power adapter. Then reload the batteries or reconnect the AC power adapter and try again. If you think the camera is faulty, contact your FUJIFILM dealer.
Cannot print with PictBridge.	"♣≒" PICTBRIDGE is not selected in "♣" USB mode in the "ऒ" SET-UP menu.	Select "♣⇒" PICTBRIDGE in "ঊ" USB mode in the "ໝ" SET-UP menu.
The camera was connected to a PC when the USB mode was set to "🅰 🖘".		Perform steps ① to ③ to remove the camera from the PC.  • Windows ① The "New Hardware Found" wizard or "Scanner and Camera" wizard appears. If the wizard does not appear, proceed to step ③. ② Click the [Cancel] button. ③ Disconnect the camera from the PC.
		Macintosh     The window for locating the driver appears. If the window does not appear, proceed to step ③.     Click the [Cancel] button.     Disconnect the camera from the Macintosh.

# **Specifications**

System	
•	
Model	Digital camera IS-1
Effective pixels	9.0 million pixels
CCD	1/1.6-inch Super CCD HR
Storage media	xD-Picture Card (16/32/64/128/256/512 MB/1 GB/2 GB) CF card and Microdrive™ (Compatibility is listed on Fujifilm website: http://www.fujifilm.com/products/digital/)
File format	Still image: DCF-compliant Compressed: Exif ver.2.2 JPEG, DPOF-compatible Uncompressed: CCD-RAW (RAF) * Design rule for Camera File System compliant DPOF compatible Movie: AVI format, Motion JPEG Audio: WAVE format, Monaural sound
Number of recorded pixels	Still image: $3488 \times 2616$ pixels/ $3696 \times 2464$ pixels/ $2592 \times 1944$ pixels/ $2048 \times 1536$ pixels/ $1600 \times 1200$ pixels/ $640 \times 480$ pixels ( $1600 \times 1200$ pixels/ $1600 \times 1200$ pix
File size	See the table on P.150.
Lens	Fujinon 10.7× optical zoom lens F2.8-F4.9
Focal length	f=6.2 mm-66.7 mm (Equivalent to approx. 28 mm-300 mm on a 35 mm camera)
Digital zoom	Approx. 2× (10.7× optical zoom lens is used together: Max. zoom scale: 21.4×)
Aperture (Wide-angle)	F2.8 to F11 Up to 13 steps in 1/3 EV increments Manual/Auto selectable
	shooting mode: approx. 2 m (6.6 ft.) to infinity) Telephoto: approx. 2 m (6.6 ft.) to infinity (In High-speed shooting mode: approx. 4 m (13.1 ft.) to infinity) Macro: Wide-angle: approx. 10 cm (3.9 in.) to 3 m (9.8 ft.) Telephoto: approx. 90 cm (3.0 ft.) to 3 m (9.8 ft.) Super macro: approx. 1 cm to 1 m (0.4 in. to 3.3 ft.) (Wide-angle only)
Sensitivity	AUTO/Equivalent to ISO 80/100/200/400/800/1600
Photometry	TTL 256-zones metering Multi, Spot, Average
Exposure control	Program AE (♣WI), ♣W, ♠, ♠, ♠, ♠, P), Shutter-priority AE, Aperture-priority AE, Manual exposure
Scene position	(Picture Stabilization),
Exposure compensation	-2 EV to +2 EV in 1/3 EV-step increments (P, S, A)
Shutter speed	AUTO, ₩, ♠, ♠, 1/4 sec. to 1/4000 sec. ♦: 4 sec. to 1/500 sec. P/S/A: 4 sec. to 1/4000 sec. M: 30 sec. to 1/4000 sec. Bulb (Up to 30 sec.)
Continuous shooting	Top 4-frame: Number of recorded frames: up to 4 frames (Max. 1.5 frames/sec.) Final 4-frame: Number of recorded frames: last 4 frames before releasing the shutter button (Max. 1.5 frames/sec.) Long-period continuous shooting mode: Number of recorded frames: up to 40 frames. (Max. 1.1 frames/sec.)
Auto bracketing	± 1/3 EV, ± 2/3 EV, ± 1 EV
Focus	Mode: Auto focus, Continuous AF, Manual focus AF system: TTL contrast-type AF frame selection: AF (CENTER), AF (MULTI), AF (AREA)

# **Specifications**

System	
White balance	Automatic scene recognition/Preset (Fine, Shade, Fluorescent (Daylight), Fluorescent (Warm White), Fluorescent (Cool White), Incandescent/Custom white balance (2 types))
Self-timer	Approx. 10 sec./2 sec.
Flash type	Auto flash Effective range ( 150 : AUTO): Wide-angle: approx. 30 cm-5.6 m (1.0 ft18.4 ft.) Telephoto: approx. /90 cm-3 m (3.0 ft9.8 ft.)
Flash mode	Auto, Red-Eye Reduction, Forced Flash, Suppressed Flash, Slow Synchro, Red-Eye Reduction + Slow Synchro
Viewfinder	0.44 inches, 235,000 pixels, LCD viewfinder Approx. 100% coverage
LCD monitor	2.0 inches, Aspect ratio: 4:3; approx. 235,000 pixels low-temperature polysilicon TFT, Approx. 100% coverage
Movie	640 × 480 pixels/320 × 240 pixels (140/1420) (30 frames per second with monaural sound) A series of continuous image can be recorded up to available recording time per media.
Photography functions	High-speed shooting, Best framing, Post shot assist window, Frame No. memory
Playback functions	Trimming, Image rotate, Automatic playback, Multi-frame playback, Sorting by date, Voice memo
Other functions	PictBridge, Exif print, Language (English, Francais, Deutsch, Español, Italiano, 中文, 한글), Time difference, FinePix photo mode ( <i>F</i> -mode)

Input/Output Terminal	
A/V OUT (Audio/Visual output	t) NTSC/PAL-type (with monaural sound)
Digital input/output	USB2.0 High-Speed
DC input socket	AC Power Adapter AC-5VX (sold separately)
Accessory shoe	Hot shoe
Synchronizing terminal	Equipped with ISO 519 synchronizing terminal as standard, lock screw provided

Power supply	Use one of the following:  • 4× AA-size alkaline batteries  • 4× AA-size Ni-MH (Nickel-Metal Hydride) batteries (sold separately)  • AC Power Adapter AC-5VX (sold separately)				
Guide to the number of available frames for battery	Battery Type Media	Alkaline batteries	Ni-MH batteries 2500 mAh		
operation	xD-Picture Card	Approx. 120 frames	Approx. 320 frames		
	Microdrive	Approx. 70 frames	Approx. 300 frames		
	When using alkaline batteries, use the batteries supplied with the camera. You can use Ni-MH batteries also. The storage media should be xD-Picture Card or Microdrive. Pictures should be taken at a temperature of +23°C (+73°F), with the LCD monitor turned on, AF-assist illuminator off, the optical zoom moved from full wide-angle to full telephoto (or vice-versa) and back again to its original position every 30 seconds, the flash used at full power every second shot and the camera turned off and then on again once every 10 shots.  ■ Note: Because the number of available shots varies depending on the capacity of alkaline batteries or the level of charge in Ni-MH batteries, the figures shown here for the number of available shots using batteries are not guaranteed. The number of available shots will also decline at low temperatures.				
Camera dimensions (W/H/D)	128.0 mm × 93.0 mm × 129 (not including accessories a		5.1 in.		
Camera mass (weight)	Approx. 650 g/22.9 oz. (not including accessories, b	atteries and <b>xD-Picture</b>	Card or CF/Microdrive)		
Waight for photography	Approx 760 g/26 9 oz (incl	uding bottorion and vD	Dieture Cord		

Temperature: 0°C to +40°C (+32°F to +104°F) 80% humidity or less (no condensation)

Approx. 760 g/26.8 oz. (including batteries and xD-Picture Card)

148

Weight for photography

Operating conditions

#### ■ Standard number of available frames/recording time per media

The number of available frames, recording time or file size varies slightly depending on the subjects photographed. Note also that the divergence between standard number of frames and the actual number of frames is greater for medias with higher capacities. When used media is 4GB or more, a movie up to 60 minutes long (at the "EED" setting) or 120 minutes long (at the "EED" setting) can be recorded.

Visit website for information on available Microdrive / CompactFlash card: http://www.fujifilm.com/products/digital/

Quality	y setting	9M F	9M N	3:2	5M	ЗМ	2M	03M	RAW	640 (30 fps)	(30 fps)
Number	of recorded pixels	3488 >	× 2616	3696 × 2464	2592 × 1944	2048 × 1536	1600 × 1200	640 × 480	_ *	640 × 480	320 × 240
Image	data size	4.5 MB	2.2 MB	2.2 MB	1.2 MB	780 KB	630 KB	130 KB	18.8 MB	_	-
	16 MB	3	6	6	12	19	25	122	0	13 sec.	26 sec.
L L	32 MB	6	13	13	25	40	50	247	1	27 sec.	54 sec.
xD-Picture	64 MB	13	28	28	50	81	101	497	3	55 sec.	109 sec.
햞	128 MB	28	56	56	102	162	204	997	6	111 sec.	219 sec.
	256 MB	56	113	113	204	325	409	1997	13	223 sec.	7.3 min.
Card	512 MB	113	227	227	409	651	818	3993	27	7.4 min.	14.6 min.
۵ ا	1 GB	228	456	456	819	1305	1639	7995	54	14.9 min.	29.3 min.
	2 GB	456	913	913	1640	2558	3198	15992	108	29.8 min.	58.6 min.
Micro	drive 340 MB	77	155	155	279	445	559	2729	18	5.1 min.	10.0 min.
Micro	drive 1 GB	234	469	469	842	1313	1642	8212	55	15.3 min.	30.1 min.

\* Number of recorded pixel is 4864 × 3648 when displaying images on PC by using FinePixViewer.

If you shoot using the **xD-Picture Cards** with model numbers containing "M" such as DPC-M1GB, movie recording time may be reduced if you repeatedly record and erase (frame erase) image files. In such a case, erase all frames or format the **xD-Picture Card** before use. Back up important frames (files) onto your PC or another media.

- \* These specifications are subject to change without notice. FUJIFILM shall not be held liable for damages resulting from errors in this Owner's Manual.
- \* The LCD monitor on your digital camera is manufactured using advanced high-precision technology. Even so, small bright points and anomalous colors (particularly around text) may appear on the monitor. These are normal display characteristics and do not indicate a fault with the monitor. This phenomenon will not appear on the recorded image.
- \* The operation error may be caused in a digital camera by the strong radio interference (i. e. electric fields, static electricity, line noise, etc.).
- \* Due to the nature of the lens, the edges of images may appear distorted. This is normal.

## **Explanation of Terms**

#### Deactivated batteries

Leaving an Ni-MH battery unused in storage for a long period may cause a rise in the level of substances that inhibit current flow inside the battery and result in a dormant battery. A battery in this state is referred to as deactivated.

Because current flow is inhibited in a deactivated Ni-MH battery, the battery's original level of performance cannot be achieved.

#### ΕV

A number denotes Exposure Value. The EV is determined by the brightness of the subject and sensitivity (speed) of the film or CCD. The number is larger for bright subjects and smaller for dark subjects. As the brightness of the subject changes, a digital camera maintains the amount of light hitting the CCD at a constant level by adjusting the aperture and shutter speed.

When the amount of light striking the CCD doubles, the EV increases by 1. Likewise, when the light is halved, the EV decreases by 1.

#### Frame rate (fps)

The frame rate refers to the number of images (frames) that are photographed or played back per second. For example, when 10 frames are continuously photographed in a 1-second interval, the frame rate is expressed as 10 frs.

For reference, TV images are displayed at 30 fps (NTSC).

#### JPEG

Joint Photographic Experts Group

A file format used for compressing and saving color images. The higher the compression rate, the greater the loss of quality in the decompressed (restored) image.

#### Memory effect

If an Ni-MH battery is repeatedly charged without first being fully discharged, its performance may drop below its original level. This is referred to as the "memory effect".

#### Motion JPEG

A type of AVI (Audio Video Interleave) file format that handles images and sound as a single file. Images in the file are recorded in JPEG format. Motion JPEG can be played back by QuickTime 3.0 or later.

#### Smear

A phenomenon specific to CCDs whereby white streaks appear on the image when there is a very strong light source, such as the sun or reflected sunlight, in the photography screen.

#### WAVE

A standard format used on Windows systems for saving audio data. WAVE files have the ".WAV" file extension and the data can be saved in either compressed or uncompressed format. Uncompressed recording is used on this camera.

WAVE files can be played back on a personal computer using the following software:

Windows: MediaPlayer

Macintosh: QuickTime Player

\* QuickTime 3.0 or later

#### White Balance

Whatever the kind of the light, the human eye adapts to it so that a white object still looks white. On the other hand, devices such as digital cameras see a white subject as white by first adjusting the color balance to suit the color of the ambient light around the subject. This adjustment is called matching the white balance.



Exif Print Format is a newly revised digital camera file format that contains a variety of shooting information for optimal printing.

## Memo

	—
	_
	_
	_
	_
	_
	_
	_
	_
	_
	_
	_
	_
	_
	_
	_
	_
·	_
	_
	_
	_
	_
	—
	_
	_
	_
	_
	_
	_
·	_

## **FUJIFILM Digital Camera Worldwide Network**

If you have technical questions or if you need repair service, ask the following local distributor.

Please present the warranty card and your purchase receipt when you ask for repairs. Refer to the warranty card for conditions of the warranty. There is a case that repair and Technical support cannot be accepted for some models which your local distributor does not deal with.

These lists are subject to change without notice.

NORTH AME	RICA	
Canada	FUJIFILM Canada Inc.	
	Technical support	600 Suffolk Court Mississauga Ontario, L5R 4G4
		TEL 1-866-818-FUJI (3854) http://www.fujihelp.ca
	Repair service	600 Suffolk Court Mississauga Ontario, L5R 4G4
		TEL 1-800-263-5018 FAX 1-905-755-2993 http://www.fujihelp.ca
J.S.A.	FUJIFILM U.S.A., Inc.	
	Technical support	1100 King George Post Rd., Edison, NJ 08837
		TEL 800-800-3854 FAX 732-857-3487 digitalinfo@fujifilm.com
	Repair service	1100 King George Post Rd., Edison, NJ 08837
		TEL 732-857-3000 FAX 732-857-3471 njcamerarepair@fujifilm.com
lawaii	FUJIFILM Hawaii, Inc.	
	Technical support &	94-468 Akoki Street, Waipahu, HI. 96797
	Repair service	TEL 1-808-677-3854, ext. 209 FAX 1-808-677-1443 kurt_kmett@fujifilmhawaii.com
CENTRAL & S	SOUTH AMERICA	
rgentina	Imagen e informacion	S.A.
	Technical support &	Fondo de la Legua 936 San Isidro Pcia. de Buenos Aires
	Repair service	TEL +54-11-4836-1000 FAX +54-11-4836-1144 servtec@imageneinformacion.com.ar
olivia	Reifschneider Bolivia	
	Technical support &	Calle H N.° 5 - Equipetrol Norte - Santa Cruz
	Repair service	TEL +591 33 44 1129 FAX +591 33 45 2919 gciagral@bibosi.scz.entelnet.bo
razil	FUJIFILM do Brasil Lt	
	Technical support &	Av. Vereador José Diniz, 3400 - Campo Belo, São Paulo/SP
	Repair service	TEL 0800-12-8600 FAX +55 11 5091-4150 camarasdigitais@fujifilm.com.br
hile	Reifschneider SA	·==
	Technical support &	Av. El Conquistador del Monte 5024, Huechuraba, Santiago, Chile
	Repair service	TEL 02-4431500 FAX 02-4431596 ceciliacalvo@reifschneider.cl
olombia	Animex de Colombia I	
	Technical support &	Calle 44 N.º 13-43 Piso 2 Apartado 18001 - Bogotá
	Repair service	TEL +57 1 338-0299 FAX +57 1 288-2208 animex@etb.net.co
cuador	Espacri Cia Ltda	
	Technical support &	Bolivar 5-69 y Hermano Miguel
	Repair service	TEL 593-72-835526 FAX 593-72-833157
cuador	Importaciones Espacr	i Cia. Ltda.
	Technical support &	Simón Bolivar 5-69 y Hno. Miguel - Cuenca
	Repair service	TEL +593 783 5526 FAX +593 783 3157 portiz@fujifilm.com.ec
/lexico	Fujifilm de Mexico, S.	A. de C.V.
	Technical support	Av. Ejercito Nacional 351, Col. Granada 11520 Mexico, D.F.
		TEL (52-55) 5263-5566 / 68 FAX (52-55) 5254-1508 jlgiraud1@fujifilm.com.mx
	Repair service	Av. Presidente Juarez 2007, Col. Tepetlacalco, 54090 Tlalnepantla, Edo. de Mexico
		TEL (52-55) 5263-5500 FAX (52-55) 5254-1508 jlgiraud1@fujifilm.com.mx
araguay	Errece S.R.L.	
	Technical support &	Edificio Unitas 15 de Agosto 1035, Asunción
	Repair service	TEL +595 21 444256 FAX +595 21 444651 jmarbulo@fujifilm.com.py
'eru	Procesos de Color S.A	
	Technical support &	Pablo Bermudez 111 Apartado 3794 - Esq. Arequipa - Lima 11
	Repair service	TEL +51 14 33 5563 FAX +51 14 33 7177 jalvarado@fujifilm.com.pe
Jruguay	Fotocamara S.R.L.	
	Technical support &	Cuareim 1439, montevideo, Uruguay
	Repair service	TEL +598-2-9002004 FAX +598-2-9008430 fotocam@adinet.com.uy
Iruguay	Kiel S.A.	
	Technical support &	Maldonado 1787 Montevideo- Uruguay
	Repair service	TEL (05982) 419 4542 FAX (05982) 412 0046 kiel@fujifilm.com.uy
/enezuela	C. Hellmund & Cia Sa	
	Technical support &	Av. Ppal Diego Cisneros Caracas Venezuela Edf Oficentro
	Repair service	TEL 0212-2022300 FAX 0212-2399796 hellmund@hellmund.com
EUROPE		
ustria	Fuji Film Oesterreich	
iuoiila	Technical support &	Traviatanassa/Pfarrassa 1230 Vienna Austria
	Repair service	Traviatagasse/Pfarrgasse, 1230 Vienna, Austria TEL 0043 1 6162606/51 or 52 FAX 0043 1 6162606/58 kamera.service@fujifilm.at
Belgium	Belgian Fuji Agency	TEL 0040 TOTOZOUO/OT OF DZ FAA 0040 TOTOZOUO/OO KAITIETA.SETVICE@TUJITIM.At
Joigiuiii	Deigian Fuji Agency	OO Accessed accessing Marine 4000 Relations

20. Avenue Lavoisier, Wavre, 1300, Belgium

TEL 3210242090 FAX 3210238562 info@fuji.be

Technical support Hondlova 2, Zagreb, Croatia TEL 38512319060 FAX 2310240 dsaravanja@fujifilm.hr Repair service Hondlova 2, Zagreb, Croatia TEL 38512316228 FAX 2310240 info@fujifilm.hr PMS IMAGING LTD Cyprus Technical support & 11, Dighenis Akritas Avenue, P.O.BOX 22315, 1586 Nicosia Repair service TEL 35722746746 FAX 35722438209 mariosashiotis@fujifilm.com.cy **Doros Neophytou CAMERA REPAIRS** Cyprus Technical support & 28B. Agiou Demetriou, Acropoli, Nicosia TEL 35722314719 FAX 35722515562 dorosn@logosnet.cy.net Repair service Czech Republic Fujifilm Cz., s.r.o. Technical support U nakladoveho nadrazi 2/1949, 130 00 Praha 3 TEL 00420 234 703 411 FAX 00420 234 703 489 fricman@fuiifilm.cz Czech Republic AWH servis Repair service Milesovska 1, 130 00 Praha 3, Czech republic TEL 00420 222 721 525 FAX 00420 222 720 122 awh@awh.cz Denmark Fujifilm Denmark A/S Technical support & Stubbeled 2, 2950 Vedbæk Denmark TEL 0045 45662244 FAX 0045 45662214 fujifilm@fujifilm.dk Repair service Finland Fuji Finland Oy Technical support & Martinkyläntie 41, 01720 Vantaa, Finland Repair service TEL +358 9 825951 FAX +358 9 870 3818 fuji@fuji.fi France FUJIFILM France Technical support & 2. Avenue Franklin, 78186 Saint-Quentin en Yvelines, France Repair service FAX 33 1 01 30 58 58 65 direction.technique@fujifilm.fr FUJIFILM Europe GmbH Germany Technical support & Heesenstr. 70, 40549 Düsseldorf International call TEL +49 211 50890 FAX +49 211 5089668 service@fuiifilm.de Repair service National call\* TEL 0180 5898980 FAX 0180 5898982 \* 12 Cent/Min aus dem deutschen Festnetz **FUJIFILM HELLAS S.A.** Greece Technical support & 1, Ihous & Ag. Anargiron str., 175 64 P.Phaliro, Athens, Greece TEL 0030 210 9404100 FAX 0030 210 9404397 fujifilm@fujifilm.gr Repair service Hungary Fujifilm Hungary Ltd. Technical support Vaci ut 19. Budapest, 1134, Hungary TEL 3612389410 FAX 3612389401 fujifilm@fujifilm.hu Iceland Icephoto (Liosmyndayorur) Technical support & Skipholt 31, 105 Reykjavik, Iceland Repair service TEL 354 568 0450 FAX 354 568 0455 framkollun@fuiifilm.is Italy FujiFilm Italia S.p.A. Technical support Via Dell'Unione Europea, 4 - 20097 San Donato Milanese (MI), Italy TEL 039-02895821 FAX 039-0289582912 info@fujifilm.it Fujifilm On Line - Call center Repair service TEL 039-026695272 info@fujifilm.it Lithuania Fujifilm Lithuania Gerosios Vilties str. 38, LT-03143 Vilnius, Lithuania Technical support & Repair service TEL 370-5-2130121 FAX 3705-5-2134066 info@fujifilm.lt Malta Ciancio (1913) Co.Ltd. Technical support & Fuji Tech Centre, Ciancio House, Cannon Road, Qormi, QRM05 Repair service TEL 0356-21-480500 FAX 0356-21-488328 info@fujifilm.com.mt Netherlands Fuiifilm Nederland BV Technical support Hoogstraat 39, 3011 PE, Rotterdam, The Netherlands TEL 010-2812345 FAX 010-2812334 fuji@fujifilm.nl Hoevenseweg 43, 4877 LA, Etten-Leur, The Netherlands Repair service TEL 010-2812345 FAX 076-7502641 reparatie@fuiifilm.nl Norway Fuiifilm Norge AS Technical support Lilleakerveien 10, 0283 Oslo, Norway TEL 0047-22736000 FAX 0047-22736020 http://www.fujifilm.no/ mailto:post@fujifilm.no Liaveien 1, 5132 Nyborg, Norway Repair service TEL 0047-55393880 FAX 0047-55195201 http://www.camera.no/ mailto:service@camera.no Poland Fujifilm Polska Distribution Sp. z o.o. Poland Al..Jerozolimskie 178; 02-486 Warszawa Technical support TEL +48-22-517-66-00 FAX +48-22-517-66-02 fujifilm@fujifilm.pl Repair service Poland, Muszkieterow 15, 02-273 Warszawa TEL +48-22-886-94-40 FAX +48-22-886-94-42 serwis@fujifilm.pl Fujifilm Portugal, Lda Portugal Technical support Av. Fontes Pereira de Melo, 342, 4100-259 Porto, Portugal TEL (351) 226194200 FAX (351) 226194213 finepix@fujifilm.pt Av. Fontes Pereira de Melo. 342, 4100-259 Porto, Portugal Repair service TEL (351) 226194200 FAX (351) 225194662 cameras@fujifilm.pt

Croatia

I&I d.o.o.

Technical support &

Repair service

## **FUJIFILM Digital Camera Worldwide Network**

Technical support

Repair service

Romania	CTS-Cardinal Top Sy	
	Technical support &	112, Calea Dorobanti street, 4 flat, 1sector, Bucharest, Romania
D	Repair service	TEL 4021-230-09-82 FAX 4021-230-09-82 cts_tirla@hotmail.com
Russia	ZAO "Fujifilm RU"	Pld 1 10 Pozonova etr. Moscow 192007 Puscia
	Technical support	Bld. 1, 10, Rozanova str., Moscow, 123007, Russia TEL +7-095-956-9858 FAX +7-095-230-6217 info@fujifilm.ru
	Repair service	18, Shelepikhinskaya Naberezhnaya str., Moscow, 123290, Russia
	riopan corrido	TEL +7-095-797-3434 FAX +7-095-797-3434
Slovakia	Fujifilm Slovakia	
	Technical support	Pribylinska 2, 831 04 Bratislava, Slovakia
		TEL 00421 2 44 888 077 FAX 00421 2 44 889 300 fujifilm@fujifilm.sk
	Repair service	FIS Tatracentrum, Hodzovo nam. 4 - Tatracentrum, 811 06 Bratislava, Slovakia
D	F.::::::::::::::::::::::::::::::::::::	TEL 00421 2 54 647 347 fis.tatracentrum@stonline.sk
Spain	Fujifilm España S.A. Technical support	Aragón 180, 08011 Barcelona (España)
	recillical support	TEL 902012535 FAX 934515900 / 933230330 info@fujifilm.es
	Repair service	Aragón 180, 08011 Barcelona (España)
	riopan corrido	TEL 934511515 FAX 934515900 / 933230330 tallersat@fujifilm.es
Sweden	Fujifilm Sverige AB	,
	Technical support	Sveavägen 167 104 35 Stockholm
		TEL 46 8 506 141 70 FAX 46 8 506 142 09 kamera@fujifilm.se
	Repair service	Sveavägen 167 104 35 Stockholm
		TEL 46 8 506 513 54 FAX 46 8 506513 54 kameraverkstaden@fujifilm.se
Switzerland / Lic		40
	Fujifilm (Switzerland) Technical support &	Niederhaslistrasse 12, 8157 Dietlikon, Switzerland
	Repair service	TEL +41 44 855 5154 FAX +41 44 855 5329 RepairCenter@fujifilm.ch
Turkey	Fujifilm Turkiye Sinfo	
,	Technical support	Fujifilm Plaza, Dereboyu Cad. 39 34660 Halkali, Istanbul, Turkey
		TEL +90 212 696 5090 FAX +90 212 696 5009 csarp@fujifilm.com.tr
	Repair service	Fujifilm Plaza, Dereboyu Cad. 39 34660 Halkali, Istanbul, Turkey
		TEL +90 212 696 5090 FAX +90 212 696 5010 servis@fujifilm.com.tr
J.K.	FUJIFILM (UK) Ltd.	
	Technical support	St Martins Way St Martins Business Centre Bedford MK42 0LF
	Donair consisa	TEL +44 (0)123 424 5383 FAX +44 (0)123 424 5285 fujitec@fuji.co.uk
	Repair service	St Martins Way St Martins Business Centre Bedford MK42 0LF TEL +44 (0)123 421 8388 FAX +44 (0)123 424 5285 fujitec@fuji.co.uk
Ukraine	Image Ukraine CJSC	122 144 (0) 120 421 0000 1700 144 (0) 120 424 0200 Tajitoo@Tajitoo.aix
O'W WILL	Technical support &	12, Kontraktova ploshcha, Kyiv 04070, Ukraine
	Repair service	TEL +380-44-4909075 FAX +380-44-4909076 d@fujifilm.ua
MIDDLE EAST	•	
ran	Tehran Fuka Co.	
iaii	Technical support &	229, "Fuji" Bldg., Mirdamad Blvd., Tehran 19189, Iran
	Repair service	TEL (+98-21)2254810-19 FAX (+98-21)2221002 fuka@neda.net
srael	Shimone Group Ltd.	,
	Technical support	Efal 33 keyriat Arie Petah Tikva 49130, Israel
		TEL (+ ) 972 3 9250666 digital@fujifilm.co.il
	Repair service	Efal 33 keyriat Arie Petah Tikva 49130, Israel
		TEL (+ ) 972 3 9250666 FAX 972 3 9250699 khaim@shimone.com
Jordan	Grand Stores	
	Technical support &	Al- Abdali, Amman / Jordan
0.1	Repair service	TEL 009626-4646387 FAX 009626-4647542 gstores@go.com.jo
Qatar	Techno Blue Technical support	Blue Salon Bldg, 3rd Floor, Suhaim bin Hamad st, Al- Saad, Doha
	roomnoar support	TEL 00974 44 66 175 FAX 00974 44 79 053 prabu@techno-blue.com
Saudi Arabia	Emam Distribution C	
	Technical support	P.O. Box 1716, Jeddah 21441, Saudi Arabia
		TEL 96626978756 FAX 96626917036 service@fujifilm.com.sa
Syria	Film Trading Compar	ny
	Technical support	Al-Shahbandar P.O. Box:31180 Damascus SYRIA
		TEL + 963 11 2218049 FAX + 963 11 44673456 f.t.c@Net.SY
	Repair service	Al-cheikh Taha P.O. Box: 6171 Aleppo SYRIA
	Crand Stares	TEL + 963 21 4641903 FAX + 963 21 4641907 filmtradin@Net.SY
U.A.E. Yemen	Grand Stores Technical support &	P. O. Box 2144, Saleh Bin Lahej Building, Al Garhoud, Deira, Dubai
	Repair service	TEL + 971-4-2823700 FAX + 971-4-2828382 photography@grandstores.ae
	Al-Haidary Trading	. 22 - 07. 1. 2020. 00 1710. 7 07. 1 4 2020002 priotography@grandotoleo.de
	Technical support	P.O. Boy-2942 Haddah St. HTC. Sana'a, Vemen

P.O.Box-2942 Haddah St. HTC, Sana'a, Yemen TEL 00967-1-503980 FAX 00967-1-503983 P.O.Box-2942 Haddah St. HTC, Sana'a, Yemen

AFRICA					
Egypt	Foto Express Egypt				
	Technical support &	426 Pyramids St., Giza, Egypt			
14	Repair service	TEL (202) 7762062 FAX (202) 7760169 fotoegypt@access.com.eg			
Kenya	Fuji Kenya Ltd Repair service	P.O.Box 41669-00100, Fuji Plaza, Chiromo Road, Nairobi, Kenya.			
	nepair service	TEL (254-20)4446265-8 FAX (254-20)4448515 / 7 info@fujifilm.co.ke			
OCEANIA		122 (20 1 20) 11 10200 0 17 W (20 1 20) 11 100 10 7 7 III 10@ Idjiiii 11 100 100			
Australia	FUJIFILM Australia Pt	v I td			
Australia	Technical support &	Locked Bag 5100, Brookvale, NSW, 2100			
	Repair service	TEL 1800 226 355 FAX +61 (2) 9466 2854 digital@fujifilm.com.au			
Fiji	Brijlal & Co. Ltd				
	Technical support &	70-72 Cumming Street, Suva, Fiji			
Nam Oaladasia	Repair service	TEL (679)3304133 FAX (679)3302777 kapadia@connect.com.fj			
New Caledonia	Phocidis SARL Technical support &	58, rue Higginson - B.P.661 - 98845			
	Repair service	TEL (00 687) 25-46-35 FAX (00 687) 28-66-70 phocidis@phocidis.nc			
New Zealand	Fujifilm NZ Ltd	, , , , , , = ,			
	Technical support &	Cnr William Pickering & Bush Road Albany, Auckland			
	Repair service	TEL +64-9-4140400 FAX +64-9-4140410 glenn.beaumont@fujifilm.co.nz			
Papua New Guinea		Section 15 Alletmont 1 Boke St Baroke NCD BNG Mail: BO Box 2167 Boroke NCD BNG			
	Technical support	Section 15, Allotment 1, Reke St, Boroko NCD. PNG. Mail: PO Box 2167, Boroko NCD. PNG TEL +675 3256411 FAX +675 3250311 oceania@daltron.com.pg			
ASIA					
Hong Kong	Fuji Photo Products C	to. Ltd.			
	Technical support &	8/F.,TSUEN WAN IND. CENTRE, 220 TEXACO RD., TSUEN WAN, HONG KONG			
	Repair service	TEL (852)2406 3287 FAX (852)2408 3130 rsd@chinahkphoto.com.hk			
Indonesia	PT Modern Photo Tbk				
	Technical support &	JI.Matraman Raya 12, Jakarta Timur 13150			
	Repair service	TEL +62 021 2801000 FAX +62 021 8581620+62 021 2801012 assd_kmr@moderngroup.co.id			
Malaysia	FUJIFILM (Malaysia) Sdn. Bhd.				
	Technical support	Letter Box 1, Level 10, 11 & 12, Menara Axis, No 2, Jalan 51A/223, 46100 Petaling Jaya,			
		Selangor Darul Ehsan, Malaysia			
		TEL 603-79584700 FAX 603-79584110 digital@fujifilm.com.my			
	Repair service	Letter Box 1, Level 10, 11 & 12, Menara Axis, No 2, Jalan 51A/223, 46100 Petaling Jaya,			
		Selangor Darul Ehsan, Malaysia TEL 603-79584700 FAX 603-79584110 technical@fujifilm.com.my			
Philippines	YKL Development & Trdg. Corp.				
	Technical support	24 Sto. Domingo St., Quezon City 1100, Philippines			
		TEL 632-7436601~06 FAX 632-7324661 digital@yklcolor.com			
	Repair service	24 Sto. Domingo St., Quezon City 1100, Philippines			
Singapore	FUJIFILM (Singapore)	TEL 632-7436601~06 FAX 632-7324661 tech_services@yklcolor.com			
Singapore	Technical support &	10 New Industrial Road Fujifilm Building Singapore 536201			
	Repair service	TEL 65-6380 5557 FAX 65-6281 3594 service@fujifilm.com.sg			
South Korea	Korea Fujifilm Co., Ltd				
	Technical support	30-1, Mukjeung-dong, Jung-gu, Seoul, Korea			
	Vancon AC Contas (Es	TEL +82-2-3282-7363 FAX +82-2-2269-7435 photo@fujifilm.co.kr			
	Yonsan AS Center (Fujidigital) Repair service #301, 3F, Jeonjaland, 16-9, Hangangro3-ga, Yongsan-gu, Seoul, Korea				
	riopair service	TEL +82-2-701-1472 FAX +82-2-718-1331 1bowl@hanmail.net			
South Korea	Kangnam AS Center (Digitalgallery)				
	Repair service	2F, Hyeongin Tower, 23-2, Bangyi-dong, Songpa-gu, Seoul, Korea			
0	D 40 0t- (D)	TEL +82-2-2203-1472 FAX +82-2-418-5572 nurijili@hanmail.net			
South Korea	Busan AS Center (Dig Repair service	ıtar-sewon) 241-4, Bujeon-dong, Busanjin-gu, Busan, Korea			
	riepaii service	TEL +82-51-806-1472 FAX +82-51-817-0083 merahan@yahoo.co.kr			
Taiwan	Hung Chong Corp.				
	Technical support &	No. 38, Min-Chuan E. Rd. Sec. 6, Taipei (114), Taiwan, R.O.C.			
	Repair service	TEL 886-2-6602-8988 FAX 886-2-2791-8647 dah@mail.hungchong.com.tw			
Thailand	FUJIFILM (Thailand) L				
	Technical support	388 SP Building, 8th Floor, Phayathai, Bangkok 10400			
	Repair service	TEL +662-2730029 ext. 755 FAX +662-2730239 supaleark@fujifilm.co.th 388 SP Building, 8th Floor, Phayathai, Bangkok 10400			
		TEL +662-2730029 ext.761,762 FAX +662-2730239 warin@fujifilm.co.th			
		= *			

156 TEL 00967-1-503977 FAX 00967-1-503983

## Memo

-	
-	

## **Safety Notes**

- Make sure that you use your IS-1 camera correctly.
   Read these Safety Notes and your Owner's Manual carefully before use.
- After reading these Safety Notes, store them in a safe place.

#### About the Icons

The icons shown below are used in this document to indicate the severity of the injury or damage that can result if the information indicated by the icon is ignored and the product is used incorrectly as a result.

**⚠ WARNING** 

This icon indicates that death or serious injury can result if the information is ignored.

**⚠** CAUTION

This icon indicates that personal injury or material damage can result if the information is ignored.

The icons shown below are used to indicate the nature of the information which is to be observed.



Triangular icons tell you that this information requires attention ("important").



Circular icons with a diagonal bar tell you that the action indicated is prohibited ("Prohibited").



Filled circles with an exclamation mark tell you an action that must be performed ("Required").

## **. ! WARNING**

If a problem arises, turn the camera off, remove the batteries, disconnect and unplug the AC power adapter.

Continued use of the camera when it is emitting smoke, is emitting any unusual odor, or is in any other abnormal state can cause a fire or electric shock.

Contact your FUJIFILM dealer.



power socket


Do not allow water or foreign objects to enter the camera.

If water or foreign objects get inside the camera, turn the camera off, remove the batteries and disconnect and unplug the AC power adapter. Continued use of the camera can cause a fire or electric shock.



• Contact your FUJIFILM dealer.

Do not use the camera in the bathroom or shower.






Do not use in the bathroom or shower.

Never attempt to change or take apart the camera. (Never open the casing.) Do not use the camera when it has


been dropped or the casing is damaged.






Do not disassemble

Do not change, heat or unduly twist or pull the connection cord and do not place heavy objects on the connection cord.



and cause a fire or electric shock.If the cord is damaged, contact your





This can cause the camera to fall or tip over and cause injury.




Never attempt to take pictures while in motion.

Do not use the camera while you are walking or driving a vehicle.





This can cause an electric shock due to induced current from the lightning discharge.



Load the batteries with the  $\oplus$  and  $\ominus$  marks.



## **!** WARNING

Do not heat, change or take apart the batteries.

Do not drop or subject the batteries to impacts.

Do not attempt to recharge lithium or

alkaline batteries.

Do not store the batteries with

metallic products.

Do not use chargers other than the

specified model to charge the batteries.

Any of these actions can cause the

batteries to burst or leak and cause fire or injury as a result.

Use only the batteries or AC power adapters specified for use with this camera.


Do not use voltages other than the

power supply voltage shown.

The use of other power sources can

The use of other power sources can cause a fire.

If the battery leaks and fluid gets in contact with your eyes, skin or clothing. Flush the affected area with clean water and seek medical attention or call an emergency number right away.



The charger is designed for Fujifilm HR-AA Ni-MH batteries. Using the charger to charge conventional batteries or other types of rechargeable batteries can cause the battery to leak fluid, overheat or burst.

When discarding or storing batteries, cover the battery terminals with insulation tape.

 Contact with other metallic objects or batteries could cause the batteries to ignite or burst.

Keep xD-Picture Cards out of the reach of small children.

Because xD-Picture Cards are small, they can be swallowed by children. Be sure to store xD-Picture Cards out of the reach of small children. If a child swallows an xD-Picture Card, seek medical attention or call an emergency number.



## ! CAUTION

Do not use this camera in locations affected by oil fumes, steam, humidity or dust.




Do not leave this camera in places subject to extremely high temperatures.

Do not leave the camera in locations such as a sealed vehicle or in direct sunlight. This can cause a fire.




Keep out of the reach of small children.


This product could cause injury in the hands of a child.




This can cause the heavy object to tip over or fall and cause injury.




to disconnect the AC power adapter.
This can damage the power cord or cables and cause a fire or electric shock.




This could cause a fire or electric shock.




This can cause heat to build up and distort the casing or cause a fire.



Failure to do so can cause a fire or electric shock.




Leaving the charger plugged into the power socket can cause a fire.



Take particular care when photographing infants and young children.

When an **xD-Picture Card** is removed, the card could come out of the slot too quickly. Use your finger



cleaning for your camera.

Build-up of dust in your camera can

cause a fire or electric shock.
 Contact your FUJIFILM dealer to request internal cleaning every 2 years.

 Please note this is not a free of charge service.



## Memo

	_
	_
	_
	_
	_
	_
-	
	_
	_
	_
	_
-	_
	_
-	

## **FUJIFILM**

FUJIFILM Corporation
MIDTOWN WEST, 7-3, AKASAKA 9-CHOME, MINATO-KU, TOKYO 107-0052, JAPAN
http://www.fujifilm.com/products/digital/